

Remove the standard four pin fixed type float chamber from your Amal Mark 2 Concentric carburettor. This exposes the jet holder and associated main jet and needle jet, all of which should be removed. Insert the four locating pins (1) contained in the QD Kit in the corners of the carburettor body in place of the original float chamber fixing pins.

Remove needle jet and main jet from original jet holder and fit to the new jet holder (2) provided. Refit tightly to carburettor body.

Carefully remove all components from the old float chamber; jets, float, float hinge pin, fuel inlet valve, fuel pipe connections and filter and fit to QD float chamber (3). Do not forget the cold start jet and pilot passage blanking plug.

Refit with new float chamber face gasket (4) and drain plug washer (5). Locating float chamber beneath the carburettor body, secure with combined drain plug/release bolt (6).

