

Parts - Tools - Accessories Bulletin

June 19, 1967

67-9P

SUBJECT: CD466B AND CD466C LOWER SADDLEBAG MOUNTS

The CD466B and CD466C Lower Saddlebag Mounts are used in conjunction with the CD464 and CD469 Combination Accessory Groups to mount CD144 or CD279 saddlebags. The CD466B mounts are used on 650cc models, and the CD466C mounts on 500cc models.

MOUNTING INSTRUCTIONS:

1. Attach the lower saddlebag mount at the upper rear using the rear support bracket bolts of the Combination Accessory Group. On 650cc models, use the muffler bolt to attach the saddlebag mount at the lower front, and on 500cc models use the Pillion Footrest Bolt (see illustration below).
2. Insert the rubber-covered "Well Nuts" supplied with the lower saddlebag mounts into the large $\frac{1}{2}$ " holes in the side rails of the Combination Accessory Group from the outside.
3. Hook one of the slots in the steel backing plate attached to the saddlebag on the rivet welded to the lower saddlebag mount and position the mounting holes in the saddlebag over the "Well Nuts".
4. Insert the 1- $\frac{1}{4}$ " machine screws through the holes from inside the bag, using the spring clips as washers for the screws. As the screws are tightened the "Well Nut" will expand behind the side rail to firmly secure the saddlebag in place.

