

Float Chambers

Type 302	Type 504	Type 510
ALTERNATIVE BANJO CONNECTIONS FOR TYPES 302 & 504	ALTERNATIVE BANJO CONNECTIONS FOR TYPE 510	



LIST No. 115/2.

September 1964

SPARE PARTS LIST

FOR TYPE 302 RIGID AND TYPES 504 AND 510 REMOTE FLOAT CHAMBERS

	TYPE 302			TYPE 504		TYPE 510
	RIGID	RIGID	REMOTE	REMOTE		REMOTE
	PART No.	ART No	PAR	ART No.	PART No.	PART No
Float Chamber Complete	302/1	302/10	302/18	504/1	504/2	510/1
Float Chamber Body only ..	302/001	302/001	302/015	504/001	504/001	510/001
Float Chamber Cover complete	302/002	302/002	302/002	504/008	504/008	510/003
Float Chamber Cover Washer						510/004
Cover Fixing Screws ..	302/009	302/009	302/009	302/009	302/009	302/009
Tickler	302/010	302/010	302/010	504/007	504/007	14/333
Tickler Spring	14/032	14/032	14/032	14/032	14/032	14/032
Tickler Cotter	14/033	14/033	14/033	14/033	14/033	14/033
Tickler Washer	14/189	14/189	14/189	14/189	14/189	14/189
Float	302/004			504/005	504/005	
Float See note	302/032		—	—		10/009
Float	302/042	302/042	302/042			—
Float Needle w re	14/320					10/006
Float Needle	302/035					
Float Needle	302/044	302/044	302/044	302/044	302/044	
Base Plug and Guide	14/321-2			—		
Base Plug and Guide tion *	14/322-302/036					
Base Plug and Guide	302/045-6	302/045-6	302/045-6			
Base Plug Washer	14/252	14/252	14/252			
Banjo (see illustrations, page 3)	as required	s required	14/250	s required	as required	as required
Banjo Nut or Bolt	14/255	14/255	14/255	302/043	302/043	510/011
Banjo Washers	14/275	14/275	14/275	14/275	14/275	510/012
Petrol Union Nuts	14/042	14/042	14/042	14/042	14/042	14/042
Petrol Union Nipples ..	14/041	14/041	14/041	14/041	14/041	14/041
Plug Screw	14/232	14/232				510/019
Plug Screw Washer	14/241	14/241				14/336
Float Chamber Connection ..			302/071	4/219	302/070	14/219
Float Chamber Cont'n Washer			14/037	4/336	14/336	14/336
Banjo Connection (for M/ch.)			302/057			
Banjo Connection Washer ..			14/336			
Banjo Nut (Outlet)			302/056			
Base Plug and Guide (Excelsior)	302/069-046	302/069-046	302/069-046			
Needle Seating Washer ..						14/047
Needle Seating						510/005
Float Hinge Spindle Washer						116/162
Float Hinge Spindle complete						510/018
Banjo Bolt Washer						178/035

*Original part numbers 302/004, 14/320, 14/321-2, were modified to 302/032, 302/035, 14/322-302/036 since when a further modification was made, i.e., 302/042, 302/044, 302/045-6.

We suggest that parts prior to the last modification should be replaced as an assembly so bringing the float chamber to the latest setting.

GUARANTEE.—The Company take all possible reasonable care in the manufacture and the quality of their products. Purchasers are informed that, any part proved to be defective in manufacture or quality, and returned to the works within six months of its purchase new, will be replaced. The Company must respectfully point out however, that its responsibility and that of its agents, stockists and dealers, is limited to this Guarantee, and that they cannot, under any circumstances, be held responsible for any loss or for any contingent or resulting liability arising through any defect. These conditions of sale and use also apply when the Company's products form part of the original equipment of machines purchased new.

PAGE FOUR


Printed in England. 1,000/9/64.

**AMAL LTD., HOLDFORD ROAD, WITTON,
BIRMINGHAM 6, ENGLAND**

'Phone : Birmingham, BIRchfields 4571.
(P.B.X. 6 lines)

Telegrams : "AMALCARB, 'PHONE,
BIRMINGHAM."

G.P.2 Mixing Chamber





September, 1964.

LIST No. 115/2 (Issue No. 4)

SPARE PARTS FOR Type G.P.2 RACING CARBURETTOR (With TYPE 302 RIGID & TYPES 504 & 510 REMOTE FLOAT CHAMBERS)

COMPONENT	FOR T15GP2	FOR T10GP2	FOR T5GP2	FOR T3GP2
Mixing Chamber Body	Specify Engine Details	Specify Engine Details	Specify Engine Details	Specify Engine Details
Mixing Chamber Top	316/097	316/045	316/049	316/414
Mixing Chamber Cap	316/103	316/046	316/050	316/412
Lock Spring for Mixing Chamber Cap	316/098	316/126	316/048	316/402
Adjuster for Throttle Cable	316/159	316/159	316/159	316/159
Lock Nut for ditto	3369	3369	3369	3369
Throttle Cable Adjuster Sheath	316/083	316/083	316/083	316/083
Throttle Valve (Standard)	316/104	316/010	316/020	316/413
Throttle Valve, opposite Standard, Twin Carbs. ..	316/185	316/013	316/189	—
Throttle Valve Screwed Nipple	5/204	5/204	5/204	5/204
†Throttle Valve Spring	175/308	316/458	316/459	316/466
Jet Needle (Standard)	316/007	316/007	316/146	316/465
Jet Needle (Weak)	316/030	316/030	316/029	316/408
Jet Needle Clip	316/021	316/021	316/021	316/021
Jet Needle Clip Screw	316/015	316/015	316/015	316/015
*Choke Adaptor (Please state bore size)	Not normally supplied separately from M/c. body			
Choke Adaptor Washer	316/100	316/005	316/025	316/462
Choke Adaptor Securing Screws	316/489	316/489	316/489	316/489
Spray Tube	316/067	316/067	316/144	316/144
*Air Tube (Please state bore size when ordering) ..	Not normally supplied separately from M/c. body			
Air Tube Lock Ring	175/115	175/119	175/371	316/411
Main Jet	3326	3326	3326	3326
Jet Holder	15/625	15/625	316/027	316/027
Jet Holder Plug Screw	3348	3348	3348	316/028
Jet Holder Plug Screw	—	185/282	316/028	—
Needle Jet	316/065	316/065	316/065	316/065
Air Valve Cable Adjuster	2626	2626	2626	2626
Lock Nut for ditto	2627	2627	2627	2627
Air Barrel Top	2507	2507	2507	2507
Air Barrel Plug Screw	—	—	—	185/280
Air Valve	2502	2502	2502	2502
Air Valve Spring	2558	2558	2558	2558
Air Valve Nipple Holder	2503	2503	2503	2503
Air Valve Nipple	2629	2629	2629	2629
Air Jet	316/052	316/052	316/052	316/052
Air Jet Plug Screw	316/456	316/456	316/456	316/456
Air Jet Plug Screw Washer	38/023	38/023	38/023	38/023
Pilot Jet	376/076	376/076	376/076	376/076
Pilot Jet Cover Nut	316/494	316/494	316/494	316/494
Pilot Cover Nut Washer	116/162	116/162	116/162	116/162
Pilot Air Adjuster	332/017	332/017	332/017	332/017
Pilot Plug Screws	2403	2403	2403	2403
Pilot Air Adjuster Locknut	332/020	332/020	332/020	332/020
Pilot Air Connection	316/490	316/490	316/490	316/490
Banjo Connection for Remote Float Chamber ..	14/218	14/218	14/218	14/218
Banjo Washer	36/006	36/006	36/006	36/006
Outlet Clip	27/073	27/072	316/421	316/421
Outlet Clip Screw	1962	1962	316/422	316/422
Jet Key	244/1397	244/1397	244/1397	244/1397

†When twin carburettors fitted this component is 75/395 for Type 15, 316/406 for Type 10, and 175/396 for Type 5.
*These parts are not normally supplied separately as they are machined in position with the mixing chamber body.

**AMAL LTD., HOLDFORD ROAD, WITTON,
BIRMINGHAM 6, ENGLAND**
'Phone : Birmingham, BIRchfields 4571. Telegrams : "AMALCARB, 'PHONE.
(P.B.X. 6 lines) BIRMINGHAM."