

20-10227C



REPLACEMENT PARTS CATALOGUE

No. 15

6T	-	THUNDERBIRD
T100	-	TIGER 100
T110	-	TIGER 110
TR6	-	TROPHY
T120	-	BONNEVILLE 120

FROM ENGINE No. 020076

SEPTEMBER 1958

TRIUMPH ENGINEERING COMPANY LIMITED
MERIDEN WORKS, ALLESLEY
COVENTRY

Telegrams (for Spares)
"Trusty, Coventry"

Telephone
Meriden 331

British Only

MOTORCYCLES AND PARTS INC.

32451 PARK LANE
GARDEN CITY, MI 48135 USA

PHONE ORDER HOURS:
MONDAY THRU FRIDAY 10-6 EST

Fax or email 24 hours a day!

RETAIL: 734-421-0303
WHOLESALE: 734-525-1980
FAX: 734-422-9253
EMAIL: info@britishonly.com
WEBSITE: www.britishonly.com

THE BIGGEST!

ENGINE REBUILDING PARTS
GASKETS-SEALS-BEARINGS
BUSHINGS-PISTONS-RINGS
CLUTCHES-TUNE UP PARTS
SPEED EQUIPMENT

THE BEST!

STOCK AND CUSTOM PARTS
SEATS-HANDLEBARS-CHAINS
TIRES-TUBES-EXHAUST PIPES
MUFFLERS-GAS TANKS-FENDERS
RESTORATION PARTS

THE ONLY!

WORLD'S LARGEST SELECTION OF FACTORY ORIGINAL NEW AND USED PARTS
45,000 SQ. FT. OF MOTORCYCLE PARTS & ACCESSORIES FROM 1911 TO 1984 FOR ALL BRITISH MAKES!
CASH FOR ALL BRITISH BIKES, PARTS AND LITERATURE

V.I.P. Buyers Club

10% OR MORE OFF 17,000 PARTS



British Only E-Store

Bookstore
New Products
Scratch & Dent
Blue Light Specials

50,000+ PARTS
LISTED ONLINE
7,000+ PARTS
VIEWABLE ONLINE

CALL FOR OUR FREE
200 PAGE CATALOG!

OVERSEAS CUSTOMERS PLEASE SEND \$10.00 FOR AIR POST

1-800-BRT-ONLY

OR

1-800-278-6659

Visit our ever expanding website!

www.britishonly.com

50,000+ PARTS LISTED ONLINE

7,000+ PARTS VIEWABLE ONLINE

SPECIALIZING IN:

TRIUMPH

Norton

BSA

PARTS
SHIPPED
WORLDWIDE!



Parts sent to Coventry for repair, replacement or as patterns should bear the sender's name and address and clear instructions should accompany the parts. All parts must be forwarded carriage paid and care should be taken to ensure that all remittances are sent separately and not enclosed with the parts. Fragile units such as cylinders, etc., should always be boxed to avoid damage in transit. Complete machines should have all fitments such as horns, driving mirrors, tools, etc., removed by the sender before despatch, as it is impossible for us to accept responsibility in the event of loss in transit. We are always pleased to give estimates for overhauling and repairs, but should an estimate not be accepted, a charge will be made covering cost of dismantling and re-assembling, if carried out.

Communications relating to Parts should be addressed to the SPARES MANAGER and for repairs, guarantee claims and technical advice to the SERVICE MANAGER, Triumph Engineering Co. Ltd., Meriden Works, Allesley, Coventry. In order to facilitate quick reference, the quoting of any number, invoice number or reference from previous communications is of essential importance. **Accessories not of our manufacture should be sent direct to the actual makers, whose names and addresses appear on Page 90.**

WHERE TO OBTAIN. Triumph Spare Parts may be obtained from any Triumph Dealer, and we recommend our customers to place their orders with the Triumph Dealer in their district, as we do not normally supply direct. When parts not usually asked for are required, and for which the Dealer may have to wire or obtain specially, the postage or carriage incurred becomes payable.

We are not able to supply Transfers as originally affixed to Triumph Motor Cycles, but we are at all times willing to supply a transfer denoting that the machine is of genuine Triumph manufacture, provided the Frame and Engine prefix letters and numbers are quoted.

Customers are warned against the risk incurred by purchasing parts that are not of genuine Triumph manufacture. This risk is eliminated if parts are ordered as instructed, either from our recognised Dealers, or direct from the Spares Department, Meriden Works, Allesley, Coventry.

TERMS OF BUSINESS


THE most convenient method of paying for Spare Parts is by the C.O.D. system. By this method you pay the postman for the goods when he delivers them to you. As the minimum C.O.D. collection fee is 1/2, only goods to the value of 2/- and over can be sent by this system. We do not despatch goods by rail C.O.D.

Where goods are not sent C.O.D., cash must accompany the order. All remittances should be made payable to the Triumph Engineering Co. Ltd., and crossed "Barclay's Bank Ltd." if in the form of Postal Order or cheque. Letters containing currency notes must be registered.


Should a remittance be forwarded by telegraphic money order, the name and address of the sender must be inserted in the space provided on the Post Office requisition form for a private message from remitter to payee. Unless this is complied with the Post Office omit such information from the telegram and we are not then in a position to trace the sender.

Postage, carriage and packing is charged at 5% on the value of the goods, minimum charge 1/-. Packing boxes, cases, crates, etc., are charged for at cost and are returnable.

THUNDERBIRD (6T)



TIGER 100 (T100)



THUNDERBIRD (6T)

SPECIFICATION


Bore and stroke, mm. ...	...71 × 82	Ignition (fully retard)	
ins. ...	2.79 × 3.23	ins. (mm.) ...	$\frac{1}{32}$ (0.8) B.T.C.
Cylinder capacity		Piston ring gap (Compression and	
c/cm. (cu. ins.) ...	649 (40)	Scraper) ins. (mm.)	.010-.014 (.25-.35)
Compression ratio ...	... 7 : 1	Petrol tank, gallons (litres) ...	4 (18)
Engine sprocket ...	... 24	Oil tank, pints (litres) ...	5 (3)
Tappet clearance, cold		Weight, lbs. (dry) (kilos)	385 (175)
ins. (mm.) ...	.010 (.26)		

TIGER 100 (T100)


SPECIFICATION

Bore and stroke, mm. ...	...63 × 80	Ignition, fully advanced	
ins. ...	2.48 × 3.15	ins. (mm.) ...	$\frac{3}{8}$ (9.5) B.T.D.C.
Cylinder capacity		Piston ring gap	
c/cm. (cu. ins.) ...	498 (30.5)	Compression—	
Compression ratio ...	... 8 : 1	ins. (mm.) ...	.010-.014 (.25-.35)
Engine sprocket, solo ...	... 22	Scraper—	
Carburetter main jet (Amal) ...	220	ins. (mm.) ...	.007-.011 (.18-.28)
Carburetter pilot jet (Amal) ...	25	Petrol tank, gallons (litres) ...	4 (18)
Carburetter slide (Amal) ...	...376/3 $\frac{1}{2}$	Oil tank, pints (litres) ...	5 (3)
Carburetter needle jet (Amal) ...	.1065	Weight lbs. (dry) (kilos)	375 (170)
Tappet clearance, cold			
ins. (mm.) ...	.010 (.26)		

TIGER 110 (T110)



TROPHY (TR6)



TIGER 110 (T110)

SPECIFICATION

Bore and stroke, mm. ...	...71×82	Tappet clearance, cold ...	.004 ex (.10)
ins. ...	2.79×3.23	ins. (mm.) ...	.002 in. (.05)
Cylinder capacity		Ignition, fully advanced	
c/cm. (cu. ins.) ...	649 (40)	ins. (mm.) ...	$\frac{23}{64}$ (9.2) B.T.D.C.
Compression ratio ...	8 : 1	Piston ring gap (Compression and	
Engine sprocket, solo ...	24	Scraper) ins. (mm.)	.010-.014 (.25-.35)
Carburetter main jet (Amal) ...	*250	Petrol tank, gallons (litres) ...	4 (18)
Carburetter pilot jet (Amal) ...	25	Oil tank, pints (litres) ...	5 (3)
Carburetter slide (Amal) ...	376/3 $\frac{1}{2}$	Weight lbs. (dry) (kilos)	395 (179)
Carburetter needle jet (Amal) ...	.1065		

*270 without air filter


TROPHY (TR6)

SPECIFICATION

Bore and stroke, mm. ...	...71×82	Tappet clearance, cold ...	.004 ex (.10)
ins. ...	2.79×3.23	ins. (mm.) ...	.002 in. (.05)
Cylinder capacity		Ignition, fully advanced	
c/cm. (cu. ins.) ...	649 (40)	ins. (mm.) ...	$\frac{23}{64}$ (9.2) B.T.D.C.
Compression ratio ...	8 : 1	Piston ring gap (Compression and	
Engine sprocket, solo ...	24	Scraper) ins. (mm.)	.010-.014 (.25-.35)
Carburetter main jet (Amal) ...	*250	Petrol tank, gallons (litres) ...	4 (18)
Carburetter pilot jet (Amal) ...	25	Oil tank, pints (litres) ...	5 (3)
Carburetter slide (Amal) ...	376/3 $\frac{1}{2}$	Weight lbs. (dry) (kilos)	370 (168)
Carburetter needle jet (Amal) ...	.1065		

*270 without air filter

BONNEVILLE 120 (T.120)



SPECIFICATION

Bore and stroke, mm. ...	... 71 × 82	Carburetter needle jet (Amal) ...	·1065
ins. ...	2·79 × 3·23	Tappet clearance, cold ...	·004 ex (·10)
Cylinder capacity		ins. (mm.) ...	·002 in (·05)
c/cm. (cu. ins.) ...	... 649	Ignition, fully advanced	
Compression ratio ...	... 8 : 1	ins. (mm.) ...	$\frac{7}{16}$ " (11) B.T.D.C.
Engine sprocket, solo ...	... 24	Piston ring gap (Compression and Scraper) ins. (mm.)	·010-·014 (·25-·35)
Carburetters main jet (Amal) ...	240	Petrol tank, gallons (litres) ...	4 (18)
Carburetter pilot jet (Amal) ...	25	Oil tank, pints (litres) ...	5 (3)
Carburetter slide (Amal) ...	376/3½	Weight lbs. (dry) (kilos)	395 (179)

CARTON PACK — GROUP 1

Piston assemblies Part No. CP29, CPI58, CP98, CPI59, CPI63, CPI57 and Piston ring pack CP99 are being changed to include two taper compression rings instead of one plain and one taper ring.

The taper rings are, of course, fitted in the two top grooves with the etched marking "TOP" uppermost. If only one taper ring is supplied this should be fitted in the middle groove.

CARTON PACK COMPONENT LIST—GROUP I

The following sub-assemblies are supplied in carton packs under the C.P. part number stated. The contents of these carton packs are preserved and will not deteriorate under adverse conditions.

PART No.

DESCRIPTION AND CONTENTS

Brake Lining

CP.38	2	...	...	NW.243	...	...	...	Lining, brake
	16	...	...	W.129	...	...	...	Rivet

CP.66	2	...	...	W.631	...	...	...	Lining, brake
	16	...	...	W.129	...	...	...	Rivet

Crankcase Bearing

CP.144	...	2	...	...	E.1591	...	...	Bearing ball, d/s and t/s
--------	-----	---	-----	-----	--------	-----	-----	---------------------------

Fork (Telescopic) Service Pack

CP.50	...	...	2	...	...	H.443	...	...	Bearing, lower
			2	...	...	H.441	...	...	Bearing, upper
			2	...	...	E.1335	...	...	Washer, copper
			4	...	...	H.430	...	...	Washer, drain filler plug
			2	...	...	H.452	...	...	Restrictor, oil
			2	...	...	H.453	...	...	Cup, oil restrictor
			2	...	...	H.454	...	...	Pin, restrictor cup
			2	...	...	H.391	...	...	Washer, dust excluder felt
			2	...	...	H.420	...	...	Washer, outer cover felt
			2	...	...	H.1065	...	...	Washer, aluminium

Gears, Standard Ratio (to convert from Wide ratio)

CP.145	...	1	...	...	T.1382	...	...	...	Gear, mainshaft high
		1	...	...	T.916	...	...	...	Gear, mainshaft 2nd
		1	...	...	T.1063	...	...	...	Gear, layshaft and high
		1	...	...	T.1065	...	...	...	Gear, layshaft 2nd
		1	...	...	T.934	...	...	...	Gear, speedometer driven

Gears, Wide Ratio (to convert from Standard ratio)

CP.94	...	...	1	...	...	T.1384	...	...	Gear, mainshaft high
			1	...	...	T.968	...	...	Gear, mainshaft 2nd
			1	...	...	T.971	...	...	Gear, layshaft and high
			1	...	...	T.974	...	...	Gear, layshaft 2nd
			1	...	...	T.975	...	...	Gear, speedometer driven

PART No.

DESCRIPTION AND CONTENTS

Gear, Close Ratio (to convert from Standard ratio)

CP.95	...	...	1	...	...	T.1177	...	...	Mainshaft and low gear
			1	...	...	T.1383	...	...	Gear, mainshaft high
			1	...	...	T.1179	...	...	Gear, mainshaft 3rd
			1	...	...	T.955	...	...	Gear, mainshaft 2nd
			1	...	...	T.959	...	...	Layshaft and high gear
			1	...	...	T.964	...	...	Gear, layshaft 3rd
			1	...	...	T.963	...	...	Gear, layshaft 2nd
			1	...	...	T.961	...	...	Gear, layshaft low
			1	...	...	T.983	...	...	Plug, speedometer drive sealing
			1	...	...	T.948	...	...	Washer, speedometer drive plug

Kickstarter Ratchet Gear

CP.27	...	...	1	...	...	T.730	...	...	Pinion, kickstarter
			1	...	...	T.731	...	...	Ratchet, kickstart
			1	...	...	T.1250	...	...	Spring, ratchet
			1	...	...	T.1338	...	...	Sleeve
			1	...	...	T.732	...	...	Lockwasher

Pistons 500 c.c. Models

CP.109	...	...	1	...	...	E.3052	...	...	Piston, CR. 5 : 1
			1	...	...	E.656	...	...	Ring, first compression
			1	...	...	E.3048	...	...	Ring, second compression (Taper)
			1	...	...	GE.29	...	...	Ring, scraper
			1	...	...	WE.203E	...	...	Pin, gudgeon
			2	...	...	WE.479	...	...	Circlip
CP.109/20	...	...	1	...	...	E.3052/20	...	...	Piston, +.020", CR. 5 : 1
			1	...	...	E.656/20	...	...	Ring, first compression
			1	...	...	E.3048/20	...	...	Ring, second compression (Taper)
			1	...	...	GE.29/20	...	...	Ring, scraper
			1	...	...	WE.203E...	...	...	Pin, gudgeon
			2	...	...	WE.479	...	...	Circlip
CP.37	...	...	1	...	...	E.1969	...	...	Piston, CR. 6 : 1
			1	...	...	E.656	...	...	Ring, first compression
			1	...	...	E.3048	...	...	Ring, second compression (Taper)
			1	...	...	GE.29	...	...	Ring, scraper
			1	...	...	WE.203E...	...	...	Pin, gudgeon
			2	...	...	WE.479	...	...	Circlip
CP.37/10	...	...	1	...	...	E.1969/10	...	...	Piston, +.010", CR. 6 : 1
			1	...	...	E.656/10	...	...	Ring, first compression
			1	...	...	E.3048/10	...	...	Ring, second compression (Taper)
			1	...	...	GE.29/10...	...	...	Ring, scraper
			1	...	...	WE.203E...	...	...	Pin, gudgeon
			2	...	...	WE.479	...	...	Circlip

GROUP I – CARTON PACK

PART No.				DESCRIPTION AND CONTENTS		
CP.37/20	...	1	...	E.1969/20	...	Piston, +.020", CR. 6 : 1
		1	...	E.656/20 ...	...	Ring, first compression
		1	...	E.3048/20	...	Ring, second compression (Taper)
		1	...	GE.29/20	...	Ring, scraper
		1	...	WE.203E	...	Pin, gudgeon
		2	...	WE.479 ...	...	Circlip
CP.29 ...	...	1	...	E.1563 ...	...	Piston, CR. 7 : 1
		1	...	E.656 ...	...	Ring, first compression
		1	...	E.3048 ...	...	Ring, second compression (Taper)
		1	...	GE.29 ...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479 ...	...	Circlip
CP.29/10	...	1	...	E.1563/10	...	Piston, +.010", CR. 7 : 1
		1	...	E.656/10 ...	...	Ring, first compression
		1	...	E.3048/10	...	Ring, second compression (Taper)
		1	...	GE.29/10...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip
CP.29/20	...	1	...	E.1563/20	...	Piston, +.020", CR. 7 : 1
		1	...	E.656/20 ...	...	Ring, first compression
		1	...	E.3048/20	...	Ring, second compression (Taper)
		1	...	GE.29/20...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479 ...	...	Circlip
CP.29/30	...	1	...	E.1563/30	...	Piston, +.030", CR. 7 : 1
		1	...	E.656/30 ...	...	Ring, first compression
		1	...	E.3048/30	...	Ring, second compression (Taper)
		1	...	GE.29/30...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479 ...	...	Circlip
CP.29/40	...	1	...	E.1563/40	...	Piston, +.040", CR. 7 : 1
		1	...	E.656/40 ...	...	Ring, first compression
		1	...	E.3048/40	...	Ring, second compression (Taper)
		1	...	GE.29/40...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479 ...	...	Circlip

CARTON PACK – GROUP I

PART No.		DESCRIPTION AND CONTENTS				
CP.131	...	1	...	...	E.1908	Piston, CR. 7.6 : 1
		1	...	...	E.656	Ring, first compression
		1	...	...	E.3048	Ring, second compression (Taper)
		1	...	...	GE.29	Ring, scraper
		1	...	...	WE.203E...	Pin, gudgeon
		2	...	...	WE.479	Circlip
CP.131/10	...	1	...	...	E.1908/10	Piston, +.010", CR. 7.6 : 1
		1	...	...	E.656/10	Ring, first compression
		1	...	...	E.3048/10	Ring, second compression (Taper)
		1	...	...	GE.29/10...	Ring, scraper
		1	...	...	WE.203E...	Pin, gudgeon
		1	...	...	WE.479	Circlip
CP.131/20	...	1	...	...	E.1908/20	Piston, +.020" CR. 7.6 : 1
		1	...	...	E.656/20	Ring, first compression
		1	...	...	E.3048/20	Ring, second compression (Taper)
		1	...	...	GE.29/20...	Ring, scraper
		1	...	...	WE.203E...	Pin, gudgeon
		1	...	...	WE.479	Circlip
CP.135	...	1	...	...	E.3098	Piston, CR. 8 : 1
		1	...	...	E.656	Ring, first compression
		1	...	...	E.3048	Ring, second compression (Taper)
		1	...	...	GE.29	Ring, scraper
		1	...	...	WE.203E...	Pin, gudgeon
		2	...	...	WE.479	Circlip
CP.135/10	...	1	...	...	E.3098/10	Piston, +.010" CR. 8 : 1
		1	...	...	E.656/10	Ring, first compression
		1	...	...	E.3048/10	Ring, second compression (Taper)
		1	...	...	GE.29/10...	Ring, scraper
		1	...	...	WE.203E...	Pin, gudgeon
		2	...	...	WE.479	Circlip
CP.135/20	...	1	...	...	E.3098/20	Piston, +.020", CR. 8 : 1
		1	...	...	E.656/20	Ring, first compression
		1	...	...	E.3048/20	Ring, second compression (Taper)
		1	...	...	GE.29/20...	Ring, scraper
		1	...	...	WE.203E...	Pin, gudgeon
		2	...	...	WE.479	Circlip

GROUP I – CARTON PACK

PART No.		DESCRIPTION AND CONTENTS				
CP.133	...	1	...	E.2489	...	Piston, CR. 8.5 : 1
		1	...	E.656	...	Ring, first compression
		1	...	E.3048	...	Ring, second compression (Taper)
		1	...	GE.29	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip
CP.133/10	...	1	...	E.2489/10	...	Piston, +.010", CR. 8.5 : 1
		1	...	E.656/10	...	Ring, first compression
		1	...	E.3048/10	...	Ring, second compression (Taper)
		1	...	GE.29/10...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip
CP.133/20	...	1	...	E.2489/20	...	Piston, +.020" CR. 8.5 : 1
		1	...	E.656/20	...	Ring, first compression
		1	...	E.3048/20	...	Ring, second compression (Taper)
		1	...	GE.29/20...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip
CP.161	...	1	...	E.3615	...	Piston, CR. 9 : 1
		1	...	E.656	...	Ring, first compression
		1	...	E.3048	...	Ring, second compression (Taper)
		1	...	GE.29	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip
CP.161/20	...	1	...	E.3615/20	...	Piston, +.020", CR.9 : 1
		1	...	E.656/20	...	Ring, first compression
		1	...	E.3048/20	...	Ring, second compression (Taper)
		1	...	GE.29/20...	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip
CP.134	...	1	...	E.2884	...	Piston, CR. 9.5 : 1
		1	...	E.656	...	Ring, first compression
		1	...	E.3048	...	Ring, second compression (Taper)
		1	...	GE.29	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip
CP.132	...	1	...	E.2671	...	Piston CR. 12 : 1
		1	...	E.656	...	Ring, first compression
		1	...	E.3048	...	Ring, second compression (Taper)
		1	...	GE.29	...	Ring, scraper
		1	...	WE.203E...	...	Pin, gudgeon
		2	...	WE.479	...	Circlip

PART No.
DESCRIPTION AND CONTENTS
Pistons, 650 c.c. Models

CP.158	...	1	...	...	E.3611	...	Piston CR. 6.3 : 1
		1	...	...	E.2897	...	Ring, first compression
		1	...	...	E.3049	...	Ring, second compression (Taper)
		1	...	...	E.2898	...	Ring, scraper
		1	...	...	WE.203E	...	Pin, gudgeon
		2	...	...	WE.479	...	Circlip
CP.98 (6T only)		1	...	...	E.2891	...	Piston, CR. 7 : 1
		1	...	...	E.2897	...	Ring, first compression
		1	...	...	E.3049	...	Ring, second compression (Taper)
		1	...	...	E.2898	...	Ring, scraper
		1	...	...	WE.203E...	...	Pin, gudgeon
		2	...	...	WE.479	...	Circlip
CP.98/10 (6T only)		1	...	...	E.2891/10	...	Piston, +.010" CR. 7 : 1
		1	...	...	E.2897/10	...	Ring, first compression
		1	...	...	E.3049/10	...	Ring, second compression (Taper)
		1	...	...	E.2898/10	...	Ring, scraper
		1	...	...	WE.203E	...	Pin, gudgeon
		2	...	...	WE.479	...	Circlip
CP.98/20 (6T only)		1	...	...	E.2891/20	...	Piston, +.020" CR. 7 : 1
		1	...	...	E.2897/20	...	Ring, first compression
		1	...	...	E.3049/20	...	Ring, second compression (Taper)
		1	...	...	E.2898/20	...	Ring, scraper
		1	...	...	WE.203E...	...	Pin, gudgeon
		2	...	...	WE.479	...	Circlip
CP.159	...	1	...	...	E.3612	...	Piston, CR. 7.5 : 1
		1	...	...	E.2897	...	Ring, first compression
		1	...	...	E.3049	...	Ring, second compression (Taper)
		1	...	...	E.2898	...	Ring, scraper
		1	...	...	WE.203E	...	Pin, gudgeon
		2	...	...	WE.479	...	Circlip
CP.159/10	...	1	...	...	E.3612/10	...	Piston, +.010", CR. 7.5 : 1
		1	...	...	E.2897/10	...	Ring, first compression
		1	...	...	E.3049/10	...	Ring, second compression (Taper)
		1	...	...	E.2898/10	...	Ring, scraper
		1	...	...	WE.203E...	...	Pin, gudgeon
		2	...	...	WE.479	...	Circlip
CP.159/20	...	1	...	...	E.3612/20	...	Piston, +.020", CR. 7.5 : 1
		1	...	...	E.2897/20	...	Ring, first compression
		1	...	...	E.3049/20	...	Ring, second compression (Taper)
		1	...	...	E.2898/20	...	Ring, scraper
		1	...	...	WE.203E...	...	Pin, gudgeon
		2	...	...	WE.479	...	Circlip

GROUP I - CARTON PACK

PART No.

DESCRIPTION AND CONTENTS

CP.163	...	1	...	...	E.3670	...	...	Piston, CR. 8 : 1
		1	...	...	E.2897	...	...	Ring, first compression
		1	...	...	E.3049	...	...	Ring, second compression (Taper)
		1	...	...	E.2898	...	...	Ring, scraper
		1	...	...	WE.203E...	...	...	Pin, gudgeon
		2	...	...	WE.479	...	...	Circlip
CP.163/10	...	1	...	...	E.3670/10	...	...	Piston, +.010", CR. 8 : 1
		1	...	...	E.2897/10	...	...	Ring, first compression
		1	...	...	E.3049/10	...	...	Ring, second compression (Taper)
		1	...	...	E.2898/10	...	...	Ring, scraper
		1	...	...	WE.203E...	...	...	Pin, gudgeon
		2	...	...	WE.479	...	...	Circlip
CP.163/20	...	1	...	...	E.3670/20	...	...	Piston, +.020", CR. 8 : 1
		1	...	...	E.2897/20	...	...	Ring, first compression
		1	...	...	E.3049/20	...	...	Ring, second compression (Taper)
		1	...	...	E.2898/20	...	...	Ring, scraper
		1	...	...	WE.203E...	...	...	Pin, gudgeon
		2	...	...	WE.479	...	...	Circlip
CP.157	...	1	...	...	E.3610	...	...	Piston, CR. 8.5 : 1
		1	...	...	E.2897	...	...	Ring, first compression (Taper)
		1	...	...	E.3049	...	...	Ring, second compression
		1	...	...	E.2898	...	...	Ring, scraper
		1	...	...	WE.203E...	...	...	Pin, gudgeon
		2	...	...	WE.479	...	...	Circlip
CP.157/10	...	1	...	...	E.3610/10	...	...	Piston, +.010" CR. 8.5 : 1
		1	...	...	E.2897/10	...	...	Ring, first compression (Taper)
		1	...	...	E.3049/10	...	...	Ring, second compression
		1	...	...	E.2898/10	...	...	Ring, scraper
		1	...	...	WE.203E...	...	...	Pin, gudgeon
		2	...	...	WE.479	...	...	Circlip
CP.157/20	...	1	...	...	E.3610/20	...	...	Piston, +.020", CR. 8.5 : 1
		1	...	...	E.2897/20	...	...	Ring, first compression (Taper)
		1	...	...	E.3049/20	...	...	Ring, second compression
		1	...	...	E.2898/20	...	...	Ring, scraper
		1	...	...	WE.203E...	...	...	Pin, gudgeon
		2	...	...	WE.479	...	...	Circlip
CP.160	...	1	...	...	E.3613	...	...	Piston, CR. 12 : 1
		1	...	...	E.2897	...	...	Ring, first compression (Taper)
		1	...	...	E.3049	...	...	Ring, second compression
		1	...	...	E.2898	...	...	Ring, scraper
		1	...	...	WE.203E...	...	...	Pin, gudgeon
		2	...	...	WE.479	...	...	Circlip

PART No.

DESCRIPTION AND CONTENTS

Piston Rings 500 c.c. Models

CP.40 ...	...	2	...	...	E.656	...	...	Ring, first compression
		2	...	...	E.3048	...	...	Ring, second compression (Taper)
		2	...	...	GE.29	...	...	Ring, scraper
CP.40/10	...	2	...	...	E.656/10	...	...	Ring, first compression
		2	...	...	E.3048/10	...	...	Ring, second compression (Taper)
		2	...	...	GE.29/10...	...	...	Ring, scraper
CP.40/20	...	2	...	...	E.656/20	...	...	Ring, first compression
		2	...	...	E.3048/20	...	...	Ring, second compression (Taper)
		2	...	...	GE.29/20...	...	...	Ring, scraper
CP.40/40	...	2	...	...	E.656/40	...	...	Ring, first compression
		2	...	...	E.3048/40	...	...	Ring, second compression (Taper)
		2	...	...	GE.29/40...	...	...	Ring, scraper

Piston Rings 650 c.c. Models

CP.99 ...	...	2	...	...	E.2897	...	...	Ring, first compression
		2	...	...	E.3049	...	...	Ring, second compression (Taper)
		2	...	...	E.2898	...	...	Ring, scraper
CP.99/10	...	2	...	...	E.2897/10	...	...	Ring, first compression
		2	...	...	E.3049/10	...	...	Ring, second compression (Taper)
		2	...	...	E.2898/10	...	...	Ring, scraper
CP.99/20	...	2	...	...	E.2897/20	...	...	Ring, first compression
		2	...	...	E.3049/20	...	...	Ring, second compression (Taper)
		2	...	...	E.2898/20	...	...	Ring, scraper

Valves

CP.96 (6T)	...	2	...	...	E.2903	...	...	Valve, inlet
		2	...	...	E.2904	...	...	Valve, exhaust
CP.103 (T100)		2	...	...	E.2969	...	...	Valve, inlet
		2	...	...	E.1956	...	...	Valve, exhaust
CP.173 (T110, TR6)		2	...	...	E.3310	...	...	Valve, inlet
		2	...	...	E.3927	...	...	Valve, exhaust

GROUP I – CARTON PACK

PART No.

DESCRIPTION AND CONTENTS

Valve Guides

CP.97	...	...	2	...	...	E.2899	...	...	Guide, inlet
			2	...	...	E.2900	...	...	Guide, exhaust

Valve Springs

CP.5	...	...	4	...	...	E.1488	...	...	Spring, inner
			4	...	...	E.1487	...	...	Spring, outer
CP.102		...	4	...	...	E.3001	...	...	Spring, inner (racing)
			4	...	...	E.3002	...	...	Spring, outer (racing)

Steering Races

CP.156	...	1	...	...	H.1018	...	...	Cone and dust cover, top
		1	...	...	H.439	...	...	Cone
		2	...	...	H.111	...	...	Cups
		40	...	...	S70-3	...	...	Balls

Sidecar Machine Jack

CP.153	...	1	...	...	F.4028	...	...	Bracket
		1	...	...	F.2605	...	...	Bolt
		1	...	...	F.4029	...	...	Jack

Tachometer Drive Kit (for TR.6)

CP.162	...	1	...	...	E.3677	...	...	Timing gear cover
		1	...	...	E.3678	...	...	Grub Screw
		1	...	...	E.3679	...	...	Bearing housing assembly, driving
		1	...	...	E.3682	...	...	Bearing housing assembly, driven
		1	...	...	E.3685	...	...	L.H. nut
		1	...	...	E.3686	...	...	Driving Gear
		1	...	...	H.1083	...	...	Mounting bracket
		1	...	...	RC.109	...	...	Tachometer head
		1	...	...	52091/5	...	...	Tachometer drive cable
		1	...	...	E.2749	...	...	Driven gear
		2	...	...	H.1086	...	...	Bolt mounting bracket

REPLACEMENT PARTS

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

ENGINE—GROUP 2

CYLINDER BLOCK

1	E3332	Block, cylinder	1	—	1	—	1
2	E3591	Block, cylinder	—	1	—	—	—
3	E3332/TR6	Block, cylinder	—	—	—	1	—
4	E2894	Washer, cylinder base	1	—	1	1	1
5	E2249	Washer, cylinder base	—	1	—	—	—

CYLINDER HEAD

6	E3873	Head, cylinder c/w guides	1	—	—	—	—
7	E3593	Head, cylinder c/w guides	—	1	—	—	—
8	E3924	Head, cylinder c/w guides	—	—	1	1	—
9	E4019	Head, c/w guides and adaptors	—	—	—	—	1
10	E3940	Adaptor, carb. to head	—	—	—	—	2
11	E3847	Locknut, carb. adaptor	—	—	—	—	2
12	E2961	Adaptor, exhaust pipe	—	2	—	—	—
13	E3583	Adaptor, exhaust pipe	—	—	2	2	2
14	E3614	Gasket, cylinder head	1	—	1	1	1
15	E3003	Gasket, cylinder head	—	1	—	—	—
16	E327	Bolt, cylinder head, short, $3\frac{3}{8}$ " U/H	4	—	4	4	4
17	E1484	Bolt, cylinder head, medium, $5\frac{3}{8}$ " U/H	2	—	2	2	2
18	E1596	Bolt, cylinder head (torque stay) $6\frac{25}{64}$ " U/H	2	—	2	2	2
19	E1596A	Bolt, cylinder head (torque stay) $5\frac{7}{8}$ " U/H	—	2	—	—	—
20	E2873	Bolt, cylinder head, short $3\frac{3}{4}$ " U/H	—	4	—	—	—
21	E2874	Bolt, cylinder head, medium $5\frac{15}{16}$ " U/H	—	2	—	—	—
22	GS308	Washer, cylinder head bolt	4	—	—	—	—
23	F2184	Washer, cylinder head bolt	—	8	8	8	8

INLET MANIFOLD

24	E3304	Manifold, inlet	1	—	1	1	—
25	E3307	Manifold, inlet	—	1	—	—	—
26	E3334	Washer, inlet manifold joint	2	—	2	2	—
27	E2967	Washer, inlet manifold joint	—	2	—	—	—

GROUP 2 — ENGINE




FIG. 1. INLET MANIFOLDS

INDEX

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	E3304	19	24	9	S25-13	21	5
2	E3307	19	25	10	E1553	21	6
3	E3334	19	26		E2962	21	7
4	E2967	19	27	11	E2962	21	7
5	E2920	21	1	12	SI-51	21	8
	E2973	21	3	13	S25-3	21	9
6	E2972	21	2	14	NA43A	94	20
7	E2973	21	3	15	E2968	94	21
8	W103	21	4				

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	E2920	Stud, inlet manifold to head, $1\frac{33}{32}$ " O/A ...	4	—	—	—	—
2	E2972	Stud, inlet manifold to head, long, $2\frac{3}{8}$ " O/A ...	—	2	—	—	—
3	E2973	Stud, inlet manifold to head, short, $1\frac{5}{16}$ " O/A ...	—	2	4	4	—
4	W103	Nut, inlet manifold to head ...	4	4	4	4	—
5	S25-13	Washer, inlet manifold to head ...	4	4	4	4	—
6	E1553	Stud, carburetter fixing, $1\frac{3}{32}$ " O/A ...	2	—	—	—	—
7	E2962	Stud, carburetter fixing, $1\frac{7}{32}$ " O/A ...	—	2	2	2	—
8	SI-51	Nut, carburetter fixing ...	2	2	2	2	—
9	S25-3	Washer, carburetter fixing ...	2	2	2	2	—

VALVES, GUIDES AND SPRINGS

10	E2903	Valve, inlet ...	2	—	—	—	—
11	E2969	Valve, inlet ...	—	2	—	—	—
12	E3310	Valve, inlet ...	—	—	2	2	2
13	E2904	Valve, exhaust ...	2	—	—	—	—
14	E1956	Valve, exhaust ...	—	2	—	—	—
15	E3927	Valve, exhaust ...	—	—	2	2	2
16	E2899	Guide, inlet valve ...	2	2	2	2	—
17	E2900	Guide, exhaust valve ...	2	2	2	2	—
18	E3827	Guide, inlet valve ...	—	—	—	—	2
19	E3828	Guide, exhaust valve ...	—	—	—	—	2
20	E1488	Spring, inner valve ...	2	2	2	2	—
21	E1487	Spring, outer valve ...	2	2	2	2	—
22	E3001	Spring, inner valve ...	—	—	—	—	4
23	E3002	Spring, outer valve ...	—	—	—	—	4
24	E1543	Collar, valve spring top ...	4	4	4	4	4
25	E1544	Cup, valve spring bottom ...	4	4	4	4	4
26	WE259A	Cotter, valve split ...	8	8	8	8	8

PISTONS

27	CP98	Piston complete, standard CR7 : I ...	2	—	—	—	—
28	CP98/10	Piston complete, + .010" CR7 : I ...	A	—	—	—	—
29	CP98/20	Piston complete, + .020" CR7 : I ...	A	—	—	—	—
30	CPI35	Piston complete, standard CR8 : I ...	—	2	—	—	—
31	CPI35/10	Piston complete, + .010" CR8 : I ...	—	A	—	—	—
32	CPI35/20	Piston complete, + .020" CR8 : I ...	—	A	—	—	—
33	CPI63	Piston complete, standard CR8 : I ...	—	—	2	2	—
34	CPI63/10	Piston complete, + .010" CR8 : I ...	—	—	A	A	—
35	CPI63/20	Piston complete, + .020" CR8 : I ...	—	—	A	A	—
36	CPI57	Piston complete, standard CR8-5 : I ...	—	—	—	—	2
37	CPI57/10	Piston complete, standard CR8-5 : I ...	—	—	—	—	A
38	CPI57/20	Piston complete, standard CR8-5 : I ...	—	—	—	—	A

GROUP 2 — ENGINE

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	E656	Ring, piston compression	—	2	—	—	—
2	E656/10	Ring, piston compression, +.010"	—	A	—	—	—
3	E656/20	Ring, piston compression, +.020"	—	A	—	—	—
4	E3048	Ring, piston compression, standard (Taper)	—	2	—	—	—
5	E3048/10	Ring, piston compression, +.010" (Taper)	—	A	—	—	—
6	E3048/20	Ring, piston compression, +.020" (Taper)	—	A	—	—	—
7	GE29	Ring, piston scraper, standard	—	2	—	—	—
8	GE29/10	Ring, piston scraper, +.010"	—	A	—	—	—
9	GE29/20	Ring, piston scraper, +.020"	—	A	—	—	—
10	E3049	Ring, piston compression, standard (Taper)	4	—	4	4	4
11	E3049/10	Ring, piston compression, +.010" (Taper)	A	—	A	A	A
12	E3049/20	Ring, piston compression, +.020" (Taper)	A	—	A	A	A
13	E2898	Ring, piston scraper, standard	2	—	2	2	2
14	E2898/10	Ring, piston scraper, +.010"	A	—	A	A	A
15	E3898/20	Ring, piston scraper, +.020"	A	—	A	A	A
16	WE203E	Pin, gudgeon	2	2	2	2	2
17	WE479	Circlip, gudgeon pin	4	4	4	4	4

Piston assemblies (Alternative Compression Ratios) and piston ring sets are available in carton packs, see pages 11 to 16.

CRANKSHAFT AND FLYWHEEL ASSEMBLY

18	E3893	Crankshaft and flywheel assembly	1	—	1	1	1
19	E3890	Crankshaft and flywheel assembly	—	1	—	—	—
20	E3894	Crankshaft c/w oil tube	1	—	1	1	1
21	E3891	Crankshaft c/w oil tube	—	1	—	—	—
22	E3903	Oil tube, crankshaft	1	1	1	1	1
23	E3905	Plug, crankshaft right side	1	1	1	1	1
24	E3906	Flywheel	1	1	1	1	1
25	E3907	Bolt, flywheel to crankshaft	3	3	3	3	3
26	E2288	Washer, serrated	3	3	3	3	3
27	E3114	Stud, crankshaft left side, $1\frac{3}{16}$ " O/A	1	1	1	1	1

REF. No. PART No. DESCRIPTION 6T T100 T110 TR6 T120

CONNECTING RODS

1	E3606	Connecting rod, complete	...	...	...	2	2	2	2	2
2	E3586	Bearing, connecting rod big end	...	...	...	4	4	4	4	4
3	E1511	Bush, connecting rod small end	...	...	...	2	2	2	2	2
4	E2490A	Bolt, connecting rod to cap, $2\frac{25}{64}$ " U/H	...	...	...	4	4	4	4	4
5	E2922	Nut, connecting rod to cap bolt	...	...	...	4	4	4	4	4

Note.—Connecting rod assembly does not include E3586 big end bearings. These bearings are also available in 0.010" and 0.020" undersizes.

CRANKCASE

6	E2892/3314	Crankcase assembly, less main bearings	...	...	...	1	—	—	—	—
7	E2220A/3281	Crankcase assembly, less main bearings	...	...	...	—	1	—	—	—
8	E2892/3282	Crankcase assembly, less main bearings	...	...	...	—	—	1	1	1
9	E672	Stud, crankcase cylinder base, $1\frac{5}{8}$ " O/A	...	...	...	6	6	6	6	6
10	E3523	Stud, crankcase cylinder base (Dowel), $1\frac{5}{8}$ " O/A	...	...	...	2	2	2	2	2
11	W76	Nut, crankcase cylinder base stud	...	...	...	4	—	4	4	4
12	PO172A	Nut, crankcase cylinder base stud	...	...	...	4	—	4	4	4
13	E2412	Nut, crankcase cylinder base stud	...	...	...	—	8	—	—	—
14	GS308	Washer, crankcase cylinder base stud	...	...	...	—	8	—	—	—
15	E1534A	Dowel, crankcase cylinder base stud (E3523)	...	...	...	2	2	2	2	2
16	E1579	Dowel, crankcase halves	...	...	...	1	1	1	1	1
17	E1534A	Dowel, crankcase halves hollow	...	...	...	1	1	1	1	1
18	E2022	Stud, magneto/distributor to crankcase, $1\frac{5}{16}$ " O/A	...	...	...	3	3	3	3	3
19	F1008	Nut, magneto to crankcase stud	...	...	...	—	3	3	3	3
20	S25-3	Washer, magneto to crankcase stud	...	...	...	—	3	3	3	3
21	S1-51	Nut, distributor to crankcase stud	...	...	...	3	—	—	—	—
22	E1539	Stud, oil junction block, $1\frac{7}{32}$ " O/A	...	...	...	1	1	1	1	1
23	S1-51	Nut, oil junction block stud	...	...	...	1	1	1	1	1
24	S23-3	Washer, oil junction block stud	...	...	...	1	1	1	1	1
25	E1532	Dowel, oil junction block	...	...	...	1	1	1	1	1
26	E1535	Dowel, crankcase to timing cover	...	...	...	1	1	1	1	1

THUNDERBIRD (6T ENGINE)

GROUP 2 — ENGINE




FIG. 3. CRANKSHAFT, CONNECTING RODS, PISTON, TIMING GEAR, etc.




FIG. 2. CRANKCASE, CYLINDER BLOCK, CYLINDER HEAD, etc.

INDEX FIG. 2

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	E3332	19	1	31	E487	32	8	63	E1496	34	15
2	E2894	19	4	32	E486	32	9	64	E3547	34	16
3	E3873	19	6	33	E1540	32	10	65	E1461T	34	17
4	E3614	19	14	34	F879	32	12	66	E1462T	34	19
5	E327	19	16	35	GS35	32	27	67	E1650	34	21
6	E1484	19	17	36	GS153	32	28	68	E1540	34	23
7	E1596	19	18	37	E1476	32	29	69	F879	34	25
8	E2920	21	1	38	E495	32	30	70	E1564	34	27
9	E2903	21	10	39	S70-7	32	31	71	E1577	34	28
10	E2904	21	11	40	E403	32	32	72	E1545	34	29
11	E2899	21	16	41	E2360	32	33	73	E1457	34	32
12	E2900	21	17	42	E1537	32	34	74	E1458	34	33
13	E1488	21	20	43	E2794	33	2	75	E1483	34	34
14	E1543	21	24	44	GS251	33	3	76	E1513	34	35
15	E1544	21	25	45	E2790	33	4	77	E470	34	36
16	WE259A	21	26	46	E1670	33	5	78	E1330	35	1
17	E2892/3314	23	6	47	GS254	33	6	79	E1575	35	2
18	E672	23	9	48	E2788	33	7	80	E1574	35	3
19	E3523	23	10	49	E2791	33	8	81	E1512	35	4
20	W76	23	11	50	E2793	33	9	82	E3253	35	5
21	PO1172A	23	12	51	E2789	33	10	83	E1435	35	6
22	E1534A	23	15	52	E2792	33	11	84	GS272	35	10
23	E2022	23	18	53	E3310/6T	33	12	85	GS273	35	11
24	SI-51	23	21	54	E2615	33	25	86	E1601	35	12
25	E1539	23	22	55	E3437	33	27	87	E1335	35	14
26	SI-51	23	23	56	E3439	33	28	88	E984	35	15
27	E1532	23	25	57	E375	33	41	89	F1880	35	16
28	E1535	23	26	58	E3059	34	6	90	SI-52	50	19
29	E1536	32	1	59	E1477	34	7	91	E3355	74	26
30	F879	32	2	60	H200	34	9	92	E1529	74	27
	E529	32	7	61	E1693	34	11	93	E3354	74	25
				62	E1505	34	13	94	E3353	74	24

INDEX FIG. 3

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	CP98	21	27	18	E3300	32	19	33	E3125	33	43
2	E3049	22	10	19	E1479	32	15	34	E3126	33	44
3	E3049	22	10	20	E1516	32	16	35	146460	33	45
4	E2898	22	13	21	E2200	32	17	36	E2254	34	1
5	WE203E	22	16	22	E1472	33	29	37	GS87	34	2
6	WE479	22	17	23	E1580	33	30	38	E2256	34	3
7	E3906	22	24	24	E398	33	31	39	E3108/24	35	17
8	E3894	22	20	25	E3275	33	32	40	E3974	35	20
9	E3907	22	25	26	E1486A	33	35	41	E3977	104	12
10	E3606	23	1	27	E1558	33	36	42	E3116	104	9
11	E1511	23	3	28	E1492	33	37	43	423506	104	1
12	E2490A	23	4	29	E1463	33	38	44	E3975	104	11
13	E2922	23	5	30	E1471	33	39	45	H1168	32	14
14	E3586	23	2	31	E400	33	40				
15	E1591	32	13	32	E3123	33	42				

TIGER 100 (T100) ENGINE




FIG. 4. CRANKCASE, CYLINDER BLOCK, CYLINDER HEAD, etc.

GROUP 2 - ENGINE




FIG. 5. CRANKSHAFT, CONNECTING RODS, PISTONS, TIMING GEARS, etc.

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	E3591	19	2	32	E1540	32	10	65	E1462T	34	19
2	E2249	19	5	33	F879	32	12	66	E1650	34	21
3	E3593	19	7	34	GS35	32	27	67	E2980	34	24
4	E2961	19	12	35	GS153	32	28	68	F879	34	25
5	E3003	19	15	36	E1476	32	29	69	E1564	34	27
6	E1596A	19	19	37	E495	32	30	70	E1577	34	28
7	E2873	19	20	38	S70-7	32	31	71	E2982	34	30
8	E2874	19	21	39	E403	32	32	72	E1457	34	32
9	E2969	21	11	40	E2360	32	33	73	E1458	34	33
10	E1956	21	14	41	E1537	32	34	74	E1483	34	34
11	E2899	21	16	42	E2794	33	2	75	E1513	34	35
12	E2900	21	17	43	GS251	33	3	76	E470	34	36
13	E1488	21	20	44	E2790	33	4	77	E1330	35	1
14	E1487	21	21	45	E1670	33	5	78	E1575	35	2
15	E1543	21	24	46	GS254	33	6	79	E1574	36	3
16	E1544	21	25	47	E2788	33	7	80	E1512	35	4
17	WE259A	21	26	48	E2791	33	8	81	E3253	35	5
18	E2220A/3281	23	7	49	E2793	33	9	82	E1435	35	6
19	E672	23	9	50	E2789	33	10	83	GS272	35	10
20	E3523	23	10	51	E2792	33	11	84	GS273	35	11
21	E2412	23	13	52	E2218/T100	33	13	85	E2767	35	13
22	E1534A	23	15	53	E2615	33	25	86	E1335	35	14
23	E2022	23	18	54	E3437	33	27	87	E984	35	15
24	F1008	23	19	55	E3439	33	28	88	F1880	35	16
25	E1539	23	22	56	E375	33	41	89	SI-52	50	19
26	SI-51	23	23	57	E3059	34	6	90	E3355	74	26
27	E1532	23	25	58	GS36	34	8	91	E1529	74	27
28	E1535	23	26	59	H200	34	9	92	E3353	74	24
29	E1536	32	1	60	E2620	34	12	93	E2228	98	24
30	F879	32	2	61	E1505	34	13	94	E3354	74	25
31	E529	32	7	62	E1496	34	15				
	E487	32	8	63	E3547	34	16				
	E486	32	9	64	E1461T	34	17				

INDEX FIG. 5

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	CPI35	21	30	15	E1591	32	13	30	E1471	33	39
2	E656	22	1	18	E3300	32	19	31	E400	33	40
3	E3048	22	4	19	E1479	32	15	32	E2741	101	15
4	GE29	22	7	20	E1516	32	16	33	170104	101	16
5	WE203E	22	16	21	E2260	32	17	34	E2254	34	1
6	WE479	22	17	22	E1472	32	29	35	GS87	34	2
7	E3906	22	24	23	E1580	32	30	36	E2256	34	3
8	E3891	22	21	24	E398	32	31	37	E3108/22	35	18
9	E3907	22	25	25	E3275	33	32	38	E3974	35	20
10	E3606	23	1	26	E3325	33	33	39	E3120	35	23
11	E1511	23	3	27	E1486A	33	35	40	E3976	35	21
12	E2490A	23	4	28	E1558	33	36	41	E3119	35	22
13	E2922	23	5	29	E1492	33	37	42	E2451	96	21
14	E3586	23	2		E1463	33	38	43	111704	96	22
								44	H1168	32	14

TROPHY (TR6) AND TIGER I10 (T110) ENGINE

GROUP 2 - ENGINE




FIG. 6. CRANKCASE, CYLINDER BLOCK, CYLINDER HEAD, etc.

FIG. 7. CRANKSHAFT, CONNECTING RODS, PISTONS, TIMING GEARS, etc.

INDEX FIG. 6


Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	E3332	19	1	31	E487	32	8	62	E3646	34	14
2	E3332/TR6	19	3	32	E486	32	9	63	E1496	34	15
3	E2894	19	4	33	E1540	32	10	64	E3547	34	16
4	E3924	19	8	34	F879	32	12	65	E3550	34	18
5	E3614	19	14	35	GS35	32	27	66	E3551	34	20
6	E327	19	16	36	GS153	32	28	67	E3552	34	22
7	E1484	19	17	37	E1476	32	29	68	E2980	34	24
8	E1596	19	18	38	E495	32	30	69	F879	34	25
9	E2973	21	1	39	S70-7	32	31	70	E1564	34	27
10	E3310	21	12	40	E403	32	32	71	E1577	34	28
11	E3927	21	15	41	E2360	32	33	72	E1545	34	29
12	E2899	21	16	42	E1537	32	34	73	E1457	34	32
13	E2900	21	17	43	E2794	32	2	74	E1458	34	33
14	E1488	21	20	44	GS251	33	3	75	E1483	34	34
15	E1487	21	21	45	E2790	33	4	76	E1513	34	35
16	E1543	21	24	46	E1670	33	5	77	E470	34	36
17	E1544	21	25	47	GS254	33	6	78	E1330	35	1
18	WE259A	21	26	48	E2788	33	7	79	E1575	35	2
19	E2892/3282	23	8	49	E2791	33	8	80	E1574	35	3
20	E672	23	9	50	E2793	33	9	81	E1512	35	4
21	E3253	23	10	51	E2789	33	10	82	E3253	35	5
22	W76	23	11	52	E2792	33	11	83	E1435	35	6
23	PO172A	23	12	53	E2218/T110	33	14	84	E3583	19	12
24	E1534A	23	15	54	E2218/Trophy	33	15	90	SI-52	50	19
25	E2022	23	18	55	E2615	33	25	91	E3335	74	26
26	F1008	23	19	56	E3437	33	27	92	E1529	74	27
27	E1539	23	22	57	E3439	33	28	93	E3353	74	24
28	SI-51	23	23	58	E375	33	41	94	E2228	96	24
29	E1532	23	25	59	E3059	34	6	95	E3354	74	25
30	E1535	23	26	60	E1477	34	7				
	E1536	32	1	61	H200	34	9				
	F879	32	2		E2620	34	12				
	E529	32	7								

INDEX FIG. 7

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	CP163	21	33	15	E1591	32	13	31	E400	33	40
2	E3049	22	10	18	E3300	32	19	32	E2741	101	15
3	E3049	22	10	19	E1479	32	15	33	I70104	101	16
4	E2898	22	13	20	E1516	32	16	34	E2254	34	1
5	WE203E	22	16	21	E2260	32	17	35	GS87	34	2
6	WE479	22	17	22	E1472	33	29	36	E2256	34	3
7	E3906	22	24	23	E1580	33	30	37	E3108/24	35	17
8	E3894	22	20	24	E398	33	31	38	E3974	35	20
9	E3907	22	25	25	E3325	33	33	39	E3120	35	23
10	E3606	23	1	26	E1486A	33	35	40	E3976	35	21
11	E1511	23	3	27	E1558	33	36	41	E3119	35	22
12	E2490A	23	4	28	E1492	33	37	42	E2451	96	21
13	E2922	23	5	29	E1463	33	38	43	I11704	96	22
14	E3586	23	2	30	E1471	33	39	44	H1168	32	14

BONNEVILLE 120

GROUP 2 — ENGINE



Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	E3332	19	1	32	E486	32	9	64	E3547	34	16
2	E2894	19	3	33	E1540	32	10	65	E3550	34	18
3	E4019	19	9	34	F879	32	12	66	E3551	34	20
4	E3614	19	14	35	GS35	32	27	67	E3552	34	22
5	E327	19	16	36	GS153	32	28	68	E2980	34	24
6	E1484	19	17	37	E1476	32	29	69	F879	34	25
7	E1596	19	18	38	E495	32	30	70	E1564	34	27
9	E3310	21	12	39	S70-7	32	31	71	E1577	34	28
	E3927	21	15	40	E403	32	32	72	E1545	34	29
10	E3827	21	18	41	E2360	32	33	73	E1457	34	32
	E3828	21	19	42	E1537	32	34	74	E1458	34	33
11	E3001	21	22	43	E2794	33	2	75	E1483	34	34
12	E3002	21	23	44	GS251	33	3	76	E1513	34	35
13	E1543	21	24	45	E2790	33	4	77	E470	34	36
14	E1544	21	25	46	E1670	33	5	78	E1330	35	1
15	WE259A	21	26	47	GS254	33	6	79	E1575	35	2
16	E2892/3282	23	8	48	E2788	33	7	80	E1574	35	3
17	E672	23	9	49	E2791	33	8	81	E1512	35	4
18	E3253	23	10	50	E2793	33	9	82	E3253	35	5
19	W76	23	11	51	E2789	33	10	83	E1435	35	6
20	PO172A	23	12	52	E2792	33	11	84	E3583	19	13
21	E1534A	23	15	53	E2218/T120	33	16	85	E3940	19	10
22	E2022	23	18	54	E2615	33	25	86	E3847	19	11
23	F1008	23	19	55	E3437	33	27	90	SI-52	50	19
24	E1539	23	22	56	E3439	33	28	91	E3335	74	26
25	SI-51	23	23	57	E375	33	41	92	E1529	74	27
26	E1532	23	25	58	E3059	34	6	93	E3353	74	24
27	E1535	23	26	59	E1477	34	7	94	E2228	96	24
28	E1536	32	1	60	H200	34	9	95	E3354	74	25
29	F879	32	2	61	E2620	34	12				
30	E529	32	7	62	E3646	34	14				
31	E487	32	8	63	E1496	34	15				

INDEX FIG. 9

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	CPI57	21	36	18	E3300	32	19	32	E2741	101	15
2	E3049	22	10	19	E1479	32	15	33	I70104	101	16
3	E3049	22	10	20	E1516	32	16	34	E2254	34	1
4	E2898	22	13	21	E2260	32	17	35	GS87	34	2
5	WE203E	22	16	22	E1472	33	29	36	E2256	34	3
6	WE479	22	17	23	E1580	33	30	37	E3108/24	35	17
7	E3906	22	24	24	E398	33	31	38	E3974	35	20
8	E3894	22	20	25	E3325	33	33	39	E3120	35	23
9	E3907	22	25	26	E3134	33	34	40	E3976	35	21
10	E3606	23	1	27	E1486A	33	35	41	E3119	35	22
11	E1511	23	3	28	E1558	33	36	42	E2451	96	21
12	E2490A	23	4	29	E1492	33	37	43	I11704	96	22
13	E2922	23	5	30	E1463	33	38	44	H1168	32	14
14	E3586	23	2	31	E1471	33	39				
15	E1591	32	13		E400	33	40				

GROUP 2 — ENGINE

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	E1536	Stud, oil pump fixing $1\frac{7}{16}$ " O/A	...	...	...	2	2
2	F879	Nut, oil pump fixing stud	...	...	...	2	2
3	E2312	Washer, oil pump fixing stud	...	...	...	2	2
4	E1508	Pipe, crankcase oil return	...	...	...	1	1
5	E1509	Clip, crankcase oil return pipe	...	...	...	1	1
6	E1645	Screw, crankcase oil return pipe $\frac{17}{64}$ " U/H	...	...	...	1	1

CRANKCASE OIL FILTER

7	E529	Filter, crankcase oil	...	...	...	1	1
8	E487	Washer, crankcase oil filter joint	...	...	...	2	2
9	E486	Cover, crankcase oil filter joint	...	...	...	1	1
10	E1540	Stud, crankcase oil filter joint $\frac{35}{64}$ " O/A	...	...	...	4	4
11	E1612	Washer, crankcase oil filter stud locking	...	...	...	4	4
12	F879	Nut, crankcase oil filter	...	...	...	4	4

CRANKCASE BEARINGS

13	E1591	Bearing, crankshaft (ball journal)	...	...	...	2	2
14	H1168	Oil Seal, L.H. Bearing	...	...	...	1	1
15	E1479	Bush, timing side camshaft	...	...	...	2	2
16	E1516	Bush, driving side camshaft (exhaust)...	...	...	...	1	1
17	E2260	Bush, driving side camshaft (breather)	...	...	...	1	1
18	E2311	Pin, timing side camshaft (breather)	...	...	...	1	1
19	E3300	Clamping Washer, T/S bearing	...	...	...	1	1

STUDS AND BOLTS FOR CRANKCASE HALVES

20	E1555	Bolt, crankcase top rear	...	...	...	1	1
21	S25-3	Washer, crankcase top rear bolt	...	...	...	1	1
22	T456	Stud, crankcase bottom front $3\frac{3}{4}$ " O/A	...	...	...	1	1
23	SI-51	Nut, crankcase bottom front stud	...	...	...	2	2
24	S25-3	Washer, crankcase bottom front stud	...	...	...	2	2
25	E1647	Screw, crankcase inside boss $\frac{3}{4}$ " U/H	...	...	...	2	2

FOR ENGINE PLATE STUDS SEE PAGE 52.

OIL PUMP

26	E3072	Pump, assembly, oil	...	...	...	1	1
27	GS35	Body, oil pump	...	...	...	1	1
28	GS153	Plunger, oil pump feed	...	...	...	1	1
29	E1476	Plunger, oil pump scavenge	...	...	...	1	1
30	E495	Block, oil pump slider	...	...	...	1	1
31	S70-7	Ball, oil pump valve	...	...	...	2	2
32	E403	Spring, oil pump valve	...	...	...	2	2
33	E2360	Plug, oil pump body	...	...	...	2	2
34	E1537	Washer, oil pump joint	...	...	...	1	1

ENGINE — GROUP 2

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
OIL RELEASE VALVE							
1	E2795	Valve, release and oil indicator					
2	E2794	Body, release valve					
3	GS251	Piston, release valve					
4	E2790	Cap, release valve					
5	E1670	Washer, release valve body					
6	GS254	Washer, release valve cap					
7	E2788	Spring, release valve main					
8	E2791	Shaft, indicator button					
9	E2793	Tube, indicator rubber					
10	E2789	Spring, indicator auxiliary					
11	E2792	Nut, indicator shaft					
TIMING COVER							
12	E3110/6T	Cover, timing gear		—	—	—	—
13	E2218/T100	Cover, timing gear	—		—	—	—
14	E2218/T110	Cover, timing gear	—	—		—	—
15	E2218/TROPHY	Cover, timing gear	—	—	—		—
16	E2218/T120	Cover, timing gear	—	—	—	—	
17	E2909	Patent plate		—	—	—	—
18	E1678	Patent plate	—		—	—	—
19	E2910	Patent plate	—	—		—	—
20	E2876	Patent plate	—	—	—		—
21	E4016	Patent plate	—	—	—	—	
22	D208-5	Rivet, patent plate	3	3	3	3	3
23	E378	Bush, timing gear cover					
24	E3585	Bush, timing gear cover (0-020" U.S.)	A	A	A	A	A
25	E2615	Plug, timing gear cover					
26	E1335	Washer, timing gear cover plug					
27	E3437	Screw, timing gear cover (short), $\frac{15}{16}$ " U/H	7	7	7	7	7
28	E3439	Screw, timing gear cover (long), $1\frac{3}{16}$ " U/H	3	3	3	3	3
TIMING GEARS AND CAMSHAFTS							
29	E1472	Pinion, timing					
30	E1580	Key, timing pinion					
31	E398	Nut, timing pinion					
32	E3275	Camshaft, inlet and exhaust	2	2	—	—	—
33	E3325	Camshaft, inlet and exhaust	—	A	2	2	
34	E3134	Camshaft, inlet	—	—	—	—	
35	E1486A	Wheel, inlet and exhaust camshaft	2	2	2	2	2
36	E1558	Key, camshaft wheel	2	2	2	2	2
37	E1492	Nut, camshaft wheel exhaust					
38	E1463	Nut, camshaft wheel inlet (pump drive)					
39	E1471	Wheel, intermediate gear					
40	E400	Bush, intermediate gear wheel					
41	E375	Spindle, intermediate gear wheel					
42	E3123	Pinion, distributor		—	—	—	—
43	E3125	Pin, distributor pinion		—	—	—	—
44	E3126	Circlip distributor pinion,		—	—	—	—
45	146460	Washer, distributor pinion (brass)		—	—	—	—

GROUP 2 — ENGINE

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
CRANKCASE BREATHER							
1	E2254	Valve, crankcase rotary	1	1	1	1	1
2	GS87	Disc, crankcase rotary valve	1	1	1	1	1
3	E2256	Spring, crankcase rotary valve	1	1	1	1	1
4	E2724	Pipe, crankcase breather	1	1	1	1	1
5	E3078	Extension, crankcase breather pipe (rubber) ...	1	1	1	1	1
TAPPETS AND TAPPET BLOCKS							
6	E3059	Tappet	4	4	4	4	4
7	E1477	Block, tappet guide	2	—	2	2	2
8	GS36	Block, tappet guide	—	2	—	—	—
9	H200	Screw, tappet guide block lock, $\frac{7}{16}$ " U/H ...	2	2	2	2	2
10	E2312	Washer, serrated	2	2	2	2	2
PUSH RODS							
11	E1693	Rod, push	4	—	—	—	—
12	E2620	Rod, push	—	4	4	4	4
PUSH ROD COVER TUBE							
13	E1505	Tube, push rod cover	2	—	—	—	—
14	E3646	Tube, push rod cover	—	2	2	2	2
15	E1496	Washer, push rod cover lower seal	2	2	2	2	2
16	E3547	Washer, push rod cover upper seal	2	2	2	2	2
OVERHEAD ROCKER GEAR							
17	E1461T	Box, inlet rocker	1	—	—	—	—
18	E3550	Box, inlet rocker	—	1	1	1	1
19	E1462T	Box, exhaust rocker	1	—	—	—	—
20	E3551	Box, exhaust rocker	—	1	1	1	1
21	E1650	Gasket, rocker box joint	4	—	—	—	—
22	E3552	Gasket, rocker box joint	—	2	2	2	2
23	E1540	Stud, rocker box to cylinder head, $\frac{9}{32}$ " O/A ...	4	—	—	—	—
24	E2980	Stud, rocker box to cylinder head, $\frac{15}{16}$ " O/A ...	—	4	6	6	6
25	F879	Nut, rocker box to cylinder head	4	4	6	6	6
26	E3302	Washer, rocker box to cylinder head nut ...	—	4	6	6	6
27	E1564	Cap, rocker box inspection	4	4	4	4	4
28	E1577	Washer, rocker box inspection cap	4	4	4	4	4
29	E1545	Bolt, rocker box to cylinder head, 2" U/H ...	4	—	4	4	4
30	E2982	Bolt, rocker box to cylinder head, 2 $\frac{5}{32}$ " U/H ...	—	4	—	—	—
31	S25-13	Washer, rocker box to cylinder head	4	4	4	4	4
32	E1457	Rocker, valve, R.H.	2	2	2	2	2
33	E1458	Rocker, valve, L.H.	2	2	2	2	2
34	E1483	Ball pin, valve rocker	4	4	4	4	4
35	E1513	Adjusting pin, valve rocker	4	4	4	4	4
36	E470	Locknut, adjusting pin	4	4	4	4	4

ENGINE — GROUP 2 GASKET SET — GROUP 3

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	E1300	Washer, valve rocker, thrust $\frac{3}{8}$ "	2	2	2	2	2
2	E1575	Washer, valve rocker, thrust $\frac{1}{2}$ "	6	6	6	6	6
3	E1574	Washer, valve rocker spring	4	4	4	4	4
4	E1512	Spindle, valve rocker	2	2	2	2	2
5	E3253	Sealing ring, rocker spindle (rubber)	2	2	2	2	2
6	E1435	Nut, valve rocker spindle (dome)	2	2	2	2	2
7	E1335	Washer, valve rocker spindle (copper)	4	4	4	4	4

ROCKER OIL FEED AND DRAIN PIPES

8	E3082	Pipe, rocker oil feed	1	1	1	1	1
9	E3383	Connection, feed pipe (rubber)	1	1	1	1	1
10	GS272	Pipe, rocker oil drain inlet	1	1	—	—	—
11	GS273	Pipe, rocker oil drain exhaust	1	1	—	—	—
12	E1601	Adaptor, drain pipe to cylinder head	4	—	—	—	—
13	E2767	Adaptor, drain pipe to cylinder head	—	4	—	—	—
14	E1335	Washer, drain pipe to cylinder head	8	8	—	—	—
15	E984	Adaptor, drain pipe to cover tube	2	2	—	—	—
16	F1880	Washer, drain pipe to cover tube	4	4	—	—	—

ENGINE SPROCKET

17	E3108/24	Sprocket, engine 24T solo	1	—	1	1	1
18	E3108/22	Sprocket, engine 22T solo	—	1	—	—	—
19	E3108/22	Sprocket, engine 22T sidecar	A	—	—	—	—
20	E3974	Key, crankshaft left side	1	1	1	1	1
21	E3976	Distance piece	—	1	1	1	1
22	E3119	Tab washer	—	1	1	1	1
23	E3120	Nut, engine sprocket	—	1	1	1	1

For 6T nut and tab washer see Page 104.
Engine sprockets are available in sizes from 17 to 25 teeth.

GASKET SET—GROUP 3

24	GS6T/56	Gasket set	1	—	—	—	—
25	GST100/56	Gasket set	—	1	—	—	—
26	GST110/56	Gasket set	—	—	1	1	1

GROUP 4 — GEARBOX

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
GEARBOX—GROUP 4							
1	T1525	Gearbox complete less clutch—standard ratio ...	1	1	1	—	—
2	T1528	Gearbox complete less clutch—standard ratio ...	—	—	—	1	—
3	T1583	Gearbox complete less clutch—standard ratio ...	—	—	—	—	1
4	T1526	Gearbox complete less clutch—close ratio ...	1	1	1	—	—
5	T1529	Gearbox complete less clutch—close ratio ...	—	—	—	1	—
6	T1584	Gearbox complete less clutch—close ratio ...	—	—	—	—	1
7	T1527	Gearbox complete less clutch—wide ratio ...	1	1	1	—	—
8	T1530	Gearbox complete less clutch—wide ratio ...	—	—	—	1	—
9	T1585	Gearbox complete less clutch—wide ratio ...	—	—	—	—	1
GEARBOX CASING							
10	T1201	Casing, with bushes, gearbox ...	1	1	1	1	1
11	T989	Dowel, casing to inner cover ...	2	2	2	2	2
12	E698	Stud, casing to outer cover, $2\frac{7}{8}$ " O/A ...	2	2	2	2	2
13	S1-51	Nut, casing stud ...	2	2	2	2	2
14	S25-3	Washer, casing stud ...	2	2	2	2	2
15	T1562	Cover with bushes, gearbox inner ...	1	1	1	1	1
16	T323A	Stud, inner cover to outer cover, $1\frac{15}{16}$ " O/A ...	1	1	1	1	1
17	S1-51	Nut, inner cover to outer cover stud ...	1	1	1	1	1
18	S25-3	Washer, inner cover to outer cover stud ...	1	1	1	1	1
19	E3436	Screw, inner cover to casing (long), $1\frac{1}{2}$ " U/H ...	1	1	1	1	1
20	E3437	Screw, inner cover to casing, $\frac{15}{16}$ " U/H ...	3	3	3	3	3
21	T45	Stop, kickstarter quadrant ...	1	1	1	1	1
22	E732	Plug, filler ...	1	1	1	1	1
23	NE507	Washer, filler plug ...	1	1	1	1	1
24	T1534	Cover, with bushes, gearbox outer ...	1	1	1	1	1
25	E3442	Screw, outer cover to casing (long), 3" U/H ...	1	1	1	1	1
26	E3438	Screw, outer cover to casing, $2\frac{9}{16}$ " U/H ...	1	1	1	1	1
27	E3437	Screw, outer cover to inner cover, $\frac{15}{16}$ " U/H ...	2	2	2	2	2
28	E3439	Screw, outer cover to inner cover (long), $1\frac{3}{16}$ " U/H ...	1	1	1	1	1
29	T1542	Cover, plate outer cover ...	1	1	1	1	1
30	T1541	Joint, washer, cover plate ...	1	1	1	1	1
31	E2312	Washer, cover screw ...	2	2	2	2	2
32	T1553	Screw, cover plate, $\frac{3}{8}$ " U/H ...	2	2	2	2	2
33	S46-15	Plug, gearbox drain and cover level ...	2	2	2	2	2
34	PT.104B	Washer, gearbox drain and cover level ...	2	2	2	2	2

REF. No. PART No. DESCRIPTION 6T T100 T110 TR6 T120

GEARBOX FITTINGS

1	F3769	Stud, gearbox clamp 4 $\frac{15}{16}$ " O/A	...	...	...	1	1	1	1	1
2	F3770	Washer, R.H. gearbox clamp stud	...	...	...	1	1	1	1	1
3	F3771	Nut, L.H. gearbox clamp stud	...	...	...	1	1	1	1	1
4	F3772	Nut, R.H. gearbox clamp stud	...	...	...	1	1	1	1	1
5	F3575	Bolt, gearbox pivot 7" U/H	...	...	...	1	1	1	1	1
6	DS47	Nut, gearbox pivot bolt	...	...	...	1	1	1	1	1
7	PCW73A	Washer, gearbox pivot bolt	...	...	...	1	1	1	1	1
8	F4422	Eyebolt, gearbox adjuster	...	...	...	1	1	1	1	1
9	GS203	Washer, eyebolt nut	...	...	...	2	2	2	2	2
10	SI-51	Nut, gearbox eyebolt	...	...	...	2	2	2	2	2
11	F3767	Pivot pin, gearbox adjuster	...	...	...	1	1	1	1	1
12	S26-1	Washer, pivot pin	...	...	...	1	1	1	1	1
13	PO172A	Nut, pivot pin	...	...	...	1	1	1	1	1

SHAFTS AND GEARS (STANDARD RATIO)

(See page 43 for wide and close ratio gears)

14	T914	Mainshaft and low gear (16T)	...	...	...	1	1	1	1	1
15	PT108B	Bush, mainshaft for clutch rod	...	...	...	1	1	1	1	1
16	S66-1	Woodruff key No. 6	...	...	...	1	1	1	1	1
17	T1047	Nut, clutch to mainshaft	...	...	...	1	1	1	1	1
18	T1045	Washer, clutch to mainshaft, plain	...	...	...	1	1	1	1	1
19	T1046	Washer, clutch to mainshaft, lock	...	...	...	1	1	1	1	1
20	T1382	Gear, mainshaft high (26T)	...	...	...	1	1	1	1	1
21	T1370	Bush, mainshaft high gear	...	...	...	1	1	1	1	1
22	T917	Gear, mainshaft 3rd (24T)	...	...	...	1	1	1	1	1
23	T916	Gear, mainshaft 2nd (20T)	...	...	...	1	1	1	1	1
24	T1063	Layshaft c/w high gear (20T) and speedometer gear	...	...	...	1	1	1	1	1
25	T930	Gear, layshaft 3rd (22T)	...	...	...	1	1	1	1	1
26	T1065	Gear, layshaft 2nd (26T)	...	...	...	1	1	1	1	1
27	T926	Gear, layshaft low (30T)	...	...	...	1	1	1	1	1
28	T928	Bush, layshaft low gear	...	...	...	1	1	1	1	1

For speedometer drive gears see page 108.

GEARBOX CASING BEARINGS

29	T448	Bearing, high gear	...	...	...	1	1	1	1	1
30	T946	Oil seal, high gear bearing	...	...	...	1	1	1	1	1
31	E489	Circlip, high gear bearing retaining	...	...	...	1	1	1	1	1
32	S35-7	Bearing, mainshaft	...	...	...	1	1	1	1	1
33	T280	Circlip, mainshaft bearing	...	...	...	1	1	1	1	1
34	T1367	Bush, layshaft casing and inner cover	...	...	...	2	2	2	2	2
35	T912	Peg, layshaft bush	...	...	...	2	2	2	2	2
36	T981	Disc, layshaft bush	...	...	...	1	1	1	1	1

GROUP 4 — GEARBOX

GEARBOX




FIG. 10

INDEX FIG. 10

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	T1201	36	10	35	T981	37	36	70	T1222	41	1
2	T989	36	11	36	T341	40	1	71	T31	41	2
3	E698	36	12	37	T412	40	3	72	T47	41	3
4	SI-51	36	13	38	T57	40	4	73	T25A	41	4
5	S25-3	36	14	39	T23	40	5	74	T24A	41	5
6	T1534	36	24	40	T933	40	6	75	T730	41	6
7	T1562	36	15	41	T948	40	7	76	T731	41	7
8	T323A	36	16	42	T397	40	8	77	T1250	41	9
9	SI-51	36	17	43	T399	40	9	78	NT297	41	10
10	S25-3	36	18	44	T500	40	10	79	T732	41	11
11	T45	36	21	45	NT261	40	11	80	T1338	41	8
12	T1542	36	29	46	T44	40	12	81	T471A	41	12
13	T1541	36	30	47	T372	40	13	82	T440	41	13
14	S46-15	36	33	48	T373	40	14	83	T1539	42	1
15	PT104B	36	34	49	T260B	40	15	84	T1536	42	3
16	T914	37	14	50	T913	40	16	85	T1554	42	6
17	PT108B	37	15	51	T291	40	17	86	E2312	42	7
18	S66-1	37	16	52	T407	40	18	87	T413	42	9
19	T1382	37	20	53	T454	40	19	88	T453	42	10
20	T1370	37	21	54	F879	40	20	89	T1552	42	11
21	T917	37	22	55	E2312	40	21	90	T924	108	10
22	T916	37	23	56	T408/1540	40	22	91	T925	108	12
23	T1063	37	24	57	T406	40	24	92	T934	108	13
24	T930	37	25	58	T405	40	25	93	T825	108	15
25	T1065	37	26	59	T1194	40	26	94	E3449	40	2
26	T926	37	27	60	W932	40	28	95	T1553	36	32
27	T928	37	28	61	T449	40	29	96	E2312	36	31
28	T448	37	29	62	T404	40	30	97	T1512	40	35
29	T946	37	30	63	E3309	40	23	98	Split pin	42	2
30	E489	37	31	64	T224	40	31	99	E3412	42	5
31	S35-7	37	32	65	S25-3	40	32	100	T1538	42	4
32	T280	37	33	68	T451	40	33	101	E732	36	22
33	T1367	37	34	69	F1814	40	41	102	NE507	36	23
34	T912	37	35								

GROUP 4 — GEARBOX

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	T341	Bush, gear selector camplate ...	1	1	1	1	1
2	E3449	Peg, gear selector camplate bush ...	1	1	1	1	1
3	T412	Bush, footchange spindle inner ...	1	1	1	1	1
4	T57	Bush, footchange spindle outer ...	1	1	1	1	1
5	T23	Bush, kickstarter outer ...	1	1	1	1	1
6	T933	Bush, speedo gear inner cover ...	1	1	1	1	1
7	T948	Washer, speedo gear bush sealing ...	1	1	1	1	1

GEAR CHANGE SELECTOR MECHANISM

8	T397	Quadrant, gear operating ...	1	1	1	1	1
9	T399	Spindle, gear operating quadrant ...	1	1	1	1	1
		Split pin $1\frac{1}{2} \times \frac{5}{16}$ dia....	1	1	1	1	1
10	T500	Camplate, gear control ...	1	1	1	1	1
11	NT261	Roller, gear control camplate ...	2	2	2	2	2
12	T44	Plunger, gear control camplate ...	1	1	1	1	1
13	T372	Bush, gear control camplate plunger ...	1	1	1	1	1
14	T373	Spring, gear control camplate plunger ...	1	1	1	1	1
15	T260B	Fork, gear selector mainshaft ...	1	1	1	1	1
16	T913	Fork, gear selector layshaft ...	1	1	1	1	1
17	T291	Rod, gear selector fork ...	1	1	1	1	1
18	T407	Plate, quadrant guide ...	1	1	1	1	1
19	T454	Stud, quadrant guide plate $\frac{7}{8}$ " O/A ...	4	4	4	4	4
20	F879	Nut, quadrant guide plate stud ...	4	4	4	4	4
21	E2312	Washer, quadrant guide plate stud ...	4	4	4	4	4
22	T408/1540	Quadrant, gearchange ...	1	1	1	1	1
23	E3309	"O" ring, gearchange quadrant ...	1	1	1	1	1
24	T406	Plunger, gear quadrant ...	2	2	2	2	2
25	T405	Spring, gear quadrant plunger ...	2	2	2	2	2
26	T1194	Pedal, gearchange ...	1	1	1	1	1
27	T1564	Pedal, gearchange (Heel and Toe) (Alternative equipment) ...	A	A	A	A	A
28	W932	Set screw, gearchange pedal 1" U/H ...	1	1	1	1	1
29	T449	Rubber, gearchange pedal ...	1	1	1	1	1
30	T404	Spring, gearchange pedal return ...	2	2	2	2	2
31	T224	Nut, gear quadrant spindle ...	1	1	1	1	1
32	S25-3	Washer, gear quadrant spindle ...	1	1	1	1	1

KICKSTARTER

33	T451	Crank, kickstarter (rigid) ...	1	1	1	—	1
34	*T1270	Crank, kickstarter (folding) complete ...	A	A	A	1	A
35	T1512	Tube, kickstarter shaft rubber ...	1	1	1	1	1
36	T1271	Lever, kickstarter ...	A	A	A	1	A
37	T1272	Pedal, kickstarter ...	A	A	A	1	A
38	T1273	Bolt, lever to pedal 1.155" U/H ...	A	A	A	1	A
39	S70-3	Ball, pedal locating ...	A	A	A	1	A
40	T1167	Spring, pedal locating ball ...	A	A	A	1	A
41	F1814	Rubber, kickstarter pedal ...	1	1	1	1	1

* Fitted to T100 and T110 machines for export to U.S.A.

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	T1222	Cotter pin c/w nut and washer					
2	T31	Spring, k/s crank return					
3	T47	Peg, k/s anchor					
4	T25A	Quadrant, kickstarter					
5	T24A	Shaft, kickstarter axle					
6	T730	Pinion, kickstarter					
7	T731	Ratchet, kickstarter					
8	T1338	Sleeve, kickstarter pinion					
9	T1250	Spring, kickstarter pinion					
10	NT297	Nut, kickstarter ratchet					
11	T732	Washer, kickstarter lock					

GEARBOX SPROCKET

12	T471A	Sprocket, gearbox					
13	T440	Nut, gearbox sprocket locking					

CLUTCH AND SHOCK ABSORBER

14	T1548	Clutch assembly					—
15	T1586	Clutch assembly	—	—	—	—	
16	T1549	Housing clutch sprocket					
17	T1038	Centre, clutch					
18	T1039	Plate, inner, retaining shock absorber					
19	T1040	Screw, inner, retaining shock absorber, 0.417" ...	4	4	4	4	4
20	T1041	Spider, clutch shock absorber					
21	T1472	Rubber insert, clutch shock absorber (drive) ...	4	4	4	4	4
22	T1473	Rubber insert, clutch shock absorber (rebound) ...	4	4	4	4	4
23	T1044	Plate, outer, retaining shock absorber					
24	T1040	Screw, outer, retaining shock absorber, 0.417" U/H	4	4	4	4	4
25	T418	Hub, clutch					
26	T394	Roller, clutch housing to hub	20	20	20	20	20
27	T1362	Plate, clutch driving (bonded)	5	5	5	5	5
28	T1363	Plate, clutch driven (plain)	6	6	6	6	6
29	T999	Spring, clutch pressure	4	4	4	4	—
30	T1560	Spring, clutch pressure (strong)	A	A	A	A	4
31	T423A	Pin, clutch pressure spring, 1 $\frac{37}{32}$ " U/H	4	4	4	4	4
32	T427	Nut, clutch pressure spring pin	4	4	4	4	4
33	T998	Cup, clutch pressure spring	4	4	4	4	4
34	T986	Plate, clutch pressure c/w button					
35	T422	Button, clutch pressure plate					

GROUP 4 — GEARBOX

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

CLUTCH CONTROL

1	T1539	Lever, clutch operating	...	...	...	...					
2	$\frac{1}{16}'' \times \frac{5}{8}''$	Split pin, cable to lever	...	...	...	...					
3	T1536	Arm, clutch lever c/w roller	...	...	...	...					—
4	T1538	Roller, clutch arm	...	...	...	...					—
5	E3412	Pin, roller to arm	...	...	...	...					—
6	T1554	Peg, clutch operating lever	...	...	...	...					
7	E2312	Washer, serrated	...	...	...	...					
8	T402	Arm, clutch lever	...	...	...	...	—	—	—	—	
9	T413	Pin, clutch lever adjusting	...	...	...	...					
10	T453	Nut, clutch lever adjusting lock	...	...	...	...					
11	T1552	Rod, clutch operating	...	...	...	...					




FIG. II. CLUTCH AND SHOCK ABSORBER

INDEX FIG. II

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	T1047	37	17	12	T418	41	25
2	T1045	37	18	13	T394	41	26
3	T1046	37	19	14	T1362	41	27
4	T1549	41	16	16	T1363	41	28
5	T1038	41	17	17	T5160	41	30
6	T1039	41	18		T999	41	29
7	T1040	41	19	18	T423A	41	31
8	T1041	41	20	19	T427	41	32
9	T1472	41	21	20	T998	41	33
10	T1473	41	22	21	T986	41	34
11	T1044	41	23				

WIDE RATIO GEARS — GROUP 5
STANDARD RATIO GEARS — GROUP 6
CLOSE RATIO GEARS — GROUP 7

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

WIDE RATIO GEARS—GROUP 5

To convert from standard to wide ratio

1	T1384	Gear, mainshaft high 28T	...	...	...	...					
2	T968	Gear, mainshaft 2nd 19T	...	...	...	...					
3	T971	Gear, layshaft high 18T c/w speedo gear	...	...	...	...					
4	T974	Gear, layshaft 2nd 27T	...	...	...	...					
5	T975	Gear, speedometer driven	...	...	...	...					

STANDARD RATIO GEARS—GROUP 6

To convert from wide to standard ratio

6	T1382	Gear, mainshaft high 26T	...	...	...	...					
7	T916	Gear, mainshaft 2nd 20T	...	...	...	...					
8	T1063	Gear, layshaft high 20T c/w speedo gear	...	...	...	...					
9	T1065	Gear, layshaft 2nd 26T	...	...	...	...					
10	T934	Gear, speedometer driven	...	...	...	...					

CLOSE RATIO GEARS—GROUP 7

11	T1177	Mainshaft and low gear 18T	...	...	...	...					
12	T1383	Gear, mainshaft high 24T	...	...	...	...					
13	T955	Gear, mainshaft 2nd 21T	...	...	...	...					
14	T1179	Gear, mainshaft 3rd 23T	...	...	...	...					
15	T959	Layshaft and high gear 22T	...	...	...	...					
16	T961	Gear, layshaft low 28T	...	...	...	...					
17	T963	Gear, layshaft 2nd 25T	...	...	...	...					
18	T964	Gear layshaft 3rd 23T	...	...	...	...					
19	T983	Plug, speedometer drive sealing	...	...	...	...					
20	T948	Washer, speedometer drive plug	...	...	...	...					

Gear Ratios. Suitable ratios can be selected from the three groups which will enable the rider to operate his machine for normal road work or sporting events. To vary the ratios of any group, engine sprockets ranging from 17 to 25 teeth are available.

On the page following there will be found a R.P.M. and Gear Ratio Chart, which will assist the rider in making his selection.

R P M AND GEAR CHARTS

ENGINE REVOLUTIONS PER MINUTE

GEAR RATIO	4.4	4.57	4.78	5.0	5.24	5.5	5.7	5.8	6.0	6.25	6.5	6.9	7.06	7.14	7.5	8.0	8.85	9.8	10.6	11.58	12.2	13.9	14.3	15.25	16.0	17.8	18.85
20	1144	1188	1244	1300	1364	1428	1480	1508	1560	1624	1688	1796	1836	1856	1948	2080	2300	2548	2756	3012	3172	3612	3720	3964	4160	4628	4900
25	1430	1485	1555	1625	1705	1785	1850	1885	1950	2030	2110	2245	2295	2320	2435	2600	2875	3185	3445	3765	3965	4515	4650	4955	5200	5785	6125
30	1716	1782	1866	1950	2046	2142	2220	2262	2340	2435	2532	2694	2754	2784	2922	3120	3450	3822	4134	4518	4758	5418	5585	5946	6240	6942	—
35	2002	2079	2177	2275	2387	2499	2590	2639	2730	2842	2954	3143	3213	3248	3409	3640	4025	4459	4823	5271	5551	6321	6510	6937	—	—	—
40	2288	2376	2488	2600	2728	2856	2960	3016	3120	3248	3376	3592	3672	3712	3896	4160	4600	5096	5512	6024	6344	—	—	—	—	—	—
45	2574	2673	2799	2925	3069	3213	3330	3393	3510	3554	3798	4041	4131	4176	4383	4680	5175	5733	6201	6777	7137	—	—	—	—	—	—
50	2860	2970	3110	3250	3410	3570	3700	3770	3900	4060	4220	4490	4590	4640	4870	5200	5750	6370	6890	—	—	—	—	—	—	—	—
55	3146	3267	3421	3575	3751	3927	4070	4147	4290	4466	4642	4939	5049	5104	5357	5720	6325	7007	—	—	—	—	—	—	—	—	—
60	3432	3564	3732	3900	4092	4284	4440	4524	4680	4872	5064	5388	5508	5568	5844	6240	6900	—	—	—	—	—	—	—	—	—	—
70	4004	4158	4354	4550	4774	4998	5180	5278	5460	5684	5908	6286	6426	6496	6331	6760	—	—	—	—	—	—	—	—	—	—	—
80	4576	4752	4976	5200	5456	5712	5920	6032	6240	6496	6752	7184	7344	7424	—	—	—	—	—	—	—	—	—	—	—	—	—
90	5148	5346	5598	5850	6138	6426	6660	6786	7020	7308	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
100	5720	5940	6220	6500	6820	7140	7400	7540	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
110	6292	6534	6842	7150	7502	7854	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—

NOTE.—Engine R-P-M are calculated in conjunction with 3.50 X 19 Rear tyre equipment—780 R-P-Mile—and will deviate slightly from above figures for models not so equipped.
 4.00 X 18 Rear Tyre 785 R-P-Mile.
 3.25 X 19 Rear Tyre 793 R-P-Mile.
 4.00 X 19 Rear Tyre 756 R-P-Mile.

GEAR RATIOS

GEARS	STANDARD RATIO				WIDE RATIO				CLOSE RATIO			
	Top	3rd	2nd	1st	Top	3rd	2nd	1st	Top	3rd	2nd	1st
Engine Sprocket	1.00	1.19	1.69	2.44	1.00	1.42	2.21	2.91	1.00	1.09	1.30	1.69
Gearbox Reduction												
17	6.46	7.7	10.94	15.8	6.46	9.22	14.30	18.85	6.46	7.06	8.42	11.00
18	6.10	7.28	10.32	14.9	6.10	8.70	13.50	17.80	6.10	6.66	7.95	10.40
19	5.80	6.9	9.8	14.15	5.80	8.25	12.80	16.85	5.80	6.32	7.54	9.84
20	5.50	6.55	9.3	13.4	5.50	7.84	12.18	16.0	5.50	6.00	7.15	9.35
21	5.24	6.24	8.85	12.8	5.24	7.46	11.58	15.25	5.24	5.72	6.81	8.90
22	5.00	5.95	8.45	12.2	5.00	7.13	11.05	14.55	5.00	5.45	6.50	8.50
23	4.78	5.69	8.09	11.69	4.78	6.82	10.60	13.90	4.78	5.23	6.23	8.12
24	4.57	5.45	7.75	11.2	4.57	6.54	10.14	13.35	4.57	5.00	5.96	7.78
25	4.40	5.24	7.45	10.75	4.40	6.26	9.73	12.80	4.40	4.80	5.73	7.46

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

EXHAUST SYSTEM—GROUP 8

EXHAUST PIPES

1	E3426	Pipe, exhaust, L.H.	...	...	...	...	...	1	—	—	—	—
2	E3350	Pipe, exhaust, R.H.	...	...	...	...	...	1	—	—	—	—
3	E3629	Pipe, exhaust, L.H.	...	...	...	...	...	—	1	—	—	—
4	E3633	Pipe, exhaust, R.H.	...	...	...	...	...	—	1	—	—	—
5	E3628	Pipe, exhaust, L.H.	...	...	...	...	...	—	—	1	—	1
6	E3632	Pipe, exhaust, R.H.	...	...	...	...	...	—	—	1	—	1
7	E3472	Pipe, exhaust, L.H.	...	...	...	...	...	—	—	—	1	—
8	E3473	Pipe, exhaust, R.H.	...	...	...	...	...	—	—	—	1	—
9	E1269	Clip, pipe to head	...	...	...	...	...	2	—	2	2	2
10	E1270	Clip, pipe to head	...	...	...	...	...	—	2	—	—	—
11	E409	Bolt, exhaust clip, $1\frac{3}{16}$ " U/H	...	...	...	...	...	2	2	2	2	2
12	E410A	Washer, exhaust clip bolt	...	...	...	...	...	2	2	2	2	2
13	E3469	Clip, exhaust to extension pipe	...	...	...	...	...	—	—	—	1	—
14	TE164E	Bolt, exhaust clip, $1\frac{3}{16}$ " U/H	...	...	...	...	...	—	—	—	1	—
15	TE164C	Nut, exhaust clip bolt (D shape)	...	...	...	...	...	—	—	—	1	—
16	TE164D	Washer, exhaust clip bolt (D shape)	...	...	...	...	...	—	—	—	1	—
17	E2989	Bracket, exhaust pipe to engine plate, L.H.	...	...	...	...	...	1	1	1	—	1
18	E2990	Bracket, exhaust pipe to engine plate, R.H.	...	...	...	...	...	1	1	1	—	1
19	DS57	Bolt, exhaust pipe to bracket, $\frac{7}{16}$ " U/H	...	...	...	...	...	2	2	2	—	2
20	S26-2	Washer, exhaust pipe to bracket bolt	...	...	...	...	...	2	2	2	1	2
21	F879	Nut, exhaust pipe to bracket bolt	...	...	...	...	...	2	2	2	1	2
22	F1369	Bolt, exhaust pipe clip, $\frac{5}{8}$ " U/H	...	...	...	...	...	—	—	—	1	—
23	F1699	Clip, pipe to backstay	...	...	...	...	...	—	—	—	1	—

SILENCERS

24	E3651	Silencer, L.H.	...	...	...	...	...	1	1	1	—	1
25	E3652	Silencer, R.H.	...	...	...	...	...	1	1	1	—	1
26	E3470	Silencer	...	...	...	...	...	—	—	—	1	—
27	DS55	Bolt, silencer hanger, $1\frac{5}{16}$ " U/H	...	...	...	...	...	2	2	2	—	2
28	F1213	Bolt, silencer hanger, $\frac{11}{16}$ " U/H	...	...	...	...	...	—	—	—	1	—
29	S1-51	Nut, silencer hanger bolt	...	...	...	...	...	2	2	2	1	2
30	S25-3	Washer, silencer hanger bolt nut	...	...	...	...	...	—	—	—	1	—
31	E3469	Clip, silencer to exhaust pipe	...	...	...	...	...	—	—	—	1	—
32	TE164E	Bolt, silencer to exhaust pipe clip, $1\frac{3}{16}$ " U/H	...	...	...	...	...	—	—	—	1	—
33	TE164C	Nut, silencer to exhaust pipe clip	...	...	...	...	...	—	—	—	1	—
34	TE164D	Washer, silencer to exhaust pipe clip	...	...	...	...	...	—	—	—	1	—

GROUP 8 — EXHAUST SYSTEM




FIG. 12. EXHAUST PIPES AND SILENCERS

EXHAUST SYSTEM — GROUP 8

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	E3767	Clip, silencer to exhaust pipe	2	2	2	—	2
2	F3430	Bolt, silencer to exhaust pipe clip, $\frac{5}{8}$ " U/H	2	2	2	—	2
3	E3768	Washer, clip bolt nut (D shape)	4	4	4	—	4
4	E1310	Nut, clip bolt	2	2	2	—	2
5	F4141	Stay, clip bolt to frame	2	2	2	—	2
6	F3641	Stud, stay to frame, $\frac{15}{16}$ " O/A	1	1	1	—	1
7	S26-3	Washer, fixing stud	1	1	1	—	1
8	SI-51	Nut, stay stud	1	1	1	—	1

INDEX FIG. 12

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	E3426	45	1	15	DS57	45	19
	E3629	45	3	16	F1369	45	22
	E3628	45	5	17	S26-2	45	20
2	E3472	45	7	18	F879	45	21
3	E3350	45	2	19	E3651	45	24
	E3633	45	4	20	E3652	45	25
	E3632	45	6	21	E3470	45	26
4	E3473	45	8	22	DS55	45	27
5	E1269	45	9	23	F1213	45	28
	E1270	45	10	24	SI-51	45	29
6	E3469	45	13	25	S25-3	45	30
7	E410A	45	12	26	E3767	47	1
8	E409	45	11	27	F3430	47	2
9	TE164E	45	14	28	E3768	47	3
10	TE164C	45	15	29	E1310	47	4
11	TE164D	45	16	30	F4141	47	5
12	E2989	45	17	31	F3641	47	6
13	E2990	45	18	32	SI-51	47	8
14	F1699	45	23	33	S26-3	47	7

GROUP 9 - FRAME




FIG. 13. FRAME

INDEX FIG. 13

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	DS55	45	27	33	F2647	52	3	65	F3595	83	1
2	SI-51	45	29		E2223	52	4	66	F867	83	2
3	F3769	37	1	34	F3760	52	5	67	SI-52	83	5
4	F3772	37	4	34A	F3541	52	6	68	S25-2	83	6
5	F3575	37	5	35	F3571	53	2	69	S26-16	83	7
6	DS47	37	6	36	F2414	53	3	70	F3597	83	8
7	F4422	37	8	37	F1711	53	4	71	Split pin	83	9
8	SI-51	37	10	38	F839	53	5	72	S25-13	83	10
9	F3767	37	11	39	F3665	53	6	73	F3667	83	12
10	PO172A	37	13	40	F1680	53	7	74	F3593	83	13
11	F4414	50	1	41	F3108	53	8	75	F987	83	14
12	F1561	50	21	42	DS47	53	9	76	NF704	83	15
13	PO172A	50	22	43	PO172A	53	10	77	F3592	83	16
14	F1841	50	6	44	SI-52	53	11	78	DS48	83	17
15	F3900	50	7	45	F862	53	14	79	F862	83	19
16	F1451	50	8	46	H111	58	26	80	T87	83	20
17	SI-52	50	9	47	H111	58	26	81	F1694	83	21
18	F4273	50	10	48	F4304	51	19	82	F1695	83	22
19	F3816	50	14	49	F3619	51	20	83	F2271	83	23
20	F3814	50	11	50	F2725	51	22	84	SI-51	83	24
21	F3635	50	24	51	F3617	51	23	85	F3641	84	12
22	F3718	50	25	52	F3618	51	24	86	F1008	84	13
23	F3580	50	26	53	F3723	51	26	87	E2593	107	10
24	F2603	50	27	54	F3097	51	27		F3006	107	11
25	KW194	50	31	55	F1610	51	28	88	SI-51	107	13
26	F1431	51	1	56	F3096	51	29	89	See page 108		
27	F3690	51	2	57	F3641	47	6	90	See page 108		
28	F3574	51	3	58	SI-51	47	8	91	See page 108		
29	F3564	51	4	59	F967	50	12	92	9054/151	108	24
30	F3797	51	5	60	F3815	50	13	93	9054/47	108	25
31	F3798	51	6	61	T449	51	25	94	9054/171	108	23
32	F3799	51	7	62	F3770	37	2	97	E2113	108	31
	F2646	52	1	63	F3641	74	14	98	PO172A	108	33
	E2222	52	2	64	F1008	74	15	99	F3774	51	8

GROUP 9 — FRAME

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
FRONT PORTION							
1	F4414	Frame, front portion	1	1	1	1	1
2	F3906	Bolt, steering stop $\frac{9}{16}$ " U/H	2	2	2	2	2
3	T224	Locknut, stop bolt	2	2	2	2	2
4	D402/3	Lock, steering head c/w keys	A	A	A	A	A
5	D403	Key, lock (state number)	A	A	A	A	A
6	F1841	Support, petrol tank front	1	1	1	—	1
7	F3900	Support, petrol tank front (Export Tigers only)	—	A	A	1	A
8	F1451	Bolt, petrol tank front support $2\frac{1}{8}$ " U/H	1	1	1	1	1
9	SI-52	Nut, petrol tank front support	1	1	1	1	1
10	F4273	Support, petrol tank rear	1	1	1	1	1
11	F3814	Cup, tank support rubbers	4	4	4	4	4
12	F967	Washer, rubber top	2	2	2	2	2
13	F3815	Washer, rubber spigotted lower	2	2	2	2	2
14	F3816	Bolt, tank support to frame $1\frac{3}{16}$ " U/H	2	2	2	2	2
15	E3308	Stay, engine to frame torque	2	2	2	2	2
16	F2603	Bolt torque stay to frame lug $\frac{15}{16}$ " U/H	1	1	1	1	1
17	SI-51	Nut, torque stay bolt	1	1	1	1	1
18	S26-3	Washer, torque stay bolt	1	1	1	1	1
19	SI-52	Nut, torque stay to engine bolt	2	2	2	2	2
20	S26-1	Washer, torque stay to engine bolt	2	2	2	2	2
21	F1561	Stud, seat lug to back stays $5\frac{5}{16}$ " O/A	1	1	1	1	1
22	PO172A	Nut, seat lug to back stays stud	2	2	2	2	2
23	S26-1	Washer, seat lug to back stays stud	2	2	2	2	2

SEE FRONT FORK GROUP FOR STEERING RACES PAGE 58

REAR PORTION

24	F3635	Frame, rear portion	1	1	1	1	1
25	F3718	Support bracket L.H. silencer	1	1	1	1	1
26	F3580	Support bracket R.H. silencer	1	1	1	1	1
27	F2603	Bolt, bracket to frame $\frac{15}{16}$ " U/H	1	1	1	1	1
28	E1396	Stud, bracket to frame $1\frac{1}{8}$ " O/A	2	2	2	2	2
29	SI-51	Nut, bracket to frame bolts and stud	3	3	3	3	3
30	S26-3	Washer, bracket to frame bolts and stud	3	3	3	3	3
31	KW194	Lubricator, swinging fork	1	1	1	1	1
32	WE170	Washer, lubricator	1	1	1	1	1

ALWAYS QUOTE COLOURS WHEN ORDERING FRAME PARTS.

FRAME —GROUP 9 STAND — GROUP 10

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
SWINGING FORK							
1	F4131	Swinging fork assy. c/w bushes	1	1	1	1	1
2	F3690	Bush, fork lug	2	2	2	2	2
3	F3574	Spacing washer, R.H.	1	1	1	1	1
4	F3564	Spindle, S/Fork	1	1	1	1	1
5	F3797	Rod, cap retaining	1	1	1	1	1
6	F3798	Cap, spindle retaining	2	2	2	2	2
7	F3799	Nut, cap retaining	1	1	1	1	1
8	F3774	Stay, rear brake torque	1	1	1	1	1
9	F3780	Bolt, stay to fork 1 $\frac{1}{16}$ " U/H	1	1	1	1	1
10	DS47	Nut, stay bolt	1	1	1	1	1
11	PCW73A	Washer, stay bolt nut	1	1	1	1	1

STAND—GROUP 10

FRONT STAND

12	H412	Front stand	1	1	1	1	1
13	DS55	Bolt, front guard to stand $\frac{3}{16}$ " U/H	1	1	1	1	1
14	SI-51	Nut, front guard to stand bolt... ..	1	1	1	1	1
15	NS362	Nut, front stand to guard spigot	1	1	1	1	1
16	H424	Screw, front stand to fork pivot $\frac{39}{64}$ " U/H	2	2	2	2	2
17	S25-3	Washer, pivot screw plain	2	2	2	2	2
18	H425	Washer, pivot screw spring	2	2	2	2	2

CENTRE STAND

19	F4304	Centre stand	1	1	1	1	1
20	F3619	Pivot bolt, stand to frame 1 $\frac{3}{16}$ " U/H	2	2	2	2	2
21	F4484	Tab washer	2	2	2	2	2
22	F2725	Nut, stand to frame bolt	2	2	2	2	2
23	F3617	Spring, centre stand	1	1	1	1	1
24	F3618	Connecting link, stand spring	1	1	1	1	1
25	T449	Rubber, stand pedal	1	1	1	1	1

PROP STAND

26	F3723	Prop stand	1	1	1	1	1
27	F3097	Swivel pin, prop stand 1 $\frac{1}{4}$ " U/H	1	1	1	1	1
28	F2610	Spring, tension	1	1	1	1	1
29	F3096	Lock washer, swivel pin	1	1	1	1	1

GROUP II — ENGINE PLATE

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

ENGINE PLATE—GROUP II

1	F2646	Plate, engine front L.H.	...	...	...	...	1	—	—	—	—
2	E2222	Plate, engine front L.H.	...	...	...	...	—	1	1	1	1
3	F2647	Plate, engine front R.H.	...	...	...	...	1	—	—	—	1
4	E2223	Plate, engine front R.H.	...	...	...	...	—	1	1	1	—
5	F3760	Plate, engine rear L.H. ...	...	...	...	...	1	1	1	1	1
6	F3541	Plate, engine rear R.H. ...	...	...	...	...	1	1	1	1	1
7	F3688	Undershield, crankcase ...	...	...	...	...	—	—	—	1	—




FIG. 14. ENGINE PLATE—STUDS, BOLTS, NUTS AND WASHERS

INDEX FIG. 14

Illust. No.	Part No.	Description	Illust. No.	Part No.	Description
1, 3 and 4	F1711	Stud	8	F3769	Stud
	PO172A	Nut		F3770	Washer T.S.
	S26-1	Spring Washer		F3771	Nut D.S.
2	F2414	Stud	9, 10, 11 and 12	F3772	Nut T.S.
	DS47	Nut		F839	Stud
	PCW73A	Spring Washer		PO172A	Nut
5	F1680	Stud	13	S26-1	Spring Washer
	DS47	Nut		F3665	Stud
	PCW73A	Spring Washer		SI-52	Nut
6	T456	Stud	14	S26-1	Spring Washer
	SI-51	Nut		F3108	Bolt
	S25-3	Washer		PO172A	Nut
7	E1555	Bolt		S26-1	Spring Washer
	S25-3	Washer			

ENGINE PLATE — GROUP 11

TELESCOPIC FRONT FORK — GROUP 12

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	E2275	Cover, engine plate front	1	1	1	1	1
2	F3571	Cover, engine plate rear	1	1	1	1	1
3	F2414	Stud, $\frac{7}{16}$ " $\times$ $4\frac{1}{8}$ " C.E.I.	1	1	1	1	1
4	F1711	Stud, $\frac{3}{8}$ " $\times$ $4\frac{1}{16}$ " C.E.I.	3	3	3	3	3
5	F839	Stud, $\frac{3}{8}$ " $\times$ $4\frac{7}{16}$ " C.E.I.	4	4	4	4	4
6	F3665	Stud, $\frac{3}{8}$ " $\times$ $4\frac{1}{4}$ " C.E.I.	1	1	1	1	1
7	F1680	Stud, $\frac{7}{16}$ " $\times$ $4\frac{3}{8}$ " C.E.I.	1	1	1	1	1
8	F3108	Bolt, rear engine plate to frame, $7\frac{3}{32}$ " U/H	1	1	1	1	1
9	DS47	Nut, for F2414, F1680 Studs	4	4	4	4	4
10	PO172A	Nut, for F1023, F1711, F839 Studs and F3108 bolt	15	15	15	15	15
11	SI-52	Nut, for F3665 Stud	2	2	2	2	2
12	PCW73A	Washer, for F2414, F1680 Studs	4	4	4	4	4
13	S26-1	Washer, for F1711, F839 Studs and F3108 bolt	17	17	17	17	17
14	F862	Distance tube for F3108 bolt	1	1	1	1	1

FRONT FORK—GROUP 12

15	H1198	Fork assembly	1	1	1	—	1
16	H1200	Fork assembly	—	—	—	1	—
17	H663A	Lug, fork top	1	1	1	—	1
18	H380	Lug, fork top c/w clips	—	—	—	1	—
19	F1760	Bolt, fork top lug pinch, $1\frac{11}{16}$ " U/H	1	1	1	1	1
20	H379	Nut, fork pinch bolt	1	1	1	1	1
21	H660	"U" bolt, handlebar clamp	2	2	2	—	2
22	S25-3	Washer, handlebar clamp	4	4	4	—	4
23	E1310	Nut, handlebar clamp	4	4	4	—	4
24	H506	Cap, handlebar clamp	—	—	—	2	—
25	H436	Bolt, handlebar clamp cap, $\frac{7}{8}$ " U/H	—	—	—	4	—
26	H1229	Crown and stem fork	1	1	1	1	1
27	H405	Nut, crown and stem sleeve	1	1	1	1	1
28	H941	Bolt, crown and stem to stanchion, $2\frac{1}{4}$ " U/H	2	2	2	2	2
29	E2412	Nut, crown and stem to stanchion	2	2	2	2	2
30	S25-2	Washer, crown and stem to stanchion	2	2	2	2	2

GROUP 12 — TELESCOPIC FRONT FORK




FIG. 15. TELESCOPIC FORK

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	H799	Cover, nacelle, L.H.	1	1	1	—	1
2	H1205	Cover, nacelle, R.H.	1	1	1	—	1
3	H963	Cover, top c/w headlamp bracket, L.H.	—	—	—	1	—
4	H964	Cover, top c/w headlamp bracket, R.H.	—	—	—	1	—
5	H962	Gaiter, rubber, telescopic	—	—	—	2	—
6	D340	Clip, gaiter top	—	—	—	2	—
7	H1208	Top unit, nacelle	1	—	—	—	—
8	H1207	Top unit, nacelle	—	1	1	—	—
9	H1278	Top unit, nacelle	—	—	—	—	1
10	A46	Transfer, Thunderbird	1	—	—	—	—
11	A57	Transfer "Bonneville 120"	—	—	—	—	1
12	H669	Grommet, handlebar rubber	2	2	2	—	2
13	H961	Grommet, control cables	3	3	3	—	3
14	H689	Screw, top unit to nacelle cover, $\frac{1}{4}$ " U/H	2	2	2	—	2
15	H691	Nut, motif front	2	2	2	—	2
16	E2880	Washer, serrated	2	2	2	—	2
17	H623	Motif (flash), L.H.	1	1	1	—	1
18	H624	Motif (flash), R.H.	1	1	1	—	1
19	H688	Screw, motif front, $\frac{5}{16}$ " U/H	2	2	2	—	2
20	H691	Nut, motif front	2	2	2	—	2

INDEX FIG. 15

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	H663A	53	17	30	H432A	58	6
2	F1760	53	19	31	H443	58	8
3	H379	53	20	32	H444	58	9
4	H660	53	21	33	H384	58	10
5	E1310	53	23		H1095	58	11
6	H1229	53	26		H749	58	12
7	H405	53	27	34	H399A	58	15
8	H941	53	28	35	H452	58	17
9	E2412	53	29	36	H453	58	18
10	H799	55	1	37	H454	58	19
11	H1205	55	2	38	F879	58	20
12	H1207	55	8	39	H394	58	21
	H1208	55	7	40	H1096	58	22
13	H623	55	17	41	H397	58	23
14	H624	55	18	42	H1063	58	24
15	H420	57	3	43	H1062	58	25
16	H1201	57	4	44	H1018	58	27
17	H1202	57	5	45	H439	58	28
18	H1071	57	11	47	H536	58	30
19	H430	57	12	48	H565	58	31
20	H1053	57	8	49	H408	58	32
21	H1070	57	10	50	H409	58	33
22	H390	57	13	51	H413	58	34
23	H391	57	14	52	F1718	58	35
24	H445	57	15	53	SI-51	58	36
25	H431	57	16	54	H435	58	37
26	H441	58	1	55	H95	58	38
27	H382A	58	2	56	F3098	108	18
28	H519A	58	4	57	H992	57	17
29	H430	58	5	58	H993	57	18

GROUP 12 – TELESCOPIC FRONT FORK




FIG. 16. TELESCOPIC FORK (TROPHY)

TELESCOPIC FRONT FORK — GROUP 12

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	E2880	Washer, motif front	2	2	2	—	2
2	H687	Screw, top unit to nacelle cover, $\frac{3}{8}$ " U/H	2	2	2	—	2
3	H420	Washer, cover tube (rubber)	2	2	2	—	2
4	H1201	Bottom member c/w spindle cap, L.H.	1	1	1	—	1
5	H1202	Bottom member c/w spindle cap, R.H.	1	1	1	—	1
6	H1203	Bottom member c/w spindle cap, L.H.	—	—	—	1	—
7	H1204	Bottom member c/w spindle cap, R.H.	—	—	—	1	—
8	H1053	Cap, spindle fixing	2	2	2	2	2
9	S26-3	Washer, spring	4	4	4	4	4
10	H1070	Bolt, spindle cap, $1\frac{7}{8}$ " U/H	4	4	4	4	4
11	H1071	Plug, drain	2	2	2	2	2
12	H430	Washer, drain plug	2	2	2	2	2
13	H390	Sleeve, cover tube dust excluder	2	2	2	2	2
14	H391	Washer, cover tube dust excluder felt	2	2	2	2	2
15	H445	Washer, inner, for H391	2	2	2	2	2
16	H431	Washer, outer for H391	2	2	2	2	2
17	H992	Horn grille (replaces Pilot Lamp)	1	1	1	—	1
18	H993	Screw, grille fixing, 0.540" U/H	2	2	2	—	2
19	GS299	Washer, serrated	2	2	2	—	2
20	F3799	Nut, fixing screw	2	2	2	—	2

INDEX FIG. 16

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	H380	53	18	27	H444	58	9
2	F1760	53	19	28	H384	58	10
3	H379	53	20	29	H399	58	16
4	H506	53	24	30	H452	58	17
5	H436	53	25	31	H453	58	18
6	H1229	53	26	32	H454	58	19
7	H405	53	27	33	F879	58	20
8	H941	53	28	34	H394	58	21
9	E2412	53	29	35	H1096	58	22
10	H963	55	3	36	H397	58	23
11	H964	55	4	37	H1063	58	24
13	H1203	57	6	38	H1062	58	25
14	H1204	57	7	39	H1018	58	27
15	H1071	57	11	40	H439	58	28
16	H430	57	12	42	H536	58	30
17	H1053	57	8	43	H565	58	31
18	H1070	57	10	44	H408	58	32
19	H390	57	13	45	H409	58	33
20	H391	57	14	46	H413	58	34
21	H445	57	15	47	F1718	58	35
22	H431	57	16	48	SI-51	58	36
23	H441	58	1	49	H435	58	37
24	H382	58	3	50	H95	58	38
25	H432	58	7	52	F3098	108	18
26	H443	58	8	53	H962	55	5
				54	D340	55	6

GROUP 12 — TELESCOPIC FRONT FORK

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	H441	Bearing, bottom cover tube	2	2	2	2	2
2	H382A	Stanchion	2	2	2	—	2
3	H382	Stanchion	—	—	—	2	—
4	H519A	Plug, stanchion oil filler, $\frac{3}{16}$ " U/H	2	2	2	—	2
5	H430	Washer, stanchion oil filler	2	2	2	—	2
6	H432A	Nut, stanchion to top lug	2	2	2	—	2
7	H432	Nut, stanchion to top lug	—	—	—	2	—
8	H443	Bearing, stanchion lower	2	2	2	2	2
9	H444	Nut, stanchion hydraulic stop	2	2	2	2	2
10	H384	Spring, main (RED)	2	2	2	2	2
11	H1095	Spring, main (BLUE) sidecar	A	A	A	A	A
12	H749	Spring, main (PURPLE) extra heavy sidecar	A	A	A	A	A
13	H1106	Pressure tube assembly	2	2	2	2	2
14	H1107	Pressure tube assembly	—	—	—	2	—
15	H399A	Rod, oil pressure	2	2	2	2	2
16	H399	Rod, oil pressure	—	—	—	2	—
17	H452	Restrictor, oil	2	2	2	2	2
18	H453	Cup, oil restrictor rod	2	2	2	2	2
19	H454	Pin, oil restrictor rod cup	2	2	2	2	2
20	F879	Nut, oil restrictor rod	2	2	2	2	2
21	H394	Tube pressure	2	2	2	2	2
22	H1096	Body, pressure tube valve	2	2	2	2	2
23	H397	Sleeve, pressure tube support	2	2	2	2	2
24	H1063	Bolt, valve body to lug, $\frac{3}{16}$ " U/H	2	2	2	2	2
25	H1062	Washer, valve body bolt (aluminium)	2	2	2	2	2

STEERING CUPS, CONES AND BALLS

26	H111	Cup, frame lug, top and bottom	2	2	2	2	2
27	H1018	Cone, head lug, top, c/w dust cover	1	1	1	1	1
28	H439	Cone, crown and stem, bottom	1	1	1	1	1
29	S70-3	Ball, top and bottom race, $\frac{1}{4}$ "	40	40	40	40	40

STEERING DAMPER

30	H536	Knob, c/w rod	1	1	1	1	1
31	H565	Washer, damper knob abutment	1	1	1	1	1
32	H408	Sleeve, damper adjusting	1	1	1	1	1
33	H409	Pin, sleeve securing	1	1	1	1	1
34	H413	Plate, damper anchor	1	1	1	1	1
35	F1718	Bolt, damper anchor plate, $1\frac{3}{16}$ " U/H	1	1	1	1	1
36	SI-51	Nut, damper anchor plate	1	1	1	1	1
37	H435	Disc, damper anchor plate friction	1	1	1	1	1
38	H95	Spring, damper anchor plate	1	1	1	1	1

FRONT WHEEL — GROUP 13

REF. No. PART No. DESCRIPTION 6T T100 T110 TR6 T120

FRONT WHEEL—GROUP 13

1	WI333	Wheel, front, complete	...	...	...	...	1	—	—	—	—
2	WI323	Wheel, front, complete	...	...	...	...	—	1	1	1	1
3	WI229	Rim, spokes and hub, assembly	...	...	...	...	1	—	—	—	—
4	WI324	Rim, spokes and hub, assembly	...	...	...	...	—	1	1	1	1
5	WI230	Rim, front wheel, WM2-19	...	...	...	...	1	1	1	1	1
6	*WI236	Spoke, straight, 8/10G × 6"	...	...	...	...	40	—	—	—	—
7	*WI328	Spoke, straight, 8/10G × 5½"	...	...	...	...	—	40	40	40	40
8	S79-2	Nipple, spoke	...	...	...	...	40	40	40	40	40
9	WI231	Hub and brake drum	...	...	...	...	1	—	—	—	—
10	WI325	Hub and brake drum	...	...	...	...	—	1	1	1	1
11	WI239	Spindle, front wheel	...	...	...	...	1	1	1	1	1
12	W653	Bearing, front wheel	...	...	...	...	2	2	2	2	2
13	WI237	Dust cover, L.H. bearing	...	...	...	...	1	1	1	1	1
14	T280	Circlip, L.H. bearing	...	...	...	...	1	1	1	1	1
15	WI238	Backing ring, R.H. bearing	...	...	...	...	1	1	1	1	1
16	W582	Retaining ring, R.H. bearing	...	...	...	...	1	1	1	1	1
17	WI334	Cover plate, L.H. hub	...	...	...	...	1	—	—	—	—
18	WI332	Cover plate, L.H. hub	...	...	...	...	—	1	1	1	1
19	WI197	Weight, wheel balance, ½ oz.	...	...	...	...	} As required.				
20	WI198	Weight, wheel balance, 1 oz.	...	...	...	...					

*Supplied complete with Nipple S79-2.

FRONT BRAKE

21	WI301	Plate, front brake anchor	...	...	...	...	1	—	—	—	—
22	WI330	Plate, front brake anchor	...	...	...	...	—	1	1	1	1
23	WI302	Pin, shoe fulcrum	...	...	...	...	1	1	1	1	1
24	S25-2	Washer, fulcrum pin nut	...	...	...	...	1	1	1	1	1
25	E1435	Domed nut, fulcrum pin	...	...	...	...	1	1	1	1	1
26	W93	Shoe, brake c/w lining	...	...	...	...	2	—	—	—	—
27	WI337	Shoe, brake c/w lining, leading	...	...	...	...	—	1	1	1	1
28	WI338	Shoe, brake c/w lining, trailing	...	...	...	...	—	1	1	1	1
29	NW243	Lining, brake shoe	...	...	...	...	2	—	—	—	—
30	WI336	Lining, brake shoe	...	...	...	...	—	2	2	2	2
31	WI29	Rivet, brake shoe lining	...	...	...	...	16	16	16	16	16
32	WI35	Spring, brake shoe return	...	...	...	...	2	2	2	2	2
33	WI243	Cam, brake operating	...	...	...	...	1	1	1	1	1
34	WI298	Lever, brake cam	...	...	...	...	1	—	—	—	—
35	WI331	Lever, brake cam	...	...	...	...	—	1	1	1	1
36	S1-52	Nut, brake cam lever	...	...	...	...	1	1	1	1	1
37	S25-6	Washer, brake cam lever	...	...	...	...	1	1	1	1	1
38	W592	Spring, brake cam lever return	...	...	...	...	1	1	1	1	1
39	WF32	Pin, brake cam lever pivot	...	...	...	...	1	1	1	1	1
40		⅜" × ½" Split pin, pivot pin	...	...	...	...	1	1	1	1	1
41	WI246	Nut, anchor plate to spindle	...	...	...	...	1	1	1	1	1




FIG. 17. FRONT WHEEL for THUNDERBIRD (6T)

INDEX FIG. 17

<i>Illust. No.</i>	<i>Part No.</i>	<i>Page No.</i>	<i>Ref. No.</i>
1	WI334	59	17
2	T280	59	14
3	WI237	59	13
4	W653	59	12
5	WI239	59	11
6	S79-2	59	8
7	WI236	59	6
8	WI231	59	9
9	WI238	59	15
10	W582	59	16
11	W93	59	26
12	WI243	59	33
13	WI301	59	21
14	W592	59	38
15	WI298	59	34
16	S25-6	59	37
17	SI-52	59	36
18	WI35	59	32
19	WI302	59	23
20	NW243	59	29
21	WI29	59	31
22	WI246	59	41
23	S25-2	59	24
24	E1435	59	25

GROUP 13 — FRONT WHEEL




FIG. 18. FRONT WHEEL—TIGER 100, TIGER 110, TROPHY AND BONNEVILLE 120

INDEX FIG. 18

<i>Illust. No.</i>	<i>Part No.</i>	<i>Page No.</i>	<i>Ref. No.</i>
1	W1332	59	18
2	T280	59	14
3	W1237	59	13
4	W653	59	12
5	W1239	59	11
6	S79-2	59	8
7	W1328	59	7
8	W1325	59	10
9	W1238	59	15
10	W582	59	16
11	W1337	59	27
	W1338	59	28
12	W1243	59	33
13	W1330	59	22
14	W592	59	38
15	W1331	59	35
16	S25-6	59	37
17	SI-52	59	36
18	W135	59	32
19	W1302	59	23
20	W1336	59	29
21	W129	59	31
22	W1246	59	41
23	S25-2	59	24
24	E1435	59	25

GROUP 14 — REAR WHEEL

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

REAR WHEEL—GROUP 14

1	WI305	Wheel, rear, complete ...	...	...	...	1	1	1	—	1
2	WI307	Wheel, rear, complete ...	...	...	...	—	—	—	1	—
3	WI306	Rim, spokes and hub assembly ...	...	...	...	1	1	1	—	1
4	WI308	Rim, spokes and hub assembly ...	...	...	...	—	—	—	1	—
5	W79A	Rim, rear wheel WM.2-19 ...	...	...	...	1	1	1	—	1
6	WI007	Rim, rear wheel WM.3-18 ...	...	...	...	—	—	—	1	—
7	*WI104	Spoke, L.H. 8/10G × 8" 90° ...	...	...	...	20	20	20	—	20
8	*WI106	Spoke, R.H. 8/10G × 8 $\frac{3}{8}$ " 90° ...	...	...	...	20	20	20	—	20
9	*WI107	Spoke, L.H. 8/10G × 7 $\frac{9}{16}$ " 90° ...	...	...	...	—	—	—	20	—
10	*WI108	Spoke, R.H. 8/10G × 7 $\frac{9}{16}$ " 90° ...	...	...	...	—	—	—	20	—
11	S79-2	Nipple, spoke ...	...	...	...	40	40	40	40	40
12	WI158	Hub ...	...	...	...	1	1	1	1	1
13	W951	Sprocket and drum (46T) ...	...	...	...	8	8	8	8	8
14	W62	Bolt, sprocket and drum to hub, $\frac{11}{16}$ " U/H ...	...	...	...	8	8	8	8	8
15	SI-51	Nut, sprocket and drum to hub ...	...	...	...	8	8	8	8	8
16	W63	Lockplate, sprocket and drum nut ...	...	...	...	8	8	8	8	8
17	WI025	Spindle, rear wheel ...	...	...	...	2	2	2	2	2
18	FI747	Nut, rear wheel spindle ...	...	...	...	2	2	2	2	2
19	W653	Bearing, rear wheel ball ...	...	...	...	1	1	1	1	1
20	WI022	Ring, bearing backing, L.H. ...	...	...	...	1	1	1	1	1
21	WI023	Distance, tube, bearing ...	...	...	...	1	1	1	1	1
22	WI021	Retaining ring, bearing ...	...	...	...	1	1	1	1	1
23	WI079	Locking screw, bearing retaining ring, $\frac{5}{16}$ " U/H ...	...	...	...	1	1	1	1	1
24	WI024	Distance piece, L.H. bearing ...	...	...	...	1	1	1	1	1
25	W583	Cap, bearing dust, R.H. ...	...	...	...	1	1	1	1	1
26	WI026	Nut, bearing retaining, R.H. ...	...	...	...	1	1	1	1	1
27	WI134	Chain adjuster, rear wheel ...	...	...	...	2	2	2	2	2
28	WI015	End plate, adjuster ...	...	...	...	2	2	2	2	2
29	WI058	Nut, adjuster end plate ...	...	...	...	2	2	2	2	2
30	D106	Bolt, tyre security ...	...	...	...	1	1	1	—	1
31	WM3	Bolt, tyre security ...	...	...	...	—	—	—	2	—

*Supplied complete with nipple.

REAR WHEEL BRAKE

32	WI112	Plate, rear brake anchor ...	...	...	...	1	1	1	1	1
33	FI747	Locknut, rear brake anchor plate ...	...	...	...	2	2	2	2	2
34	W93	Shoe assembly, rear with lining ...	...	...	...	2	2	2	2	2
35	NW243	Lining, rear brake shoe ...	...	...	...	16	16	16	16	16
36	WI29	Rivet, brake shoe lining ...	...	...	...	2	2	2	2	2
37	WI35	Spring, brake shoe return ...	...	...	...	2	2	2	2	2
38	WI083	Cam assembly rear brake ...	...	...	...	1	1	1	1	1
39	WI085	Lever, rear brake cam ...	...	...	...	1	1	1	1	1
40	SI-52	Nut, rear brake cam lever ...	...	...	...	1	1	1	1	1
41	WI090	Spring, rear brake cam lever return ...	...	...	...	1	1	1	1	1
42	DS47	Nut, torque stay securing ...	...	...	...	1	1	1	1	1
43	PCW73A	Washer, torque stay nut ...	...	...	...	1	1	1	1	1




FIG. 19. REAR WHEEL

INDEX FIG. 19

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	F1747	64	18	13	W1108	64	10	25	W1021	64	22
2	F1747	64	33	14	W1106	64	8	26	W1022	64	20
3	W1085	64	39	15	W1108	64	10	27	W1158	64	12
4	W1112	64	32	16	W653	64	19	28	W1104	64	7
5	W93	64	34	17	W1026	64	26	29	W1107	64	9
6	NW243	64	35	18	W1134	64	27	30	S79-2	64	11
7	W129	64	36	19	W1015	64	28	31	W1104	64	7
8	W1024	64	24	20	W1058	64	29	32	W1025	64	9
9	W951	64	13	21	SI-52	64	40	33	W583	64	17
10	W63	64	16	22	W1090	64	41	34	SI-51	64	25
11	W62	64	14	23	W135	64	37		W79A	64	15
12	W1023	64	21	24	W1083	64	38		W1007	64	5
13	W1106	64	8		W1079	64	23				6

GROUP 15 - REAR WHEEL (QUICKLY DETACHABLE)




FIG. 20. REAR WHEEL (QUICKLY DETACHABLE)

INDEX FIG. 20

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	W1052	67	32	14A	W1107	67	9	24	W1085	67	42
2	SI-52	67	41		W1106	67	8	25	W1090	67	40
3	W1121	67	38	15	W1108	67	10	26	W135	67	46
4	W93	67	43		W1106	67	8	27	W1083	67	39
5	NW243	67	44	15A	W1108	67	10	28	W1041	67	24
6	W129	67	45		W1104	67	7	29	W1045	67	28
7	W1040	67	22		W1107	67	9	30	W1044	67	27
8	W1042	67	25	16	W1038	67	18	31	W1035	67	15
9	W1043	67	26	17	E398	67	20	32	W1033	67	13
10	W79A	67	5	18	W1053	67	33	33	W1091	67	21
11	W1007	67	6	19	W1170	67	34	34	S79-2	67	11
12	W1034	67	14	20	W1055	67	35	35	W1033	67	13
13	W1039	67	19	21	W1135	67	29	36	W1036	67	16
14	W1100	67	12	22	W1015	67	30	37	W1037	67	17
	W1104	67	7	23	W1058	67	31	38	W1143	67	23

REAR WHEEL (QUICKLY DETACHABLE) — GROUP 15

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
REAR WHEEL (QUICKLY DETACHABLE)—GROUP 15							
1	WI309	Wheel, Q.D. rear complete	1	1	1	—	1
2	WI310	Wheel, Q.D. rear complete	—	—	—	1	—
3	WI098	Wheel, less internals and brake fittings	1	1	1	—	1
4	WI099	Wheel, less internals and brake fittings	—	—	—	1	—
5	W79A	Rim, WM2-19	1	1	1	—	1
6	WI007	Rim, WM3-18	—	—	—	1	—
7	*WI104	Spoke, L.H. 8/10G × 8" 90°	20	20	20	—	20
8	*WI106	Spoke, R.H. 8/10G × 8 $\frac{3}{8}$ " 90°	20	20	20	—	20
9	*WI107	Spoke, L.H. 8/10G × 7 $\frac{9}{16}$ " 90°	—	—	—	20	—
10	*WI108	Spoke, R.H. 8/10G × 7 $\frac{7}{8}$ " 90°	—	—	—	20	—
11	S79-2	Nipple, spoke	40	40	40	40	40
12	WI100	Hub	1	1	1	1	1
13	WI033	Backing ring, bearing	2	2	2	2	2
14	WI034	Bearing, taper roller	2	2	2	2	2
15	WI035	Dust cap, L.H. bearing	1	1	1	1	1
16	WI036	Felt washer, R.H. bearing	1	1	1	1	1
17	WI037	Distance piece, R.H. bearing	1	1	1	1	1
18	WI038	Dust cap, R.H. bearing	1	1	1	1	1
19	WI039	Sleeve, bearing and spindle	1	1	1	1	1
20	E398	Locknut, bearing and spindle sleeve	2	2	2	2	2
21	WI091	Sealing ring, driving flange and brake drum	1	1	1	1	1
22	WI040	Brake drum and sprocket 46T	1	1	1	1	1
23	WI143	Grease retainer, brake drum bearing	1	1	1	1	1
24	WI041	Bearing, brake drum	1	1	1	1	1
25	WI042	Felt washer, brake drum bearing	1	1	1	1	1
26	WI043	Retainer, brake drum bearing	1	1	1	1	1
27	WI044	Circlip, brake drum bearing retainer	1	1	1	1	1
28	WI045	Sleeve, brake drum bearing	1	1	1	1	1
29	WI135	Adjuster, rear wheel chain	2	2	2	2	2
30	WI015	End plate, rear wheel adjuster	2	2	2	2	2
31	WI058	Nut, rear wheel adjuster	2	2	2	2	2
32	WI052	Nut, bearing sleeve, L.H.	1	1	1	1	1
33	WI053	Distance collar, spindle	1	1	1	1	1
34	WI170	Collar, spindle	1	1	1	1	1
35	WI055	Spindle	1	1	1	—	1
36	WM2	Bolt, tyre security	—	—	—	2	—
37	WM3	Bolt, tyre security	—	—	—	2	—

REAR WHEEL BRAKE

38	WI121	Plate, brake anchor	1	1	1	1	1
39	WI083	Cam, brake	1	1	1	1	1
40	WI090	Return spring, brake lever	1	1	1	1	1
41	SI-52	Nut, brake lever	1	1	1	1	1
42	WI085	Lever, brake	1	1	1	1	1
43	W93	Shoe, rear brake c/w lining	2	2	2	2	2
44	NW243	Lining, rear brake shoe	2	2	2	2	2
45	WI29	Rivet, rear brake shoe	16	16	16	16	16
46	WI35	Spring, rear brake shoe	2	2	2	2	2
47	DS47	Nut, torque stay securing	1	1	1	1	1
48	PCW73A	Washer, torque stay nut	1	1	1	1	1

*Supplied complete with nipple.

GROUP 16 — MUDGUARD

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

MUDGUARD—GROUP 16

FRONT MUDGUARD

1	HI211	Mudguard assembly	1	1	1	—	1
2	HI216	Blade, front mudguard	—	—	—	1	—
3	HI217	Bridge, mudguard support	—	—	—	1	—
4	HI218	Stay, front mudguard	—	—	—	1	—
5	DS57	Bolt, stay to mudguard, $\frac{7}{16}$ " U/H	—	—	—	4	—
6	E1612	Washer, stay to mudguard bolt	—	—	—	4	—
7	F879	Nut, stay to mudguard bolt	—	—	—	4	—
8	F929	Bolt, bridge to fork, $\frac{1}{2}$ " U/H	2	2	2	—	2
9	F4299	Washer, bridge bolt	2	2	2	—	2
10	H451	Bolt, bridge to fork, $1\frac{1}{8}$ " U/H	—	—	—	2	—
11	SI-52	Nut, bridge bolt	—	—	—	2	—
12	HI171	Clip, brake cable... ..	1	1	1	—	1
13	H916	Screw, cable clip, $\frac{9}{32}$ " U/H	1	1	1	—	1
14	GS299	Washer, shakeproof	1	1	1	—	1
15	H745	Nut	1	1	1	—	1

INDEX FIG. 21

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	HI211	68	1	14	S26-2	70	28
2	H424	51	16	15	H251	70	29
3	S25-3	51	17	16	F4394	70	5
4	HI216	68	2	17	F3685	70	6
5	DS57	68	5	18	F3896	70	17
6	E1612	68	6	19	DS-57	70	18
7	F879	68	7	20	F879	70	19
8	HI218	68	4	21	F2996	70	23
9	H412	51	12	22	F3363	70	30
10	HI217	68	3	23	F929	70	31
11	F929	68	8	24	SI-51	70	32
12	F4299	68	9	25	F1369	70	34
13	F2698	70	22	26	F879	70	36




FIG. 21. FRONT AND REAR MUDGUARDS

GROUP 16 – MUDGUARD

GROUP 17 – NUMBER PLATE

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

LICENCE HOLDER

1	D261	Licence holder, etc.	1	1	1	1	1
2	DS57	Bolt, licence holder securing, $\frac{7}{16}$ " U/H	1	1	1	—	1
3	S25-1	Washer, licence holder securing bolt	1	1	1	—	1
4	F879	Nut, licence holder securing bolt	1	1	1	—	1

REAR MUDGUARD

5	F4394	Mudguard assembly, complete	1	1	1	—	1
6	F3685	Mudguard assembly, complete	—	—	—	1	—
7	F3599	Bracket, mudguard to rear engine plates	1	1	1	1	1
8	F2335	Bolt, bracket to rear engine plates, $\frac{11}{16}$ " U/H	2	2	2	2	2
9	S1-51	Nut, mudguard bracket bolt	2	2	2	2	2
10	S26-3	Washer, mudguard bracket bolt	2	2	2	2	2
11	DS57	Bolt, mudguard to bracket, $\frac{7}{16}$ " U/H	2	2	2	2	2
12	F879	Nut, mudguard to bracket bolt	2	2	2	2	2
13	S26-2	Washer, mudguard to bracket bolt	2	2	2	2	2
14	F3632	Bolt, mudguard to frame, $1\frac{9}{16}$ " U/H	2	2	2	2	2
15	S1-51	Nut, mudguard to frame bolt	2	2	2	2	2
16	S26-3	Washer, mudguard to frame bolt	2	2	2	2	2
17	F3896	Lifting handle, rear	1	1	1	1	1
18	DS57	Bolt, lifting handle to mudguard, $\frac{7}{16}$ " U/H	2	2	2	2	2
19	F879	Nut, lifting handle bolt	2	2	2	2	2
20	S26-2	Washer, lifting handle bolt	2	2	2	2	2
21	D324	Mudflap, rubber	A	A	A	A	A

NUMBER PLATE—GROUP 17

FRONT NUMBER PLATE

22	F2698	Plate assembly, number	1	1	1	—	1
23	F2996	Plate, number	—	—	—	1	—
24	H741	Clip, plate to mudguard c/w nut and bolt	—	—	—	2	—
25	H687	Screw, plate to clip, $\frac{3}{8}$ " U/H	—	—	—	2	—
26	F879	Nut, plate stud	2	2	2	—	2
27	H745	Nut, plate clip screw	—	—	—	2	—
28	S26-2	Washer, stud	2	2	2	—	2
29	H251	Beading, plate (rubber)	1	1	1	—	1

REAR NUMBER PLATE

30	F3363	Plate, rear number	1	1	1	1	1
31	F929	Bolt, rear number plate top, $\frac{1}{2}$ " U/H	1	1	1	1	1
32	S1-51	Nut, rear number plate top bolt	1	1	1	1	1
33	S26-3	Washer, number plate top bolt	1	1	1	1	1
34	F1369	Bolt, rear number plate bottom, $\frac{5}{8}$ " U/H	2	2	2	2	2
35	S26-2	Washer, bottom bolt nut	2	2	2	2	2
36	F879	Nut, bottom bolt	2	2	2	2	2
37	D68	Transfer, number plate (gold and white)	1	1	1	1	1

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

PETROL AND OIL TANK—GROUP 18

PETROL TANK (ALWAYS STATE COLOUR REQUIRED)

1	F4115	Tank, petrol (4 gallons)	...	...	...	...	1	1	1	—	1
2	F4116	Tank, petrol (3 gallons)	...	...	...	...	—	A	A	1	A
3	F4148	Styling strip, L.H. front	...	...	...	...	1	1	1	—	1
4	F4151	Styling strip, R.H. front	...	...	...	...	1	1	1	—	1
5	F4146	Styling strip, L.H. rear	...	...	...	...	1	1	1	—	1
6	F4149	Styling strip, R.H. rear ...	...	...	...	...	1	1	1	—	1
7	F4235	Styling strip, L.H. front	...	...	...	...	—	A	A	1	A
8	F4237	Styling strip, R.H. front	...	...	...	...	—	A	A	1	A
9	F4236	Styling strip, L.H. rear	...	...	...	...	—	A	A	1	A
10	F4238	Styling strip, R.H. rear ...	...	...	...	...	—	A	A	1	A
11	F4127	Styling unit, L.H.	...	...	...	...	1	1	1	1	1
12	F4128	Styling unit, R.H.	...	...	...	...	1	1	1	1	1
13	F4129	Screw, unit securing (·435" U/H)	...	...	...	...	4	4	4	4	4
14	F3220	Cap, tank filler ...	...	...	...	...	1	1	1	—	1
15	F3219	Cap, tank filler c/w jack chain	...	...	...	...	—	—	—	1	—
16	F4048	Washer, cap joint	...	...	...	...	1	1	1	1	1
17	F3967	Band, centre styling	...	...	...	...	1	1	1	1	1
18	F4019	Washer, shakeproof	...	...	...	...	1	1	1	1	1
19	H919	Nut, band fixing tag	...	...	...	...	1	1	1	1	1
20	F2551	Pad, knee grip, L.H.	...	...	...	...	1	1	1	—	1
21	F2552	Pad, knee grip, R.H.	...	...	...	...	1	1	1	—	1
22	F1606	Pad, knee grip, L.H. (Export Tigers)	...	...	...	...	—	A	A	1	A
23	F1605	Pad, knee grip, R.H. (Export Tigers)	...	...	...	...	—	A	A	1	A
24	F3915	Plate, knee grip insert, L.H. (Export Tigers)	...	...	...	...	—	A	A	1	A
25	F3916	Plate, knee grip insert, R.H. (Export Tigers)	...	...	...	...	—	A	A	1	A
26	F1953	Screw, knee grip pad, $\frac{5}{8}$ " U/H ...	...	...	...	...	4	4	4	—	4
27	T361	Bolt, knee grip pad	...	...	...	...	—	A	A	4	A
28	S25-13	Washer, knee grip bolt	...	...	...	...	—	A	A	4	A
29	F1808	Bolt, petrol tank fixing, $1\frac{3}{16}$ " U/H	...	...	...	...	4	4	4	4	4
30	F1813	Washer, rubber (upper)	...	...	...	...	4	4	4	4	4
31	F967	Washer, rubber (lower front)	...	...	...	...	2	2	2	2	2
32	F3815	Washer, rubber spigotted (rear)	...	...	...	...	2	2	2	2	2
33	S25-27	Washer, plain	...	...	...	...	4	4	4	4	4
34	F1717	Tap, petrol feed	...	...	...	...	1	—	—	—	—
35	F3057	Tap, petrol feed, L.H.	...	...	...	...	—	1	1	1	2
36	F3116	Tap, petrol feed, R.H. (reserve)	...	...	...	...	—	1	1	1	—
37	F1511	Washer, petrol tap and plug	...	...	...	...	2	2	2	2	2
38	F3329	Plug, petrol tank	...	...	...	...	1	—	—	—	—
39	F4448	Pipe, petrol feed	...	...	...	...	1	—	—	—	—
40	F4450	Pipe, petrol feed	...	...	...	...	—	2	2	2	—

For Bonneville 120 Petrol Pipes see Page 94.

GROUP 18 – PETROL AND OIL TANK





FIG. 22. PETROL TANKS AND FITTINGS

INDEX FIG. 22

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	F4115	71	1	17	F3815	71	32
2	F4116	71	2	18	S25-27	71	33
3	F3220	71	14	19	F4448	71	39
4	F3219	71	15	20	F1717	71	34
5	F4148	71	3	21	F3116	71	36
6	F4127	71	11	22	F3057	71	35
7	F4146	71	5	23	F1511	71	37
8	F4235	71	7	24	F3329	71	38
9	F4236	71	9	25	F4450	71	40
10	F2551	71	20	27	F3917	74	1
11	F1606	71	22	28	F2936	74	2
12	F3915	71	24	29	F3967	71	17
13	T361	71	27	30	F4129	71	13
14	F1808	71	29	31	F4019	71	18
15	F1813	71	30	32	H919	71	19
16	F967	71	31				

GROUP 18 — PETROL AND OIL TANK

GROUP 19 — CHAINGUARD

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

TANK PARCEL GRID

1	F3917	Grid, tank parcel	...	...	...	...	...	1	1	1	1	1
2	F2936	Screw, tank parcel grid	...	...	...	...	...	4	4	4	4	4
3	*F3026	Plug, petrol tank	...	...	...	...	...	4	4	4	4	4

*To replace F2936 when grid is not fitted.

OIL TANK

4	F3856	Tank, oil	...	...	...	...	...	1	—	—	—	—
5	F4513	Tank, oil	...	...	...	...	...	—	1	1	1	—
6	F4529	Tank, oil	...	...	...	...	...	—	—	—	—	1
7	F3658	Cap, oil tank filler	...	...	...	...	...	1	1	1	—	1
8	F3796	Cap, oil tank filler c/w jack chain	...	...	...	...	...	—	—	—	1	—
9	F3217/21	Jack chain, filler cap	...	...	...	...	...	—	—	—	1	—
10	E1792	Plug, oil tank drain	...	...	...	...	...	1	1	1	1	1
11	PT104B	Washer, oil tank drain plug	...	...	...	...	...	1	1	1	1	1
12	T1203	Pipe, oil tank vent (flexible)	...	...	...	...	...	1	—	—	—	—
13	T1578	Pipe, oil tank vent (flexible)	...	...	...	...	...	—	1	1	1	1
14	F3641	Stud, oil tank to seat tube, $\frac{15}{16}$ " O/A	...	...	...	...	...	1	1	1	1	1
15	F1008	Nut, oil tank to stud	...	...	...	...	...	1	1	1	1	1
16	S26-3	Washer, oil tank stud nut	...	...	...	...	...	1	1	1	1	1
17	F1213	Bolt, tank to backstay bracket, $\frac{11}{16}$ " U/H	...	...	...	...	...	1	1	1	1	1
18	SI-51	Nut, backstay bracket bolt	...	...	...	...	...	1	1	1	1	1
19	S26-3	Washer, backstay bolt nut	...	...	...	...	...	1	1	1	1	1
20	F3179	Filter, oil tank	...	...	...	...	...	1	1	1	1	1
21	F1713	Washer, oil tank filter	...	...	...	...	...	1	1	1	1	1
22	F3655	Pipe, top half oil feed	...	...	...	...	...	1	1	1	1	1
23	F3182	Union nut, feed pipe	...	...	...	...	...	1	1	1	1	1
24	E3353	Pipe, oil feed (flexible)	...	...	...	...	...	1	1	1	1	1
25	E3354	Pipe, oil return (flexible)	...	...	...	...	...	1	1	1	1	1
26	E3335	Junction block, oil pipes to engine	...	...	...	...	...	1	1	1	1	1
27	E1529	Washer, oil pipe block joint	...	...	...	...	...	1	1	1	1	1
28	SI-51	Nut, oil pipe block securing	...	...	...	...	...	1	1	1	1	1
29	S25-3	Washer, oil pipe block securing nut	...	...	...	...	...	1	1	1	1	1

For securing bolt, nut and washer, oil tank to rear engine plates, see Rear Mudguard group page 70.

CHAINGUARD—GROUP 19

REAR CHAINGUARD

30	F4130	Chainguard	...	...	...	...	...	1	1	1	—	1
31	F4138	Chainguard	...	...	...	...	...	—	—	—	1	—
32	F4134	Bracket, front	...	...	...	...	...	1	1	1	1	1
33	DS57	Bolt, chainguard front, $\frac{7}{16}$ " U/H	...	...	...	...	...	1	1	1	2	1
34	S26-2	Washer, chainguard bolt	...	...	...	...	...	1	1	1	2	1
35	F4135	Bolt, pivot (stepped)	...	...	...	...	...	1	1	1	1	1
36	F2277	Washer, thackeray	...	...	...	...	...	1	1	1	1	1
37	S25-13	Washer	...	...	...	...	...	1	1	1	1	1
38	F879	Nut	...	...	...	...	...	1	1	1	2	1
39	F4140	Bracket, centre	...	...	...	...	...	—	—	—	1	—
40	F4136	Bolt, chainguard rear (stepped)	...	...	...	...	...	1	1	1	1	1
41	S25-3	Washer	...	...	...	...	...	1	1	1	1	1
42	SI-51	Nut	...	...	...	...	...	1	1	1	1	1




FIG. 23. OIL TANK

INDEX FIG. 23

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	F3856	74	4	5	PT1048B	74	11
	F4513	74	5	6	T1203	74	12
	F4529	74	6		T1578	74	13
2	F3658	74	7	7	F3179	74	20
3	F3796	74	8	8	F1713	74	21
4	E1792	74	10	9	E3383	35	9

GROUP 20 — PRIMARY CHAINCASE

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

PRIMARY CHAINCASE—GROUP 20

1	T1237	Cover, chaincase outer ...	...	...	...	1	—	—	—	—
2	T1190	Cover, chaincase outer ...	...	...	...	—	1	1	1	1
3	T1231	Cover, chaincase inner ...	...	...	...	1	—	—	—	—
4	T1186	Cover, chaincase inner ...	...	...	...	—	1	1	1	1
5	T1059	Sleeve, chaincase inner (Rubber)	...	...	...	1	—	—	—	—
6	NT367	Plug, chaincase oil filler	...	...	...	1	1	1	1	1
7	NT376	Washer, chaincase oil filler plug	...	...	...	1	1	1	1	1
8	PCE102F	Plug, chaincase oil drain	...	...	...	1	1	1	1	1
9	WE170	Washer, chaincase oil drain plug	...	...	...	1	1	1	1	1
10	NT316	Dowel, chaincase to footrest	...	...	...	2	2	2	2	2
11	T1556	Plate, chaincase oil retainer	...	...	...	1	1	1	1	1
12	T91	Plate, chaincase oil retainer spring	...	...	...	1	1	1	1	1
13	T177A	Rivet, chaincase oil retainer plate	...	...	...	2	2	2	2	2
14	T496	Adjuster, rear chain oiler	...	...	...	1	1	1	1	1
15	T497	Spring, rear chain oiler ...	...	...	...	1	1	1	1	1
16	T1226	Washer, chaincase joint...	...	...	...	1	—	—	—	—
17	T1189	Washer, chaincase joint...	...	...	...	—	1	1	1	1
18	E3437	Screw, chaincase cover (short) $\frac{15}{16}$ " U/H	...	...	...	11	8	8	8	8
19	E4059	Screw, chaincase cover (long) $1\frac{13}{32}$ " U/H	...	...	...	—	3	3	3	3
20	E3444	Screw, chaincase cover (front) $2\frac{1}{2}$ " U/H	...	...	...	4	—	—	—	—
21	T1477	Washer, chaincase to crankcase joint	...	...	...	1	1	1	1	1

INDEX FIG. 24

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	T1237	76	1	11	PCE102F	76	8
2	T1190	76	2	12	WE170	76	9
3	E3978	104	4	13	NT316	76	10
4	E3979	104	5	14	T1556	76	11
5	E3444	76	20	15	T91	76	12
6	T1226	76	16	16	T496	76	14
7	T1231	76	3	17	T497	76	15
8	T1186	76	4	18	T1189	76	17
9	NT367	76	6	19	E3437	76	18
10	NT376	76	7	20	E4059	76	19




FIG. 24. PRIMARY CHAINCASE

GROUP 21 — HANDLEBAR

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

HANDLEBAR—GROUP 21

HANDLEBAR

1	H1223	Handlebar, complete with all controls	...	...	1	—	—	—	—
2	H1224	Handlebar, complete with all controls	...	...	—	—	—	1	—
3	H1225	Handlebar, complete with all controls	...	...	—	1	1	—	—
4	H1277	Handlebar, complete with all controls	...	...	—	—	—	—	1
5	H1009	Handlebar, bend only	...	...	1	1	1	—	1
6	H1003	Handlebar, bend only	...	...	—	—	—	1	—
7	H230	Grip, handlebar, L.H. rubber	...	...	1	1	1	1	1

FOR U.S.A. AND CANADIAN PATTERN SEE PAGE 82.

THROTTLE CONTROL

8	H697	Twistgrip, assembly	...	...	...	1	1	1	1	1
9	H230	Grip, twistgrip rubber	...	...	...	1	1	1	1	1
10	H698	Head, assembly, twistgrip	...	...	...	1	1	1	1	1
11	H685	Spring, twistgrip friction screw	...	...	...	1	1	1	1	1
12	H665	Screw, twistgrip friction adjuster	...	...	...	1	1	1	1	1
13	H686	Spring, twistgrip friction	...	...	...	1	1	1	1	1
14	H234	Thimble, twistgrip cable	...	...	...	1	1	1	1	1
15	H237	Grubscrew, twistgrip	...	...	...	1	1	1	1	1
16	H700	Sleeve assembly, twistgrip	...	...	...	1	1	1	1	1
17	H233	Plate, sleeve retaining	...	...	...	2	2	2	2	2
18	H232	Circlip, sleeve retaining	...	...	...	1	1	1	1	1

INDEX FIG. 25

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	H1009	78	5	9	18/892	80	17
	H1003	78	6	10	H668	80	18
	H1010	82	14	11	61/004	80	19
	H1179	82	15	12	18/087	80	20
2	H230	78	9	13	18/053	80	21
3	H698	78	10	14	18/886	80	1
4	H234	78	14	15	H689	99	24
5	H700	78	16	16	31563A	99	22
6	H233	78	17	17	18/839	80	23
7	H232	78	18	18	18/838	80	22
8	18/528	80	15				




FIG. 25. HANDLEBAR AND CONTROLS

GROUP 21 – HANDLEBAR

REF. No. PART No. DESCRIPTION 6T T100 T110 TR6 T120

FRONT BRAKE CONTROL

1	18/886	Lever assembly, front-brake	1	1	1	—	—
2	18/908	Lever assembly, front brake (ball-ended)	—	—	—	1	1
3	18/535	Lever only	1	1	1	—	—
4	18/754	Lever only (ball-ended)	—	—	—	1	1
5	18/890	Bracket, lever fulcrum	1	1	1	1	1
6	12/044	Clamp, lever bracket	1	1	1	1	1
7	11/014	Screw, lever bracket to clamp	2	2	2	2	2
8	18/087	Screw, lever fulcrum	1	1	1	1	1
9	18/053	Nut, lever fulcrum screw	1	1	1	1	1
10	18/838	Screw, adjuster	1	1	1	1	1
11	18/839	Nut, thumb	1	1	1	1	1
12	18/880	Nipple, slotted barrel	1	1	1	1	1

CLUTCH CONTROL

13	18/894	Lever assembly clutch	1	1	1	—	—
14	18/909	Lever assembly clutch (ball-ended)	—	—	—	1	1
15	18/528	Lever only	1	1	1	—	—
16	18/752	Lever only (ball-ended)	—	—	—	1	1
17	18/892	Bracket, lever fulcrum	1	1	1	1	1
18	H668	Clamp, lever bracket	1	1	1	1	1
19	61/004	Screw, lever bracket to clamp	2	2	2	2	2
20	18/087	Screw, lever fulcrum	1	1	1	1	1
21	18/053	Nut, lever fulcrum screw	1	1	1	1	1
22	18/838	Screw, adjuster	1	1	1	1	1
23	18/839	Nut, thumb	1	1	1	1	1
24	18/880	Nipple, slotted barrel	1	1	1	1	1

AIR CONTROL

25	12/612	Lever assembly air control	1	1	1	—	—
26	12/614	Lever assembly air control (chrome)	—	—	—	1	—
27	12/016	Lever only	1	1	1	—	—
28	12/556	Lever only	—	—	—	1	—
29	12/607	Bolt, centre	1	1	1	1	—
30	12/606	Cap	1	1	1	1	—
31	12/033	Washer, centre spring	1	1	1	1	—
32	11/014	Screw, fixing clip	2	2	2	2	—
33	12/044	Clip, fixing	1	1	1	1	—

HANDLEBAR GROUP 21

CONTROL CABLE — GROUP 22

REF. No. PART No. DESCRIPTION 6T T100 T110 TR6 T120

MAGNETO CONTROL

1	12/613	Lever assembly, magneto control	...	...	...	—	1	1	1	1
2	12/014	Lever only	...	...	...	—	1	1	1	1
3	12/607	Bolt, centre	...	...	...	—	1	1	1	1
4	12/606	Cap, centre	...	...	...	—	1	1	1	1
5	12/033	Washer, spring	...	...	...	—	1	1	1	1
6	11/014	Screw, clip fixing	...	...	...	—	2	2	2	2
7	12/044	Clip, fixing	...	...	...	—	1	1	1	1

CONTROL CABLE—GROUP 22

CLUTCH CABLE

8	D388	Cable assembly clutch	...	...	...	...	1	1	1	1	1
9	D103	Ferrule, cable casing	...	...	...	...	2	2	2	2	2
10	D368	Nipple	...	...	...	...	2	2	2	2	2

FRONT BRAKE CABLE

11	D414	Cable assembly, brake	...	...	...	...	1	—	—	—	—
12	D416	Cable assembly, brake	...	...	...	...	—	1	1	1	1
13	D103	Ferrule, cable casing	...	...	...	...	2	2	2	2	2
14	D368	Nipple (handlebar end)	...	...	...	...	1	1	1	1	1
15	W593	Fork end	...	...	...	...	1	1	1	1	1

THROTTLE CABLE

16	D224	Throttle cable assembly	...	...	...	...	1	1	1	1	—
17	D421	Throttle cable assembly	...	...	...	...	—	—	—	—	1
18	D422	Cable, twistgrip to junction box	...	...	...	...	—	—	—	—	1
19	244/104	Junction box	...	...	...	...	—	—	—	—	1
20	D423	Cable, junction box to carb.	...	...	...	...	—	—	—	—	2
21	D101	Ferrule, casing	...	...	...	...	3	3	3	3	10
22	H670	Guide tube, throttle wire	...	...	...	...	1	1	1	1	1
23	D83	Nipple, throttle wire (twistgrip)	...	...	...	...	1	1	1	1	1
24	NS191	Nipple, throttle wire (carb.)	...	...	...	...	1	1	1	1	5
25	D104	Adjuster, cable casing	...	...	...	...	1	1	1	1	3

GROUP 22 — CONTROL CABLE

GROUP 23 — OVERSEAS HANDLEBAR

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	D329	Cable assembly, air				—	—
2	D242	Cable assembly, air	—	—	—		—
3	D101	Ferrule, air casing					—
4	D83	Nipple, air wire (handlebar end)					—
5	NS191	Nipple, air wire (carburetter end)					—

IGNITION CABLE

6	D100	*Cable assembly, ignition	—				
7	D101	Ferrule, ignition casing	—	2	2	2	2
8	D83	Nipple, ignition wire (handlebar end)	—				
9	XA69	Clip, cables to frame, etc.	As required				

*Magneto end fittings supplied by Messrs. Lucas Ltd.

HANDLEBAR—GROUP 23

U.S.A. AND CANADIAN PATTERN

10	H1226	Handlebar, complete with all controls		—	—	—	—
11	H1227	Handlebar, complete with all controls	—			—	—
12	H1228	Handlebar, complete with all controls	—	—	—		—
13	H1279	Handlebar, complete with all controls	—	—	—	—	
14	H1010	Handlebar, bend only				—	
15	H1179	Handlebar, bend only	—	—	—		—
16	D415	Cable assembly, brake		—	—	—	—
17	D417	Cable assembly, brake	—				
18	D257	Cable assembly, throttle					—
19	D424	Cable assembly, throttle	—	—	—	—	
20	D425	Cable, twistgrip to junction box	—	—	—	—	2
21	D260	Cable assembly, ignition	—				
22	D389	Cable assembly, clutch					

REAR BRAKE CONTROL — GROUP 24 FOOTREST — GROUP 25

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

REAR BRAKE CONTROL—GROUP 24

1	F3595	Pedal, rear brake	...	...	...	...	1	1	1	1	1
2	F867	Spindle, rear brake pedal	...	...	...	...	1	1	1	1	1
3	DS48	Nut, rear brake spindle to frame	...	...	...	...	1	1	1	1	1
4	SCZ45	Washer, rear brake spindle to frame	...	...	...	...	1	1	1	1	1
5	SI-52	Nut, pedal spindle	...	...	...	...	1	1	1	1	1
6	S25-2	Washer, pedal spindle (plain)	...	...	...	...	1	1	1	1	1
7	S26-16	Washer, pedal spindle (spring)	...	...	...	...	1	1	1	1	1
8	F3597	Rod, brake operating	...	...	...	...	1	1	1	1	1
9		$\frac{1}{16}$ " $\times$ $\frac{1}{2}$ " Split pin	...	...	...	...	1	1	1	1	1
10	S25-13	Washer, brake rod for split pin	...	...	...	...	1	1	1	1	1
11	W11	Pivot roller, brake arm to rod	...	...	...	...	1	1	1	1	1
12	F3667	Thumb nut, brake rod adjusting	...	...	...	...	1	1	1	1	1

FOOTREST—GROUP 25

13	F3593	Footrest, R.H.	...	...	...	...	1	1	1	1	1
14	F987	Footrest, L.H.	...	...	...	...	1	1	1	1	1
15	NF704	Rubber, footrest	...	...	...	...	2	2	2	2	2
16	F3592	Rod, footrest	...	...	...	...	1	1	1	1	1
17	DS48	Nut, footrest rod	...	...	...	...	2	2	2	2	2
18	NT316	Dowel, footrest, R.H.	...	...	...	...	4	4	4	4	4
19	F862	Distance tube, engine plate	...	...	...	...	1	1	1	1	1
20	T87	Distance tube, L.H. footrest	...	...	...	...	1	1	1	1	1

PILLION FOOTREST

21	F1694	Pedal, footrest	...	...	...	...	2	2	2	2	2
22	F1695	Rubber, footrest pedal	...	...	...	...	2	2	2	2	2
23	F2271	Bolt, footrest pedal pivot, $\frac{15}{16}$ " U/H	...	...	...	...	2	2	2	2	2
24	SI-51	Nut, footrest pedal pivot bolt	...	...	...	...	2	2	2	2	2
25	F2277	Washer, footrest pedal pivot bolt	...	...	...	...	2	2	2	2	2

GROUP 26 — BATTERY CARRIER AND TOOLBOX

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

BATTERY CARRIER AND TOOLBOX—GROUP 26

BATTERY CASE AND TOOLBOX

1	F3870	Battery case and toolbox assembly ...	...	...	...	1	1	1	1	—
2	F4528	Battery case and toolbox assembly ...	...	...	...	—	—	—	—	1
3	E534	Swivel, carrier strap plain ...	...	...	...	1	1	1	1	1
4	E535	Swivel, carrier strap tapped ...	...	...	...	1	1	1	1	1
5	E536	Bolt, carrier strap swivel, 1 1/8" U/H ...	...	...	...	1	1	1	1	1
6	F3588	Strap, carrier top ...	...	...	...	1	1	1	1	1
7	F1668	Strap, carrier front ...	...	...	...	1	1	1	1	1
8	F1727	Pin, carrier strap hinge ...	...	...	...	2	2	2	2	2
9	F3874	Lid assembly, battery case ...	...	...	...	1	1	1	1	1
10	F3875	Fastener, lid ...	...	...	...	1	1	1	1	1
11	F3227	Grommet, lid fastener ...	...	...	...	1	1	1	1	1
12	F3641	Stud, carrier to seat tube boss, 1/8" O/A ...	...	...	...	1	1	1	1	1
13	F1008	Nut, carrier to seat tube boss stud ...	...	...	...	1	1	1	1	1
14	S26-3	Washer, carrier to seat tube boss stud ...	...	...	...	1	1	1	1	1
15	F1699	Clip, battery case to frame ...	...	...	...	1	1	1	1	1
16	DS57	Bolt, battery case to frame clip, 7/16" U/H ...	...	...	...	1	1	1	1	1
17	F879	Nut, battery case to frame clip ...	...	...	...	1	1	1	1	1
18	E1612	Washer, battery case to frame clip ...	...	...	...	1	1	1	1	1
19	A57	Transfer, "Bonneville 120" ...	...	...	...	—	—	—	—	1

For securing bolt, nut and washer, Toolbox/Battery case to rear engine plate, see Rear Mudguard Group, page 70.

DESPATCHING GOODS. Parts being returned to either the Distributor or Triumph Service Department for rectification should be well packed to avoid damage in transit. Cylinder barrels and cylinder heads are extremely vulnerable to breakage of the fins ; when casing, pack straw or old newspapers, etc., round the finning to prevent damage due to shock. Advice of despatch should be forwarded to the consignee and the sender **MUST** securely attach a label to the returned parts, clearly stating his name and address.

RECEIVING GOODS. Every possible precaution is taken to ensure that the sender's order has been correctly interpreted and the goods despatched are correct to the invoice. Parts sent in for repair are tested before despatch and are subsequently covered by our guarantee on Page 115. In the event of any shortage or damage in transit, we must be advised within 48 hours of arrival in order that the necessary action can be taken. No claim can be entertained after this period.




FIG. 26. BATTERY CARRIER AND TOOL BOX

INDEX FIG. 26

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	F3870	84	1	5	F3588	84	6
	F4528	84	2	6	F1668	84	7
2	E534	84	3	7	F1727	84	8
3	E535	84	4	8	F3874	84	9
4	E536	84	5	9	F3875	84	10

GROUP 27 – TOOLKIT

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

TOOLKIT—GROUP 27

1	D.365	Toolkit, complete	...	...	...	...	...					
2	WA.58	Roll, canvas tool ...	...	...	...	...	...					
3	D.360	Spanner, open $\frac{1}{8}$ " $\times$ $\frac{5}{16}$ " Whit.	...	...	...	...	...					
4	D.361	Spanner, open $\frac{3}{16}$ " $\times$ $\frac{1}{2}$ " Whit.	...	...	...	...	...					
5	NA.55	Spanner, open $\frac{1}{4}$ " $\times$ $\frac{5}{16}$ " Whit.	...	...	...	...	...					
6	DA.16	Spanner, open $\frac{3}{8}$ " $\times$ $\frac{7}{16}$ " Whit.	...	...	...	...	...					
7	PA.57	Spanner, closed $\frac{1}{2}$ " $\times$ $\frac{9}{16}$ " Whit.	...	...	...	...	...					
8	D.311	Spanner, closed $\frac{5}{8}$ " $\times$ $\frac{11}{16}$ " Whit.	...	...	...	...	...					
9	D.362	"C" Spanner and Tappet Key	...	...	...	...	...					
10	D.87	Box spanner, plugs	...	...	...	...	...					
11	D.363	Tyre lever and screw driver	...	...	...	...	...					
12	D.364	Tyre lever and clutch key	...	...	...	...	...					
13	DA.50/1	Extractor, clutch hub	...	...	...	...	...					
14	D.336	Screwdriver, Phillips No. 3	...	...	...	...	...					
15	415116	Spanner, magneto points	...	...	...	...	...	—				
16	400935	Screwdriver, distributor points	...	...	...	...	...		—	—	—	—
17	D.49	Tyre inflator (not in kit)	...	...	...	...	...					
18	D.220	Spanner, fork cap nuts (not in kit)	...	...	...	...	...	A	A	A	A	A
19	167	Extractor, chain rivet (not in kit)	...	...	...	...	...	A	A	A	A	A

SPECIAL WORKSHOP TOOLS

A COMPLETE LIST OF WORKSHOP TOOLS CAN BE MADE AVAILABLE BY EITHER CONTACTING YOUR DEALER OR APPLYING DIRECT TO THE TRIUMPH SERVICE DEPARTMENT. IN MOST CASES THESE TOOLS ARE VERY COSTLY AS THEY ARE MADE ENTIRELY FOR WORKSHOP USE, AND THEREFORE, IT IS NOT RECOMMENDED THAT THE PRIVATE OWNER PURCHASES THE TOOLS IN ORDER TO AID SERVICING THE MACHINE ONCE OR TWICE ONLY. IN THESE CIRCUMSTANCES IT IS FAR MORE ECONOMICAL TO GET IN TOUCH WITH A RECOGNISED DEALER.




FIG. 27. TOOL KIT

GROUP 28 – AIR FILTER




FIG. 28. AIR FILTER

INDEX FIG. 28

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	F3857	88	1	4	E2312	88	4
2	F3315E	88	2	5	F3859	88	6
3	F3376	88	3	6	F3858	88	5

AIR FILTER — GROUP 28
LEGSHIELD — GROUP 29
SIDECAR FITTINGS — GROUP 30

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

AIR FILTER—GROUP 28

1	F3857	Air filter assembly	...	...	...	...	...	1	1	1	1	—
2	F3315E	Element only	...	...	...	...	...	1	1	1	1	—
3	F3376	Screw, cover $\frac{3}{8}$ " U/H	...	...	...	...	...	1	1	1	1	—
4	E2312	Washer, serrated	...	...	...	...	...	1	1	1	1	—
5	F3858	Connection, rubber	...	...	...	...	...	1	1	1	1	—
6	F3859	Clip, at carburetter	...	...	...	...	...	1	1	1	1	—

LEGSHIELD—GROUP 29

7	F3208	Legshield, L.H.	...	...	...	...	...	1	1	1	1	1
8	F3894	Legshield, R.H.	...	...	...	...	...	1	1	1	1	1
9	F3326	Stay, legshield	...	...	...	...	...	2	2	2	2	2
10	E1598	Clip, front down tube	...	...	...	...	...	1	1	1	1	1
11	F1031	Bolt, stay to clip, $\frac{15}{16}$ " U/H	...	...	...	...	...	1	1	1	1	1
12	PO172A	Nut, stay to clip bolt	...	...	...	...	...	1	1	1	1	1
13	S25-2	Washer, stay to clip bolt	...	...	...	...	...	1	1	1	1	1
14	DS57	Bolt, stay to legshield, $\frac{7}{16}$ " U/H	...	...	...	...	...	4	4	4	4	4
15	F879	Nut, stay to legshield bolt	...	...	...	...	...	4	4	4	4	4
16	S26-2	Washer, stay to legshield bolt	...	...	...	...	...	4	4	4	4	4

SIDECAR FITTINGS—GROUP 30

17	F2587	Lug, lower front connection	...	...	...	...	...	1	1	1	1	—
18	F1746	Sleeve nut, lug to frame	...	...	...	...	...	2	2	2	2	—
19	F2600	Bolt, lower front lug	...	...	...	...	...	1	1	1	1	—
20	F1747	Nut, lower front lug bolt	...	...	...	...	...	1	1	1	1	—

PROPRIETARY GROUP

PROPRIETARY GROUP

Ancillary equipment which is fitted to our motor cycles is of the highest quality and is guaranteed by the manufacturers and not by ourselves. Any repairs or claims should be made to the actual maker who will always give owners every possible assistance. The following are the addresses of the various manufacturers:-

CARBURETTORS	Messrs. Amal Ltd., Holdford Road, Witton, Birmingham, 6.
CHAINS	Renold Chains Ltd., Wythenshawe, Manchester.
ELECTRICAL EQUIPMENT ...	Messrs. J. Lucas, Ltd., Gt. Hampton Street, Birmingham, 18.
SPARKING PLUGS	Champion Sparking Plug Co. Ltd., Feltham, Middlesex. K.L.G. Sparking Plugs Ltd., Cricklewood Works, London, N.W.2. Lodge Plugs Ltd., Rugby, Warwickshire.
SPEEDOMETERS	Messrs. Smiths Motor Accessories Ltd., Cricklewood Works, London, N.W.2.
SUSPENSION UNITS	Messrs. Girling Ltd., Kings Road, Tyseley, Birmingham, 11.
TYRES	Dunlop Rubber Co. Ltd., Fort Dunlop, Birmingham, 24.

REF. No. PART No. DESCRIPTION 6T T100 T110 TR6 T120

AMAL CARBURETTER—GROUP 31

1	376/210	Carburetter complete ...	...	...	...	...	1	—	—	—	—
2	376/35	Carburetter complete ...	...	...	...	...	—	1	—	—	—
3	376/40	Carburetter complete ...	...	...	...	...	—	—	1	1	—
4	376/204	Mixing chamber assembly ...	...	...	...	...	—	—	—	—	2
5	376/003	Chamber, mixing $1\frac{1}{8}$ " choke ...	...	...	...	...	1	—	1	1	—
6	376/001	Chamber, mixing $\frac{15}{16}$ " choke ...	...	...	...	...	—	1	—	—	—
7	376/030	Chamber, mixing $1\frac{1}{8}$ " choke ...	...	...	...	...	—	—	—	—	2
8	376/107	Top, mixing chamber ...	...	...	...	...	1	1	1	1	2
9	376/065	Cap, mixing chamber ...	...	...	...	...	1	1	1	1	2
10	4/276	Spring, mixing chamber cap ...	...	...	...	...	1	1	1	1	2
11	4/241	Screw, cap spring ...	...	...	...	...	1	1	1	1	2
12	4/137A	Screw, plus ...	...	...	...	...	—	—	—	—	2
13	376/062	Valve, air ...	...	...	...	...	1	1	1	1	—
14	4/046	Spring, air valve ...	...	...	...	...	1	1	1	1	—
15	6/047	Guide, air valve ...	...	...	...	...	1	1	1	1	—
16	376/060	Valve, throttle ($3\frac{1}{2}$ cutaway) ...	...	...	...	...	1	1	1	1	2
17	376/061	Spring, throttle valve ...	...	...	...	...	1	1	1	1	—
18	376/132	Spring, throttle valve ...	...	...	...	...	—	—	—	—	2
19	376/068	Screw, throttle stop ...	...	...	...	...	1	1	1	1	2
20	376/069	Spring, throttle stop screw ...	...	...	...	...	1	1	1	1	2
21	332/017	Screw, air adjusting ...	...	...	...	...	1	1	1	1	2
22	4/148	Spring, air adjusting screw ...	...	...	...	...	1	1	1	1	2
23	376/100	Jet, main (220) ...	...	...	...	...	—	1	—	—	—
	376/100	Jet, main (240) ...	...	...	...	...	—	—	—	—	2
	376/100	Jet, main (250) ..	...	...	...	...	—	—	1	1	—
	376/100	Jet, main (270) ...	...	...	...	...	1	—	—	—	—
24	376/057	Block, jet, $1\frac{1}{8}$ " choke ...	...	...	...	...	1	—	1	1	2
25	376/055	Block, jet, $\frac{15}{16}$ " choke ...	...	...	...	...	—	1	—	—	—
26	376/070	Peg, jet block locating ...	...	...	...	...	1	1	1	1	2
27	376/067	Washer, jet block ...	...	...	...	...	1	1	1	1	2
28	376/073	Holder, main jet ...	...	...	...	...	1	1	1	1	—
29	376/140	Holder, main jet ...	...	...	...	...	—	—	—	—	2
30	376/074	Washer, jet holder ...	...	...	...	...	1	1	1	1	4
31	376/141	Banjo, petrol inlet ...	...	...	...	...	—	—	—	—	2
32	376/075	Nut, main jet cover ...	...	...	...	...	1	1	1	1	2
33	376/072	Jet, needle (·1065) ...	...	...	...	...	1	1	1	1	2
34	376/063	Needle, jet (type C) ...	...	...	...	...	1	1	1	1	2
35	4/230	Clip, jet needle ...	...	...	...	...	1	1	1	1	2
36	376/076	Jet, pilot (25) ...	...	...	...	...	1	1	1	1	2

GROUP 31 - AMAL CARBURETTER




FIG. 29. AMAL CARBURETTER

INDEX FIG. 29

<i>Illust. No.</i>	<i>Part No.</i>	<i>Page No.</i>	<i>Ref. No.</i>
1	376/107	91	8
2	376/065	91	9
3	4/276	91	10
4	4/241	91	11
5	376/061	91	17
	376/132	91	18
6	376/060	91	16
7	376/063	91	34
8	376/003	91	5
	376/001	91	6
	376/030	91	7
9	244/1048	94	22
10	332/017	91	21
11	376/070	91	26
12	376/072	91	33
13	376/068	91	19
14	376/076	91	36
15	376/095	94	2
16	376/073	91	28
	376/140	91	29
17	376/100	91	23
18	375/075	91	32
19	376/057	91	24
	376/055	91	25
20	376/091	94	15
21	F4450	71	40
22	376/093	94	14
24	376/066	94	27
25	376/088	94	13
26	376/077	94	5
27	376/079	94	7
	376/151	94	8
28	376/094	94	11
29	376/083	94	9
30	376/089	94	12

GROUP 31 — AMAL CARBURETTER

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	116/162	Washer, pilot jet cover nut					2
2	376/095	Nut, pilot jet cover					2
3	4/035	Adjuster, air cable					—
4	6/132A	Ferrule, throttle cable					2
5	376/077	Cover, float chamber					2
6	376/078	Washer, cover joint					2
7	376/079	Screw, float chamber cover	3	3	3	3	—
8	376/151	Screw, float chamber cover	—	—	—	—	6
9	376/083	Float					—
10	376/085	Spindle, float hinge					—
11	376/094	Bush, float spindle					—
12	376/089	Needle, valve					—
13	376/088	Seating, valve needle					—
14	376/093	Gauge, filter					—
15	376/091	Bolt, banjo					—
16	376/092	Washer, banjo bolt					—
17	376/086	Tickler					—
18	343/011	Body, tickler					—
19	376/087	Spring, tickler					—
20	NA43A	Washer, insulating block to manifold	—				—
21	E2968	Block, insulating	—				—
22	244/1048	“O” ring seal, carburetter					2
23	F2603	Bolt, carburetter to head	—	—	—	—	4
24	S25-3	Washer, plain	—	—	—	—	4
25	S26-3	Washer, spring	—	—	—	—	4
26	S1-51	Nut, carburetter bolt	—	—	—	—	4
27	376/066	Tube, air intake (For use when air filter is disconnected)	A	A	A	A	2
28	14/617	Float chamber, complete	—	—	—	—	
29	14/363	Body, float chamber	—	—	—	—	
30	14/297	Cover, float chamber	—	—	—	—	
31	14/366	Needle, float	—	—	—	—	
32	14/017	Float	—	—	—	—	
33	161/054	Clip, float needle	—	—	—	—	
34	14/209	Tickler	—	—	—	—	
35	14/210	Stop, tickler	—	—	—	—	
36	14/032	Spring, tickler	—	—	—	—	
37	14/289	Cotter, tickler	—	—	—	—	

AMAL CARBURETTER — GROUP 31

CHAINS — GROUP 32

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	14/219	Union, outlet	—	—	—	—	1
2	14/336	Washer, fibre	—	—	—	—	1
3	14/173	Banjo, outlet	—	—	—	—	1
4	14/036	Nut, banjo	—	—	—	—	1
5	14/037	Washer, banjo	—	—	—	—	2

CARBURETTER FITTINGS

6	F3746	Clip, float chamber	—	—	—	—	1
7	TE164E	Bolt, clip	—	—	—	—	1
8	TE164C	"D" nut	—	—	—	—	1
9	TE164D	"D" washer	—	—	—	—	1
10	F3740	Block, float chamber mounting	—	—	—	—	1
11	F3745	Clip, block to frame	—	—	—	—	2
12	F1149	Bolt, clip	—	—	—	—	2
13	E1612	Washer, serrated	—	—	—	—	2
14	F879	Nut	—	—	—	—	2
15	F4539	Petrol pipe assembly (lines 16-20)	—	—	—	—	2
16	F4525	Petrol pipe, rubber	—	—	—	—	2
17	F3353	Elbow, obtuse	—	—	—	—	2
18	F3335	Elbow 90°	—	—	—	—	2
19	F3337	Nut, union	—	—	—	—	4
20	E4035	Clip	—	—	—	—	4
21	F4540	Petrol pipe assembly (lines 22-24)	—	—	—	—	1
22	F4526	Petrol pipe, rubber	—	—	—	—	3
23	F4356	"T" piece, steel	—	—	—	—	1
24	E4035	Clip	—	—	—	—	6

CHAINS—GROUP 32

25	D301	Chain, primary 70L × $\frac{1}{2}$ " × $\frac{5}{16}$ " (solo)	1	1	1	1	1
26	D304	Chain, rear 100L × $\frac{5}{8}$ " × $\frac{3}{8}$ "	—	1	—	—	—
27	D310	Chain, rear 101L × $\frac{5}{8}$ " × $\frac{3}{8}$ "	1	—	1	1	1
28	110046/49	Kit, primary, chain spare parts	1	1	1	1	1
29	110056/59	Kit, rear, chain spare parts	1	1	1	1	1

When replacing primary chain use 68 links for 500 c.c. sidecar machines.

GROUP 33 — LUCAS LIGHTING AND IGNITION EQUIPMENT (DYNAMO AND MAGNETO)

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

LUCAS LIGHTING AND IGNITION EQUIPMENT—GROUP 33

(For Models fitted with Dynamo and Magneto)

DYNAMO (TYPE E3L-L10)

1	20035A	Dynamo complete (positive earth)	...	...	...	—	1	1	1	1
2	200712	Armature	...	...	...	—	1	1	1	1
3	200911	Insulating plate with brush boxes	...	...	...	—	1	1	1	1
4	200910	Bracket, commutator end	...	...	...	—	1	1	1	1
5	189210	Bearing, commutator end	...	...	...	—	1	1	1	1
6	200918	Cover, commutator end	...	...	...	—	1	1	1	1
7	200904	Ring, sealing commutator end	...	...	...	—	1	1	1	1
8	200748	Plate, drive and oil seal end	...	...	...	—	1	1	1	1
9	200760	Bracket, drive and oil seal end...	...	...	...	—	1	1	1	1
10	189307	Bearing, drive and oil seal end	...	...	...	—	1	1	1	1
11	200731	Coil, field	...	...	...	—	1	1	1	1
12	188818	Nipple, cable fixing	...	...	...	—	2	2	2	2
13	200908	Plate, cable clamp	...	...	...	—	1	1	1	1
14	109660	Screw, cable clamp plate	...	...	...	—	1	1	1	1
15	200732	Bolt, through fixing	...	...	...	—	2	2	2	2
16	166014	Nut, through fixing bolt	...	...	...	—	2	2	2	2
17	188330	Washer, through fixing bolt	...	...	...	—	2	2	2	2
18	200737	Brush set	...	...	...	—	1	1	1	1
19	220197	Spring set, brush	...	...	...	—	1	1	1	1
20	189386	Key, woodruff	...	...	...	—	1	1	1	1
21	E2451	Pinion, dynamo	...	...	...	—	1	1	1	1
22	111704	Screw, dynamo pinion	...	...	...	—	1	1	1	1
23	188378	Washer, dynamo pinion	...	...	...	—	1	1	1	1
24	E2228	Nut (dome), dynamo to gear case	...	...	...	—	1	1	1	1
25	E2414	Stud, dynamo fixing 1½" O/A	...	...	...	—	1	1	1	1
26	E2226	Washer, dynamo to crankcase joint	...	...	...	—	1	1	1	1
27	E2230	Strap, dynamo fixing	...	...	...	—	1	1	1	1
28	460025	Swivel, dynamo strap	...	...	...	—	2	2	2	2
29	112450	Screw, dynamo strap	...	...	...	—	2	2	2	2
30	E2784	Cover plate, crankcase (when dynamo is removed)	...	...	...	—	1	1	1	1
31	200895	Grommet, harness lead	...	...	...	—	1	1	1	1

CUT-OUT AND REGULATOR UNIT (TYPE RB107)

32	37225H	Regulator, complete	...	...	...	—	1	1	1	1
33	F1369	Bolt, unit to rear stays ⅝" U/H	...	...	...	—	2	2	2	2
34	F879	Nut, for F1369	...	...	...	—	2	2	2	2
35	E1612	Washer, for F879	...	...	...	—	2	2	2	2

LUCAS LIGHTING AND IGNITION EQUIPMENT – GROUP 33 (DYNAMO AND MAGNETO)

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

HEADLAMP (NACELLE TYPE MCF700P)

1	51860A	Headlamp assembly	—	1	1	—	1
2	553248	Rim, front	—	1	1	—	1
3	534296	Screw and plate, front rim fixing	—	1	1	—	1
4	555309	Glass and reflector unit	—	1	1	—	1
5	553267	Ring, lamp fixing... ..	—	1	1	—	1
6	554602	Adaptor, bulb	—	1	1	—	1
7	504665	Fixing wire, light unit	—	6	6	—	6
8	373	Bulb, pre-focus 30/24W (L.H. Dipping)	—	1	1	—	1
9	554710	Pilot bulbholder	—	1	1	—	1
10	988	Bulb, pilot 3W	—	1	1	—	1
11	H689	Screw, lamp fixing ring $\frac{1}{4}$ " U/H	—	2	2	—	2
12	H690	Nut, lamp fixing ring screw	—	2	2	—	2

HEADLAMP (TROPHY)

13	51892A	Headlamp assembly	—	—	—	1	—
14	553248	Rim, front	—	—	—	1	—
15	534296	Screw and plate, front rim fixing	—	—	—	1	—
16	516798	Glass and reflector unit	—	—	—	1	—
17	554602	Adaptor, bulb	—	—	—	1	—
18	504665	Fixing wire, light unit	—	—	—	6	—
19	312	Bulb, pre-focus 30/24W	—	—	—	1	—
20	554710	Pilot bulbholder	—	—	—	1	—
21	988	Bulb, pilot 3W	—	—	—	1	—
22	859260/809795	Plug and Socket	—	—	—	1	—
23	36084	Ammeter	—	—	—	1	—
24	31315	Switch, light	—	—	—	1	—
25	308312	Panel, instrument	—	—	—	1	—
26	516183	Beading, instrument panel	—	—	—	1	—
27	186130	Screw, instrument panel	—	—	—	4	—
28	188818	Nipple, cable fixing	—	—	—	1	—

HORN (TYPE HF1441)

29	70048A	Horn, complete	—	1	1	1	1
30	701851	Bracket, horn	—	2	2	2	2
31	F3689	Bracket, horn (saddle stud fitting)	—	—	—	1	—
32	700920	Bracket, horn angle	—	1	1	—	1
33	142689	Screw, horn bracket	—	2	2	—	2
34	185051	Washer, horn bracket	—	2	2	—	2
35	DS57	Bolt, horn bracket to lug $\frac{7}{16}$ " U/H	—	2	2	—	2
36	S26-2	Washer, horn bracket to lug	—	2	2	—	2
37	H687	Screw, mounting bracket $\frac{3}{8}$ " U/H	—	—	—	2	—
38	GS299	Washer, bracket screw	—	—	—	2	—
39	H745	Nut, bracket screw	—	—	—	2	—

GROUP 33 — LUCAS LIGHTING AND IGNITION EQUIPMENT **(DYNAMO AND MAGNETO)**




FIG. 30. HEAD LAMP

INDEX FOR DYNAMO CONDITION

INDEX FOR "D.C." CONDITION (T100, T110, TR5 & TR6)

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	553248	97	2	4	554602	97	6
2	555309	97	4	5	534296	97	3
	516798	97	16	6	553267	97	5
3	373	97	8	7	504665	97	7
	312	97	19				

INDEX FOR "AC" CONDITION (5T & 6T)

Illust. No.	Part No.	Page No.	Ref. No.	Illust. No.	Part No.	Page No.	Ref. No.
1	553248	105	15	5	534296	105	16
2	555309	105	17	6	553267	105	18
3	373	105	21	7	504665	105	20
4	554602	105	19				

LUCAS LIGHTING AND IGNITION EQUIPMENT — GROUP 33 (DYNAMO AND MAGNETO)

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

TAIL LAMP (STOP LIGHT PATTERN WITH INTEGRAL REFLECTORS) TYPE 564

1	53432B	Stop and tail lamp	...	...	...	...	—	1	1	1	1
2	573839	Lens	...	...	...	...	—	1	1	1	1
3	575200	Window	...	...	...	...	—	1	1	1	1
4	575208	Gasket, lens seating	...	...	...	...	—	1	1	1	1
5	575219	Nut, lens retaining	...	...	...	...	—	2	2	2	2
6	576002	Base assembly	...	...	...	...	—	1	1	1	1
7	575209	Bulbholder assembly	...	...	...	...	—	1	1	1	1
8	575207	Grommet, bulbholder	...	...	...	...	—	1	1	1	1
9	573828	Contact assembly	...	...	...	...	—	1	1	1	1
10	573825	Grommet, cable	...	...	...	...	—	1	1	1	1
11	384	Bulb 6/18w offset pin	...	...	...	...	—	1	1	1	1
12	31383	Switch, stop lamp	...	...	...	...	—	1	1	1	1
13	H687	Screw, switch fixing $\frac{3}{4}$ " U/H	...	...	...	...	—	2	2	2	2
14	GS299	Washer, fixing screw	...	...	...	...	—	2	2	2	2

WIRING HARNESS

15	836381	Wiring harness	...	...	...	...	—	1	1	—	1
16	831200	Wiring harness	...	...	...	...	—	—	—	1	—
17	838604	Lead, twin stop/tail lamp	...	...	...	...	—	1	1	1	1

NACELLE INSTRUMENT PANEL

18	31371B	Switch, lighting	...	...	...	...	—	1	1	—	1
19	351567	Lever and screw, switch	...	...	...	...	—	1	1	—	1
20	36129A	Ammeter	...	...	...	...	—	1	1	—	1
21	31071B	Button, cut-out	...	...	...	...	—	1	1	—	1

HANDLEBAR SWITCHES AND PUSHBUTTONS

22	31563A	Switch, dipper and horn push	...	...	...	...	—	1	1	1	1
23	863082	Cable (4 core), dipper and horn push	...	...	...	...	—	1	1	1	1
24	H689	Screw, switch to lever clamp $\frac{1}{4}$ " U/H	...	...	...	...	—	2	2	2	2
25	76200A	Button, cut out	...	...	...	...	—	—	—	1	—

BATTERY (TYPE PU7E-9)

26	PU7E-9	Battery	...	...	...	...	—	1	1	1	1
27	4179504	Plug, vent	...	...	...	...	—	3	3	3	3
28	4189048	Connection, battery lead "+"	...	...	...	...	—	1	1	1	1
29	4189040	Connection, battery lead "—"	...	...	...	...	—	1	1	1	1
30	4188743	Socket, connection "+"	...	...	...	...	—	1	1	1	1
31	4188744	Socket, connection "—"	...	...	...	...	—	1	1	1	1

GROUP 33 — LUCAS LIGHTING AND IGNITION EQUIPMENT (DYNAMO AND MAGNETO)

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

MAGNETO

1	42298	Magneto, K2F manual advance and retard	...	...	—	I	I	I	I
2	42344	Magneto, K2F auto advance and retard	...	...	—	A	A	A	A
3	42350	Magneto, K2FC manual advance and retard	...	...	—	A	A	A	A
4	42368	Magneto, K2FC auto advance and retard	...	...	—	A	A	A	A
5	43234	Magneto, K2FR (racing)	...	...	—	A	A	A	A

MAGNETO PARTS

				Magneto Ref. No.		1	2	3	4	5
6	458876	Pick up with brush and spring	...	...	...	2	2	2	2	2
7	458877	Washer, pick up seating	...	...	...	2	2	2	2	2
8	451260	Brush and spring	...	...	...	2	2	2	2	2
9	410600	Nut, moulded	...	...	...	2	2	2	2	2
10	145074	Screw, pick-up fixing	...	...	...	4	4	4	4	4
11	458658	Grommet, rubber	...	...	...	2	2	2	2	2
12	459269	Cover, assembly contact breaker	...	...	...	1	1	—	—	—
13	459266	Cap moulded, breather	...	...	...	1	1	—	—	—
14	459888	Terminal assembly	...	...	...	1	1	—	—	—
15	459205	Cover assembly, contact breather	...	...	...	—	—	1	1	1
16	459194	Cap, breather	...	...	...	—	—	1	1	1
17	455190	Brush and spring	...	...	...	1	1	1	1	1
18	457681	Cover washer, rubber	...	...	...	1	1	1	1	1
19	122160	Screw, contact breaker fixing	...	...	...	1	1	1	1	1
20	470534	Contact breaker	...	...	...	1	1	1	1	—
21	470609	Contact set	...	...	...	1	1	1	1	—
22	470914	Contact breaker	...	...	...	—	—	—	—	1
23	470688	Spring, set, contact actuating	...	...	...	1	1	1	1	—
24	470537	Brush and spring, C.B. earthing	...	...	...	1	1	1	1	1
25	492195	Control parts set	...	...	...	1	—	—	—	—
26	459305	Control parts set	...	...	...	—	—	1	—	—
27	457117	Control parts set	...	...	...	—	—	—	—	1
28	454475	Cap, rubber	...	...	...	1	—	1	—	1
29	458725	Cam	...	...	...	1	—	1	—	—
30	459130	Cam	...	...	...	—	1	—	1	—
31	459271	End plate with bearing ring	...	...	...	1	—	1	—	—
32	493716	End plate with bearing ring	...	...	...	—	1	—	1	—
33	463932	Cup, bearing insulating	...	...	...	1	1	1	1	—
34	150509	Screw, end plate fixing	...	...	...	3	3	3	3	—
35	185048	Spring washer, fixing screw	...	...	...	3	3	3	3	—
36	452907	Shim, .005", end plate packing	...	...	...	As required				

LUCAS LIGHTING AND IGNITION EQUIPMENT — GROUP 33 (DYNAMO AND MAGNETO)

REF. No.	PART No.	MAGNETO REF. No. (see opposite page)	1	2	3	4	5
1	459004	Armature			—	—	—
2	459376	Armature	—	—			—
3	455361	Slip ring			—	—	—
4	456727	Slip ring	—	—			—
5	458339	Condenser			—	—	—
6	189294	Bearing, C.B. end					—
7	189244	Bearing, drive end					—
8	459005	Cup, drive bearing insulating					—
9	459002	Oil seal					—
10	455191	Brush, spring and holder, earthing					
11	455190	Brush and spring, earthing					
12	458675	Sundry parts set					—
13	458869	Sundry parts set	—	—	—	—	
14	47502	Auto advance unit complete	As required				
15	E2741	Gear magneto, fixed					
16	170104	Nut, magneto gear, $\frac{3}{8}$ " std.					
17	E1330	Washer, magneto gear, $\frac{3}{8}$ " std.					

With the exception of the parts listed above, no spares are supplied separately for the racing magneto 42324. For repair it should be returned to :—

**RACING DEPARTMENT,
JOSEPH LUCAS (SALES & SERVICE) LTD.,
GREAT HAMPTON STREET,
BIRMINGHAM, 18.**

GROUP 33 — LUCAS LIGHTING AND IGNITION EQUIPMENT (DYNAMO AND MAGNETO)

INDEX FIG. 31

<i>Illust. No.</i>	<i>Part No.</i>	<i>Page No.</i>	<i>Ref. No.</i>
2	458876	100	6
3	458876	100	6
4	458877	100	7
5	451260	100	8
6	410600	100	9
7	145074	100	10
8	458658	100	11
9	459269	100	12
	459205	100	15
10	459888	100	14
11	459266	100	13
12	455190	100	17
13	457681	100	18
14	122160	100	19
15	470534	100	20
	470914	100	22
16	470609	100	21
17	470688	100	23
18	470537	100	24
19	492195	100	25
	459305	100	26
	457117	100	27
20	454475	100	28
21	458725	100	29
	459130	100	30
22	459271	100	31
	493716	100	32
23	463932	100	33
24	150509	100	34
25	185048	100	35
26	452907	100	36
27	459004	101	1
	459376	101	2
28	455361	101	3
	456727	101	4
29	458339	101	5
30	189294	101	6
31	189244	101	7
32	459005	101	8
33	459002	101	9
34	455191	101	10
35	455190	101	11

LUCAS LIGHTING AND IGNITION EQUIPMENT — GROUP 33 **(DYNAMO AND MAGNETO)**




FIG. 31. LUCAS MAGNETO

GROUP 34 — LUCAS LIGHTING AND IGNITION EQUIPMENT (ALTERNATOR)

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
----------	----------	-------------	----	------	------	-----	------

LUCAS LIGHTING AND IGNITION EQUIPMENT—GROUP 34

ALTERNATOR RM15

1	423506	Rotor	1	—	—	—	—
2	469427	Stator assembly	1	—	—	—	—
3	862898	Cable only, alternator output	1	—	—	—	—
4	E3978	Adaptor, stator to crankcase	1	—	—	—	—
5	E3979	Screw, adaptor to crankcase	3	—	—	—	—
6	E3980	Stud, stator fixing	3	—	—	—	—
7	S1-51	Nut, stator fixing	3	—	—	—	—
8	S25-3	Washer, plain	3	—	—	—	—
9	E3116	Washer, rotor backing	1	—	—	—	—
10	E3974	Key, rotor	1	—	—	—	—
11	E3975	Tab washer	1	—	—	—	—
12	E3977	Nut, sprocket and rotor	1	—	—	—	—

RECTIFIER (TYPE FSW1500A)

13	4711A	Rectifier	1	—	—	—	—
14	F3620	Bracket, rectifier fixing	1	—	—	—	—
15	DS57	Bolt, rectifier, front and rear, $\frac{7}{16}$ " U/H	3	—	—	—	—
16	F879	Nut, rectifier rear bolt	2	—	—	—	—
17	E1612	Washer, rectifier bolt	3	—	—	—	—
18	F3600	Nut, rectifier to bracket	1	—	—	—	—

IGNITION COIL (TYPE MA6)

19	45077A	Ignition coil	1	—	—	—	—
20	421863	Clip, H.T. terminal	1	—	—	—	—
21	E3111	Bracket, coil mounting	1	—	—	—	—
22	DS57	Bolt, coil to bracket, $\frac{7}{16}$ " U/H	2	—	—	—	—
23	F879	Nut, coil to bracket bolt	2	—	—	—	—
24	E2312	Washer, coil to bracket bolt	2	—	—	—	—
25	422567	Rubber cover, H.T. lead	1	—	—	—	—
26	236741	Rubber cover, L.T. lead	2	—	—	—	—

DISTRIBUTOR

27	40449A	Distributor model DKX2A (12½° range)	1	—	—	—	—
28	406105	Plate assembly	1	—	—	—	—
29	400136	Cap, distributor	1	—	—	—	—
30	404435	Brush and spring	1	—	—	—	—
31	400052	Rotor arm	1	—	—	—	—
32	400308	Condenser	1	—	—	—	—
33	400415	Contact set	1	—	—	—	—
34	415283	Cam	1	—	—	—	—
35	416031/S	Springs auto advance set	1	—	—	—	—
36	415730	Weight assembly	1	—	—	—	—

LUCAS LIGHTING AND IGNITION EQUIPMENT (ALTERNATOR) — GROUP 34

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	400001	Base only, distributor	1	—	—	—	—
2	400164	Base c/w contact points	1	—	—	—	—
3	421935	Shaft and action plate	1	—	—	—	—
4	420406	Bushing	1	—	—	—	—
5	400843	Sundry parts set	1	—	—	—	—
6	407131	Toggle	1	—	—	—	—
7	410591	Clip, cover retaining	1	—	—	—	—
8	E3122	Adaptor, distributor to crankcase	1	—	—	—	—
9	SI-51	Nut, distributor to crankcase	3	—	—	—	—
10	PCE102F	Bolt, distributor clamp	1	—	—	—	—
11	E2312	Washer, distributor clamp	1	—	—	—	—
12	E3303	Cover, distributor protective	1	—	—	—	—

HEADLAMP (NACELLE TYPE MCF700P)

13	51860A	Headlamp assembly	1	—	—	—	—
14	553248	Rim, front	1	—	—	—	—
15	534296	Screw and plate, front rim fixing	1	—	—	—	—
16	555309	Glass and reflector unit	1	—	—	—	—
17	553267	Ring, lamp fixing... ..	1	—	—	—	—
18	554602	Adaptor, bulb	1	—	—	—	—
19	504665	Fixing wire, light unit	6	—	—	—	—
20	373	Bulb, pre-focus 30/24W (L.H. dipping)	1	—	—	—	—
21	554710	Pilot bulbholder	1	—	—	—	—
22	988	Bulb, pilot 3W.	1	—	—	—	—
23	H689	Screw, lamp fixing ring $\frac{1}{4}$ " U/H	2	—	—	—	—
24	H690	Nut, lamp fixing ring screw	2	—	—	—	—

TAIL LAMP (STOP LIGHT PATTERN WITH INTEGRAL REFLECTORS) TYPE 564

25	53432B	Stop and tail lamp	1	—	—	—	—
26	573839	Lens	1	—	—	—	—
27	575200	Window	1	—	—	—	—
28	575208	Gasket, lens seating	1	—	—	—	—
29	575219	Nut, lens retaining	2	—	—	—	—
30	576002	Base assembly	1	—	—	—	—
31	575209	Bulbholder assembly	1	—	—	—	—
32	575207	Grommet, bulbholder	1	—	—	—	—
33	573828	Contact assembly	1	—	—	—	—
34	573825	Grommet, cable	1	—	—	—	—
35	384	Bulb 3/18W. offset pin	1	—	—	—	—
36	31383	Switch, stop lamp	1	—	—	—	—
37	H687	Screw, switch fixing $\frac{3}{8}$ " U/H	2	—	—	—	—
38	GS299	Washer, fixing screw	2	—	—	—	—

GROUP 34 – LUCAS LIGHTING AND IGNITION EQUIPMENT (ALTERNATOR)

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
WIRING HARNESS							
1	838601	Harness, wiring	1	—	—	—	—
2	838604	Lead, twin stop/tail lamp	1	—	—	—	—
3	414965	Grommet, Distributor lead	1	—	—	—	—
4	236741	Grommet, L.T. Coil lead	2	—	—	—	—
5	458658	Grommet, Distributor plug leads	2	—	—	—	—
NACELLE INSTRUMENT PANEL							
6	31443B	Switch, lighting and ignition	1	—	—	—	—
7	318346	Knob, light switch	1	—	—	—	—
8	319333	Screw, knob fixing	1	—	—	—	—
9	318343	Plate, switch position index	1	—	—	—	—
10	318323	Grommet, switch for key	1	—	—	—	—
11	318341	Key, ignition	1	—	—	—	—
12	36189A	Ammeter	1	—	—	—	—
HORN PUSH AND DIPPER SWITCH							
13	31563A	Switch, dipper and horn push	1	—	—	—	—
14	H689	Screw, switch to lever clamp $\frac{1}{4}$ " U/H	2	—	—	—	—
15	863082	Cable (4 core), dipper and horn push	1	—	—	—	—
HORN							
16	70048A	Horn, complete	1	—	—	—	—
17	701851	Bracket, horn	2	—	—	—	—
18	700920	Bracket, horn angle	1	—	—	—	—
19	142689	Screw, horn bracket	2	—	—	—	—
20	185051	Washer, horn bracket	2	—	—	—	—
21	DS57	Bolt, horn bracket to lug $\frac{7}{16}$ " U/H	2	—	—	—	—
22	S26-2	Washer, horn bracket to lug	2	—	—	—	—
BATTERY (TYPE PU7E-9)							
23	PU7E-9	Battery	1	—	—	—	—
24	4179504	Plug, vent	3	—	—	—	—
25	4189048	Connection, battery lead "+"	1	—	—	—	—
26	4189040	Connection, battery lead "—"	1	—	—	—	—
27	4188743	Socket, connection "+"	1	—	—	—	—
28	4188744	Socket, connection "—"	1	—	—	—	—

TWINSEAT — GROUP 35
SPARKING PLUG — GROUP 36
SPEEDOMETER — GROUP 37

REF. No. PART No.

DESCRIPTION

6T T100 T110 TR6 T120

TWINSEAT—GROUP 35

1	F3647	Twinseat, c/w all attachments ...	...	...	1	1	1	—	—
2	F4481	Bracket, auxiliary support, L.H. (U.S.A.)	...	...	1	1	1	—	—
3	F4482	Bracket, auxiliary support, R.H. (U.S.A.)	...	...	1	1	1	—	—
4	F3815	Buffer, rubber (U.S.A.) ...	...	...	2	2	2	—	—
5	F3785	Twinseat, c/w all attachments ...	...	...	—	—	—	1	1
6	F4532	Bracket, auxiliary support (U.S.A.)	...	...	—	—	—	1	1
7	F3815	Buffer, rubber (U.S.A.) ...	...	...	—	—	—	1	1
8	F879	Nut, bracket (U.S.A.) ...	...	...	—	—	—	2	2
9	E2312	Washer, serrated (U.S.A.)	...	...	—	—	—	2	2
10	E2593	Bolt, twinseat to frame, 2 $\frac{9}{16}$ " U/H	...	...	1	1	1	—	1
11	F3066	Bolt, twinseat to frame 3" U/H	...	...	—	—	—	1	—
12	E2287	Washer, front bolt	...	...	1	1	1	1	1
13	S1-51	Nut, front bolt	...	...	1	1	1	2	2
14	F3792	Bracket, rear	...	...	—	—	—	1	1
15	S26-3	Washer, bracket bolt	...	...	—	—	—	2	2
16	F929	Bolt, bracket to pan, $\frac{1}{2}$ " U/H	...	...	—	—	—	2	2
17	F4452	Safety strap, twinseat	...	...	A	A	A	—	—
18	F4361	Safety strap, twinseat	...	...	—	—	—	A	A
19	F4129	Screw, strap to seat	...	...	4	4	4	4	4
20	GS299	Washer, serrated	...	...	4	4	4	4	4
21	H745	Nut, strap screw	...	...	4	4	4	4	4

SPARKING PLUG—GROUP 36

22	L7	Plug, sparking (Champion)	...	...	2	—	—	—	—
23	F80	Plug, sparking (K.L.G.)	...	...	2	—	—	—	—
24	H14	Plug, sparking (Lodge)	...	...	2	—	—	—	—
25	N3	Plug, sparking (Champion)	...	...	—	2	2	2	2
26	FE100	Plug, sparking (K.L.G.)	...	...	—	2	2	2	2
27	HLN	Plug, sparking (Lodge)	...	...	—	2	2	2	2
28	D297	Cover and suppressor, plug	...	...	2	2	2	2	2
29	D262	Cover, plug (U.S.A.)	...	...	2	2	2	2	2

SPEEDOMETER—GROUP 37

30	S467/107/L	Speedometer head, 120 m.p.h.	...	...	1	—	1	—	1
31	S467/99/L	Speedometer head, 120 m.p.h.	...	...	—	1	—	—	—
32	S433/3	Speedometer head, 120 m.p.h.	...	...	—	—	—	1	—
33	S467/47/L	Speedometer head, 180 k.p.h.	...	...	A	—	A	—	A
34	S467/23/L	Speedometer head, 180 k.p.h.	...	...	—	A	—	—	—
35	S433/7/L	Speedometer head, 180 k.p.h.	...	...	—	—	A	A	—
36	SC3304/07	Speedometer head, 240 k.p.h.	...	...	—	—	—	—	A
37	S467/91/L	Speedometer head, 120 m.p.h.	...	...	A	A	A	—	A

For non-standard engine sprockets (no r.p.m. calibration)

GROUP 37 — SPEEDOMETER

GROUP 38 — SUSPENSION UNIT

REF. No.	PART No.	DESCRIPTION	6T	T100	T110	TR6	T120
1	P53279/1	Bulb holder c/w bulb	1	1	1	1	1
2	P52305	Bulb holder	1	1	1	1	1
3	P.22469	Rubber ring, speedometer head	1	1	1	—	1
4	25578/2	Clamp bar	1	1	1	—	1
5	NI253	Nut, clamp bar	2	2	2	—	2
6	DS40	Bracket, speedometer head	—	—	—	1	—
7	F1369	Bolt, bracket, $\frac{5}{8}$ " U/H	—	—	—	2	—
8	HI015	Distance piece	—	—	—	2	—
9	S26-2	Washer, spring	—	—	—	2	—

SPEEDOMETER DRIVE

10	T924	Pinion, standard ratio layshaft 10T	1	1	1	1	1
11	T973	Pinion, wide ratio layshaft 8T	A	A	A	A	A
12	T925	Peg, pinion to layshaft	1	1	1	1	1
13	T934	Gear, standard ratio driven 16T	1	1	1	1	1
14	T975	Gear, wide ratio driven 15T	A	A	A	A	A
15	T825	Washer, gear thrust	1	1	1	1	1
16	D245	Cable, speedometer drive (44" long)	1	1	1	—	1
17	D245A	Cable, speedometer drive (44" long)	—	—	—	1	—
18	F3098	Clip, speedometer cable	1	1	1	1	1

SUSPENSION UNIT (GIRLING)—GROUP 38

19	SB4/279	Suspension unit	2	2	2	—	2
20	SB4/259	Suspension unit	—	—	—	2	—
21	SB4/275	Suspension unit (sidecar)	A	A	A	—	—
22	9054/316A	Bonded bush and sleeve	4	4	4	4	4
23	9054/171	Spring retainer	4	4	4	4	4
24	9054/151	Dirt shield, outer	2	2	2	2	2
25	9054/47	Dirt shield, inner	2	2	2	2	2
26	SA193/57	Spring 150 lbs. (sidecar) blue/red	A	A	A	A	A
27	9054/63	Spring 130 lbs. rate, red/yellow	A	A	A	A	A
28	9054/70	Spring 110 lbs. rate, purple/blue	A	A	A	A	A
29	9054/280	Spring 100 lbs. rate, green/green	2	2	2	2	2
30	9054/69	Spring 90 lbs. rate (road racing), yellow/white	A	A	A	A	A
31	E2113	Bolt, unit fixing, $1\frac{5}{16}$ " U/H	4	4	4	4	4
32	S25-2	Washer, lower bolt only	2	2	2	2	2
33	PO172A	Nut, unit fixing bolt	4	4	4	4	4
34	S26-1	Washer, fixing bolt nut	4	4	4	4	4

HIGH PERFORMANCE PARTS — GROUP 39

REF. No.	PART No.	DESCRIPTION	REMARKS
ENGINE			
1	CPI35	Piston, complete, CR 8 : 1	500 c.c. models
2	CPI33	Piston, complete, CR 8.5 : 1	" "
3	CPI61	Piston, complete, CR 9 : 1	" "
4	CPI34	Piston, complete, CR 9.5 : 1	" "
5	CPI32	Piston, complete, CR 12 : 1	" "
6	CPI63	Piston, complete, CR 8 : 1	650 c.c. "
7	CPI57	Piston, complete, CR 8.5 : 1	" "
8	CPI60	Piston, complete, CR 12 : 1	" "
CAMSHAFTS AND VALVE GEAR			
9	E1486R	Wheel, inlet and exhaust camshaft	3 keyway
10	E3134	Camshaft, inlet and exhaust	} Must be used together
11	E3059R	Tappet, inlet and exhaust	
12	E3411	Gear, magneto	
13	E3001	Valve, spring inner	} Interference fit
14	E3002	Valve, spring outer	
15	E3827	Valve guide, inlet	
16	E3828	Valve guide, exhaust	Bronze
CYLINDER HEAD (SPLAYED PORT)			
17	E3663	Head cylinder c/w guides and adaptors	500 c.c. models
18	E3766	Valve, inlet c/w guides and adaptors	" "
19	E1956	Valve, exhaust c/w guides and adaptors	" "
20	E3844	Adaptor, carburetter c/w guides and adaptors	" "
21	E3847	Locknut, adaptor c/w guides and adaptors	" "
22	E2961	Adaptor, exhaust pipe c/w guides and adaptors	" "
23	E3646	Tube, push rod cover	" "
24	E3550	Box, inlet rocker	" "
25	E3551	Box, exhaust rocker	" "
26	E3552	Gasket, rocker box joint	" "
27	E2982	Bolt, rocker box to head, 2 $\frac{5}{32}$ " U/H	" "
TACHOMETER DRIVE (WITH GENERATOR) KIT No. CPI62			
28	E3677	Cover, timing gears	2 off
29	E3678	Grub screw	
30	E3679	Housing, driving gear	
31	E3682	Housing, driven gear	
32	E3685	Nut, camshaft, L.H.	
33	E3686	Gear, driving	
34	E2749	Gear, driven	
35	5209/5	Cable, tachometer drive	
36	RC109	Head, tachometer	
37	H1083	Bracket, tachometer and speedometer	
38	H1086	Bolt, tachometer bracket	

GROUP 39 – HIGH PERFORMANCE PARTS

REF. No.	PART No.	DESCRIPTION	REMARKS
TACHOMETER DRIVE (WITHOUT GENERATOR)			
1	E3022	Gearbox, tachometer drive	
2	E3050	“O” ring seal	
3	E3010	Washer, gearbox joint	
4	E2994	Pinion, gearbox drive	
5	GS297	Nut, drive pinion	
6	E2995	Bolt	
7	H430	Washer, fibre	
8	E2996	Screw	
9	E2997	Nut	
10	E1612	Washer	
11	52091/5	Cable, tachometer drive	
12	RC126	Head, tachometer	
GEARBOX			
13	T427S	Nut, clutch spring	Steel
14	T1560	Spring, clutch pressure	Extra-strong
CLOSE RATIO GEARS, KIT No. CP95			
15	T1177	Mainshaft c/w low gear, 18T	
16	T1383	Gear, mainshaft high, 24T	
17	T955	Gear, mainshaft 2nd, 21T	
18	T1179	Gear, mainshaft 3rd, 23T	
19	T959	Layshaft c/w high gear, 22T	
20	T961	Gear, layshaft low, 28T	
21	T963	Gear, layshaft 2nd, 25T	
22	T964	Gear, layshaft, 23T	
23	T983	Plug, speedo drive housing	Alternative
24	T948	Washer, rubber	
25	T1227	Cap, speedo drive blanking	Alternative
To use speedometer with close ratio gears, fit standard drive gears and S467/131 head 1,425 r.p.m., obtainable from Messrs. Smiths.			
26	T1228	Pedal, gear change	
27	T1229/30	Kickstarter, folding	
FOOTRESTS			
28	F3699	Support plate, L.H. (silencer)	Alternative
29	F3700	Support plate, R.H. (silencer)	
30	F4345	Support plate, L.H. (megaphone)	Alternative
31	F4346	Support plate, R.H. (megaphone)	
32	F3703	Peg, support plates	4 off
33	F3702	Stud, support plates	2 off
34	F3450	Footrest, L.H.	
35	F3705CTE	Footrest, R.H., folding	
36	F3701	Stud, footrest to plate	2 off
37	H193	Nut	4 off
38	F1695	Rubber, footrest	2 off
39	F3166	Rod	Replaces footrest hanger
40	F3707	Pedal, rear brake	

REF. No.	PART No.	DESCRIPTION	REMARKS
----------	----------	-------------	---------

OIL TANK (1 GALLON)

1	F4329	Oil tank	
2	F3796	Filler cap "captive"	
3	F4335	Pipe, vent (flexible)	Long
4	F4330	Stud, seat lug to backstays	
5	F4331	Nut, R.H. only	
6	F4106	Bracket, bottom fixing	
7	F3814	Cup, top and bottom fixing	4 off
8	F4108	Rubber, top and bottom fixing	2 off
9	F967	Rubber, top and bottom fixing	2 off
10	F3816	Bolt, oil tank fixing	2 off
11	F3955	Nut, oil tank fixing	3 off
12	F2417	Wire, locking	2 off
13	F4110	Cup, rear fixing	2 off
14	F4109	Rubber, rear fixing	1 off
15	F4107	Rubber, rear fixing	1 off

CARBURETTERS

Cylinder head fittings for T122 to fit twin carburetters

16	E3006	Flange, inlet	1
17	E3009	Sleeve, inlet flange	2
18	E3004	Stud, flange to head	4
19	E3650	Joint washer, flange to head	2
20	E2728	Washer, stud	4
21	W103	Nut, stud	4
22	E2618	Joint washer, distance piece to flange	2
23	E3007	Distance piece, L.H.	1
24	E3008	Distance piece, R.H.	1
25	E2674	Stud, carburetter to flange	4
26	S1-51	Nut, carburetter	4
27	S25-3	Washer	4
28	NA-43	Joint washer, carburetter	2

Type 6 Carburetters

29	76AO	Carburetter mixing chamber assembly, L.H. ...	
30	76AN	Carburetter mixing chamber assembly, R.H. ...	
31	14/538	Float chamber (remote)	
32	F3745	Clip, frame tube	2
33	F3740	Block, rubber	1
34	F1149	Bolt, frame clip	2
35	E1612	Washer, shakeproof	2
36	W103	Nut, frame clip	2
37	F3746	Clip, float chamber	1
38	TE164D	"D" washer	1
39	TE164C	"D" nut	1
40	TE164E	Bolt, float clip	1

GROUP 39 – HIGH PERFORMANCE PARTS

REF. No.	PART No.	DESCRIPTION	REMARKS
Petrol Pipes Type 6 Carburetters			
1	F3748	Pipe, tank to float chamber	2 off
2	F3694	Pipe, mixing chambers connecting	
3	F3695	Pipe, connecting pipe to float chamber (flexible) ...	
4	D177-2	Clip, flexible pipe	2 off
Monobloc Carburetters (for 500 c.c. Models without splayed port)			
5	376/75	Carburetter, R.H. with modified float chamber ...	Amal supply
6	376/74	Carburetter, L.H. (376/35 suitable if already fitted) ...	Amal supply
7	376/128	Nut, special main jet cover, threaded	Amal supply
8	F4250	Pipe, balance	
Petrol Pipes. For standard tank and twin Monobloc carburetters			
9	F2593	Adaptor and gauze	2
10	F1511	Washer, fibre	5
11	F4286	Pipe to T-piece	2
12	F4289	Olive, petrol pipe	2
13	F4290	Nut, petrol pipe	2
14	F4285	T-piece	1
15	F4303	Tap, petrol	1
16	F4291	Pipe, tap to carburetters	1
Monobloc Carburetters (splayed port Models)			
17	376/77	Carburetter 1" bore	500 c.c. models
18	376/40	Carburetter 1 $\frac{1}{8}$ " bore	650 c.c. models
G.P. Carburetter (500 c.c. splayed port Models)			
19	E3671	Adaptor, cylinder head	2
20	E3786	Connection, rubber	2
21	1 $\frac{1}{4}$ "-1 $\frac{3}{4}$ "	Jubilee clip	4
22	E3675	Adaptor, carburetter	2
23	15GP	Carburetter, 1" bore	2
24	302/11	Float chamber (remote)	1
25	F4342	Bracket, carburetter and float chamber	1
26	F4344	Connection, petrol pipe	1
27	E3203	Grommet, float chamber bracket	
28	F4341	Stud, float chamber bracket	
29	F879	Nut	2
30	S25-1	Washer	2
31	F3840	Cap, float chamber bracket	2
32	E2593	Bolt	1
33	S1051	Nut	1
34	S26-3	Washer	1

REF. No.	PART No.	DESCRIPTION	REMARKS
Throttle Cable G.P. Carburetters			
1	D379	Throttle cable assembly	
2	D380	Cable, handlebar to junction box	
3	244/104	Junction box, throttle cable	
4	D381	Cable, junction box to carburetter	2 off

**For Type 6 or Monobloc Carburetters use the
T120 throttle cable**

HANDLEBARS

5	H1082	Handlebar, racing dropped	$\frac{7}{8}$ " diameter
6	18/557	Lever, assembly front brake	
7	18/556	Lever assembly, clutch	
8	12/161	Lever assembly, ignition	
9	16/117	Twistgrip	
10	16/069	Grip, handlebar	

SUSPENSION UNITS

11	SB4/259	Suspension unit ($3\frac{1}{2}$ " stroke)	Standard on Trophy
----	---------	---	--------------------

EXHAUST PIPES & MEGAPHONES

12	E3628	Pipe, exhaust, L.H. $1\frac{1}{2}$ "	T110 Standard also TR6
13	E3632	Pipe, exhaust, R.H. $1\frac{1}{2}$ "	
14	E3817	Silencer, L.H. (straight through)	
15	E3816	Silencer, R.H. (straight through)	T100 Standard with silencers E3817 and E3816
16	E3629	Pipe, exhaust, L.H. $1\frac{1}{2}$ "	
17	E3633	Pipe, exhaust, R.H. $1\frac{1}{2}$ "	
18	E3630	Pipe, exhaust, L.H. $1\frac{1}{2}$ "	T100
19	E3634	Pipe, exhaust, R.H. $1\frac{1}{2}$ "	
20	E2734	Megaphone, L.H.	
21	E2735	Megaphone, R.H.	T100
22	E3479L.H.	Megaphone, L.H. (reverse cone)	
23	E3479R.H.	Megaphone, R.H. (reverse cone)	
24	E3778	Pipe, exhaust, L.H., $1\frac{5}{16}$ "	T100
25	E3780	Pipe, exhaust, R.H. $1\frac{5}{16}$ "	
26	E3782	Megaphone, L.H.	
27	E3783	Megaphone, R.H.	
28	E3023	Extension, L.H. $1\frac{1}{2}$ "	
29	E3024	Extension, R.H. $1\frac{1}{2}$ "	
30	E3103	Extension, L.H. $1\frac{3}{4}$ "	
31	E3104	Extension, R.H. $1\frac{3}{4}$ "	

GROUP 39 — HIGH PERFORMANCE PARTS

REF. No.	PART No.	DESCRIPTION	REMARKS
----------	----------	-------------	---------

MUDGUARDS

1	H1269	Mudguard, front	...	...	...	...	...	1
2	H1271	Stay, front	...	...	...	...	...	1
3	H1270	Bridge, mudguard support	...	...	...	...	...	1
4	H1273	Stay, lower	...	...	...	...	...	1
5	H2335	Bolt, bridge and stay to fork leg	...	...	...	...	...	2
6	S25-3	Washer, plain	...	...	...	...	...	2
7	F929	Bolt, lower stay to fork leg	...	...	...	...	...	2
8	S25-3	Washer, plain	...	...	...	...	...	2
9	DS57	Bolt, mudguard to stays, $\frac{7}{16}$ " U/H	...	...	...	...	...	6
10	S25-1	Washer, plain	...	...	...	...	...	6
11	F879	Nut	...	...	...	...	...	6
12	F4348	Mudguard, rear	...	...	...	...	...	1
13	F4340	Bridge, mudguard	...	...	...	...	...	1
14	DS57	Bolt	...	...	...	...	...	4
15	S26-2	Washer	...	...	...	...	...	4
16	F879	Nut	...	...	...	...	...	4
17	F3880	Stay, c/w racing number brackets	...	...	...	...	...	1
18	DS55	Bolt, stay to frame	...	...	...	...	...	2
19	S26-3	Washer	...	...	...	...	...	2
20	SI-51	Nut	...	...	...	...	...	2

GUARANTEE

WE give the following guarantee with our motorcycles, motorcycle combinations and sidecars, including all accessories and component parts other than tyres, saddles, chains and lighting and electrical equipment, and other than accessories and component parts supplied to the order of the Purchaser and differing from those comprised in the standard specifications supplied with our motorcycles, motorcycle combinations and sidecars, but including accessories and parts supplied by way of exchange as hereinafter provided. This guarantee is given in place of any implied conditions or warranties or any liabilities whatsoever statutory or otherwise; no guarantee except that hereinafter contained and no conditions or warranty whatsoever statutory or otherwise is given or is to be implied, nor are we to be under any liability whatsoever except under the guarantee hereinafter contained. Any statement, description, condition or representation contained in any catalogue, advertisement, leaflet or other publication shall not be construed as enlarging, varying or overriding anything herein contained. In the case of machines (a) which have been used for "hiring out" purposes or (b) any motorcycle and/or sidecar used for any dirt track, cinder track or grass track racing or competitions (or any competition of any kind within an enclosure for which a charge is made for admission to take part in or view the competition) or (c) machines from which the trade mark, name or manufacturing number has been altered or removed or (d) any machines in which parts have been used not supplied by or approved by the motorcycle manufacturer or (e) any machine from which the silencing system as fitted by the manufacturer has been partially or wholly removed or interfered with, no guarantee, condition or warranty of any kind statutory or otherwise, is given or is to be implied, nor are we to be under any liability whatsoever in respect of any such machine. We guarantee, subject to the conditions mentioned below, that all precautions which are usual and reasonable have been taken by us to secure excellence of materials and workmanship but this guarantee is to extend and be in force for six months only in U.K. and ninety days overseas from date of purchase, or date of exchange in case of any accessory or part supplied by way of exchange as hereinafter provided, and damages for which we make ourselves responsible under this guarantee are limited to the free repair of or supply of a new part or accessory in exchange for the part of the motorcycle, motorcycle combination or sidecar or accessory which may have proved defective. We undertake, subject to the conditions mentioned below, to make good in manner aforesaid any part or accessory covered by this guarantee which has proved defective within the said period. We do not undertake to replace or refix or bear the cost of replacing or refixing any such new part or accessory in the motorcycle, motorcycle combination or sidecar. As motorcycles, motorcycle combinations and sidecars are easily liable to derangement by neglect or misuse, this guarantee does not apply to defects caused by wear and tear, misuse or neglect. The term "misuse" shall include, amongst others, the following acts: 1. The attaching of a sidecar to a motorcycle in such a manner as to cause damage or calculated to render the latter unsafe when ridden. 2. The use of a motorcycle or of a motorcycle and sidecar combined, when carrying more persons or a greater weight than that for which the machine was designed by the manufacturers. 3. The attaching of a sidecar to a motorcycle by any form of attachment not provided, supplied or approved by the manufacturers, or to a motorcycle which is not designed for such use. We do not guarantee tyres, saddles, chains or lighting and electrical equipment, or any accessories or component parts supplied to the order of the Purchaser differing from those comprised in the standard specifications supplied with our motorcycle combinations or sidecars. As regards all such tyres, saddles, chains, lighting and electrical equipment, accessories and component parts, no guarantee, condition or warranty of any kind statutory or otherwise is given or is to be implied, and we are to be under no liability whatsoever in respect thereof.

CONDITIONS OF GUARANTEE

If a defective part or accessory should be found in our motorcycles, motorcycle combinations or sidecars, or in any part or accessory supplied by way of exchange as before provided, it must be sent to us CARRIAGE PAID and accompanied by an intimation from the owner that he desires to have it repaired or exchanged free of charge under our guarantee, and he must also furnish us at the same time with the frame number of the machine, the date of purchase or the date when the alleged defective part or accessory was exchanged as the case may be. Failing compliance with the above, such articles will lie here at THE RISK OF THE OWNER, and this guarantee and any implied guarantee, warranty or condition shall not be enforceable.

REPAIRS

Any motorcycle, motorcycle combination or sidecar sent to us to be plated, enamelled or repaired will be repaired upon the following conditions, i.e., we guarantee that all precautions which are usual and reasonable have been taken by us to secure excellence of materials and workmanship, such guarantee to extend and be in force for three months only from the time such work shall have been executed, and this guarantee is in lieu and in exclusion of all conditions and warranties statutory or otherwise, and all liabilities whatsoever and the damages recoverable are limited to the cost of any further work which may be necessary to amend and make good the work found to be defective.

NOTE

We do not appoint agents for the sale on our behalf of our motorcycles or other goods, but we assign to motorcycle Dealers areas in which we supply to such Dealers exclusively for re-sale in such areas. No such Dealer is authorised to transact any business, give any warranty, make any representation or incur any liability on our behalf. Published retail prices are for delivery free of charge at Dealers' premises. All goods are offered for sale subject to the price ruling at time of delivery. We reserve the right to modify or deviate from the published specification.

TRIUMPH SERVICE

There are Triumph distributors and dealers in all parts of the world who carry adequate stocks of Triumph parts and who are ready at all times to help and advise owners of Triumph motorcycles.

INDEX

	Page No.
Group 1—CARTON PACKS	9
Group 2—ENGINE	19
Connecting rods	23
Crankcase	23
Crankcase bearings	32
Crankcase breather	34
Crankcase oil filter	32
Crankcase and flywheel assembly	22
Cylinder block	19
Cylinder head	19
Inlet manifold	19
Engine sprocket	35
Oil pump	32
Oil release valve	33
Overhead rocker gear	34
Piston, rings, etc.	21
Push rods	34
Push rod cover tube	34
Rocker oil feed and drain pipes	35
Studs and bolts for crankcase halves	32
Tappets and tappet blocks	34
Timing cover	33
Timing gear and camshafts	33
Valves, guides and springs	21
Group 3—GASKET SET	35
Group 4—GEARBOX	36
Clutch and shock absorber	41
Clutch control	42
Gear change selector mechanism	40
Gearbox casing	36
Gearbox fittings	37
Gearbox casing bearings	37
Gearbox sprocket	41
Kickstarter	40
Shafts and gears	37
Group 5—WIDE RATIO GEARS	43
Group 6—STANDARD RATIO GEARS	43
Group 7—CLOSE RATIO GEARS	43
R.P.M. and gear ratio charts	44
Group 8—EXHAUST SYSTEM	45

														Page No.
Group 9—FRAME	...	...	...	...	...	...	...	...	...	...	...	...	...	48
Front portion	...	...	...	...	...	...	...	...	...	...	...	...	...	50
Rear portion ...	...	...	...	...	...	...	...	...	...	...	...	...	...	50
Swinging fork	...	...	...	...	...	...	...	...	...	...	...	...	...	51
Group 10—STAND	...	...	...	...	...	...	...	...	...	...	...	...	...	51
Front stand ...	...	...	...	...	...	...	...	...	...	...	...	...	...	51
Centre stand	...	...	...	...	...	...	...	...	...	...	...	...	...	51
Prop stand ...	...	...	...	...	...	...	...	...	...	...	...	...	...	51
Group 11—ENGINE PLATES	...	...	...	...	...	...	...	...	...	...	...	...	...	52
Group 12—FRONT FORK	...	...	...	...	...	...	...	...	...	...	...	...	...	53
Group 13—FRONT WHEEL	...	...	...	...	...	...	...	...	...	...	...	...	...	59
Group 14—REAR WHEEL	...	...	...	...	...	...	...	...	...	...	...	...	...	64
Group 15—REAR WHEEL (Quickly detachable)	...	...	...	...	...	...	...	...	...	...	...	...	...	67
Group 16—MUDGUARDS	...	...	...	...	...	...	...	...	...	...	...	...	...	68
Front mudguard	...	...	...	...	...	...	...	...	...	...	...	...	...	68
Rear mudguard	...	...	...	...	...	...	...	...	...	...	...	...	...	70
Licence holder	...	...	...	...	...	...	...	...	...	...	...	...	...	70
Group 17—NUMBER PLATE	...	...	...	...	...	...	...	...	...	...	...	...	...	70
Group 18—PETROL AND OIL TANK	...	...	...	...	...	...	...	...	...	...	...	...	...	71
Parcel grid	...	...	...	...	...	...	...	...	...	...	...	...	...	74
Petrol tank	...	...	...	...	...	...	...	...	...	...	...	...	...	71
Oil tank	...	...	...	...	...	...	...	...	...	...	...	...	...	74
Group 19—CHAINGUARD	...	...	...	...	...	...	...	...	...	...	...	...	...	74
Group 20—PRIMARY CHAINCASE	...	...	...	...	...	...	...	...	...	...	...	...	...	76
Group 21—HANDLEBAR	...	...	...	...	...	...	...	...	...	...	...	...	...	78
Air control	...	...	...	...	...	...	...	...	...	...	...	...	...	80
Clutch control	...	...	...	...	...	...	...	...	...	...	...	...	...	80
Front brake control	...	...	...	...	...	...	...	...	...	...	...	...	...	80
Handlebar bend	...	...	...	...	...	...	...	...	...	...	...	...	...	78
Throttle control	...	...	...	...	...	...	...	...	...	...	...	...	...	78
Magneto control	...	...	...	...	...	...	...	...	...	...	...	...	...	81
Group 22—CONTROL CABLE	...	...	...	...	...	...	...	...	...	...	...	...	...	81
Air cable	...	...	...	...	...	...	...	...	...	...	...	...	...	82
Clutch cable	...	...	...	...	...	...	...	...	...	...	...	...	...	81
Front brake cable	...	...	...	...	...	...	...	...	...	...	...	...	...	81
Ignition cable	...	...	...	...	...	...	...	...	...	...	...	...	...	82
Throttle cable	...	...	...	...	...	...	...	...	...	...	...	...	...	81

	Page No.
Group 23—OVERSEAS HANDLEBARS	82
Group 24—REAR BRAKE CONTROL	83
Group 25—FOOTRESTS	83
Group 26—BATTERY CARRIER AND TOOLBOX	84
Group 27—TOOLKIT	86
Group 28—AIR FILTER	88
Group 29—LEGSHIELDS	89
Group 30—SIDECAR FITTINGS	89
PROPRIETARY FITTINGS	90
Group 31—AMAL CARBURETTER	91
Group 32—CHAINS	95
Group 33—LUCAS LIGHTING AND IGNITION EQUIPMENT (Dynamo and Magneto)	96
Battery	99
Cut-out and regulator unit	96
Dynamo	96
Handlebar switches and push buttons	99
Headlamp—Nacelle type	97
Headlamp—Trophy type	97
Horn	97
Magneto	100
Nacelle instrument panel	99
Stop-tail lamp	99
Wiring harness	99
Group 34—LUCAS LIGHTING AND IGNITION (Alternator)	104
Alternator	104
Battery	106
Distributor	104
Headlamp	105
Horn push and dipper switch	106
Horn	106
Ignition coil	104
Nacelle instrument panel	106
Rectifier	104
Stop-tail lamp	105
Wiring harness	106

													<i>Page No.</i>
Group 35—TWINSEAT	...	...	...	...	...	...	...	...	...	...	...	...	107
Group 36—SPARKING PLUGS	...	...	...	...	...	...	...	...	...	...	...	...	107
Group 37—SPEEDOMETER	...	...	...	...	...	...	...	...	...	...	...	...	107
Group 38—SUSPENSION UNITS (GIRLING)	...	...	...	...	...	...	...	...	...	...	...	...	108
Group 39—HIGH PERFORMANCE PARTS	...	...	...	...	...	...	...	...	...	...	...	...	109

ILLUSTRATION INDEX

	Page No.
Fig. 1 Inlet Manifolds	20
„ 2 Engine 6T Crankcase, cylinder block and head	24
„ 3 Engine 6T Crankshaft, connecting rod, pistons and timing gear	24
„ 4 Engine T100 Crankcase, cylinder block and head	26
„ 5 Engine T100 Crankshaft, connecting rods, pistons and timing gear	26
„ 6 Engine TR6 and T110 Crankcase, cylinder block and head	28
„ 7 Engine TR6 and T110 Crankshaft, connecting rods, pistons and timing gear	28
„ 8 Engine T120 Crankcase, cylinder block and head	30
„ 9 Engine T120 Crankshaft, connecting rods, pistons and timing gear	30
„ 10 Gearbox	38
„ 11 Clutch and shock absorber	42
„ 12 Exhaust pipes and silencers	46
„ 13 Frame	48
„ 13 Engine plates, studs, bolts, nuts and washers	52
„ 15 Telescopic fork 6T, T100, T110 and T120	54
„ 16 Telescopic fork TR6	56
„ 17 Front wheel 6T	60
„ 18 Front wheel T100, T110, TR6 and T120	62
„ 19 Rear wheel	65
„ 20 Rear wheel (quickly detachable)	68
„ 21 Front and rear mudguards	66
„ 22 Petrol tanks and fittings	72
„ 23 Oil tank	75
„ 24 Primary chaincase	77
„ 25 Handlebar and controls	79
„ 26 Battery carrier and toolbox	85
„ 27 Tool kit	87
„ 28 Air filter	88
„ 29 Amal carburetter	92
„ 30 Headlamp	98
„ 31 Magneto	103

To assist the owner and dealer in identifying requirements, this book contains numerous exploded views of major assemblies. Each component part is numbered and by cross reference to the illustration index, the part number of the component will be found. Against each part number a page and reference number is shown and by referring to the appropriate page, the full description of the part will be found against the reference number.

Example.

To find the part number of a scraper ring for the model T100.

1. Refer to illustration index above where it will be found that the exploded view of the T100 crankshaft assembly is on page 26.
2. Note that the number of the scraper ring on the illustration is 4.
3. Refer to the index for the illustration in question on page 27.
4. Note that No. 4 is part number GE29, listed on page 22, Reference line No. 7.

British Only

MOTORCYCLES AND PARTS INC.

32451 PARK LANE
GARDEN CITY, MI 48135 USA

PHONE ORDER HOURS:
MONDAY THRU FRIDAY 10-6 EST

Fax or email 24 hours a day!

RETAIL: 734-421-0303
WHOLESALE: 734-525-1980
FAX: 734-422-9253
EMAIL: info@britishonly.com
WEBSITE: www.britishonly.com

THE BIGGEST!

ENGINE REBUILDING PARTS
GASKETS-SEALS-BEARINGS
BUSHINGS-PISTONS-RINGS
CLUTCHES-TUNE UP PARTS
SPEED EQUIPMENT

THE BEST!

STOCK AND CUSTOM PARTS
SEATS-HANDLEBARS-CHAINS
TIRES-TUBES-EXHAUST PIPES
MUFFLERS-GAS TANKS-FENDERS
RESTORATION PARTS

THE ONLY!

WORLD'S LARGEST SELECTION OF FACTORY ORIGINAL NEW AND USED PARTS
45,000 SQ. FT. OF MOTORCYCLE PARTS & ACCESSORIES FROM 1911 TO 1984 FOR ALL BRITISH MAKES!
CASH FOR ALL BRITISH BIKES, PARTS AND LITERATURE

V.I.P. Buyers Club

10% OR MORE OFF 17,000 PARTS



British Only E-Store

Bookstore
New Products
Scratch & Dent
Blue Light Specials

50,000+ PARTS
LISTED ONLINE
7,000+ PARTS
VIEWABLE ONLINE

CALL FOR OUR FREE 200 PAGE CATALOG!

OVERSEAS CUSTOMERS PLEASE SEND \$10.00 FOR AIR POST

1-800-BRT-ONLY

OR

1-800-278-6659

Visit our ever expanding website!

www.britishonly.com

50,000+ PARTS LISTED ONLINE
7,000+ PARTS VIEWABLE ONLINE

— AMAL
— LUCAS
— SMITHS
— ROWE
— HEPOLITE
— MORGO
— DUNLOP
— RENOLD
— MEGACYCLE
— JOE HUNT
— BOOKSTORE
— NORVIL
— MORGO
— BARNETT
— JP PISTONS
— ALPHA

SPECIALIZING IN

TRIUMPH

Norton

BSA

PARTS
SHIPPED
WORLDWIDE!



----- Fold -----

NAME _____

ADDRESS _____

CITY _____

STATE _____ ZIP _____

USE
FIRST CLASS
LETTER
POSTAGE

British Only

MOTORCYCLES AND PARTS INC.

32451 PARK LANE
GARDEN CITY MI 48135 U.S.A.

----- Fold -----

British Only

MOTORCYCLES AND PARTS INC.

**32451 PARK LANE
GARDEN CITY, MI 48135
ORDER DESK 1-800-278-6659
OTHER INQUIRIES 734-421-0303
FAX 734-422-9253**

Web Address: <http://www.britishonly.com>
E-mail: info@britishonly.com

Year
Make
Model

[illegible]

Date _____ / _____ / _____ Customer # _____ Salesperson _____

Credit Card Used _____ Card# _____ Expires _____

Name _____

Address _____

City / State / Zip _____

Phone _____ / _____ Fax _____ / _____

Email _____

Signature _____

Subtotal	
Insurance	
Shipping	
Total	
Michigan Residents Add 6% Sales Tax	
Amount Enclosed	

042600

----- Fold -----

NAME _____

ADDRESS _____

CITY _____

STATE _____ ZIP _____

USE
FIRST CLASS
LETTER
POSTAGE

British Only

MOTORCYCLES AND PARTS INC.

32451 PARK LANE
GARDEN CITY MI 48135 U.S.A.

----- Fold -----

MOTORCYCLES AND PARTS INC.

Web Address: <http://www.britishonly.com>
E-mail: info@britishonly.com

Year
Make
Model

[illegible]

Date _____ / _____ / _____ Customer # _____ Salesperson _____

Credit Card Used _____ Card# _____ Expires _____

Name _____

Address _____

City / State / Zip _____

Phone _____ / _____ Fax _____ / _____

Email_____

Signature_____

Subtotal	
Insurance	
Shipping	
Total	
Michigan Residents Add 6% Sales Tax	
Amount Enclosed	

042600