

MONOBLOC CARBURETTER SPARE PARTS LIST

Component	Type 375	Type 376	Type 389
Mixing Chamber Body, Type 375	} For Part Numbers refer to Settings List		
Mixing Chamber Body, Type 376			
Mixing Chamber Body, Type 389			
"O" Ring for Intake Flange			
Jet Block, $\frac{3}{16}$ " Bore	244/765	244/1048	244/1048
Jet Block, $\frac{3}{16}$ " Bore	375/055	—	—
Jet Block, $\frac{3}{16}$ " Bore	375/056	—	—
Jet Block, $\frac{3}{16}$ " Bore	375/057	—	—
Jet Block, $\frac{1}{8}$ " Bore	375/058	—	—
Jet Block, $\frac{1}{8}$ " Bore	375/059	—	—
Jet Block, $\frac{1}{8}$ " Bore	—	376/055	—
Jet Block, 1" Bore	—	376/056	—
Jet Block, 1 $\frac{1}{16}$ " Bore	—	376/057	—
Jet Block, 1 $\frac{3}{32}$ " Bore	—	—	389/055
Jet Block, 1 $\frac{1}{8}$ " Bore	—	—	389/056
Jet Block, 1 $\frac{3}{16}$ " Bore	—	—	389/057
Jet Block, 1 $\frac{1}{2}$ " Bore	—	—	389/058
Locating Peg for Jet Block	376/070	376/070	376/070
Washer for Jet Block	375/067	376/067	376/067
Mixing Chamber Top (Std.)	375/064	376/064	389/064
Mixing Chamber Top for Adjuster and Ferrule	375/107	376/107	389/107
Mixing Chamber Top for Two Ferrules	375/099	376/099	389/099
Mixing Chamber Top Cap Ring	375/065	376/065	389/065
Cap Spring for Standard Top	4/235	4/235	29/201
Cap Spring for Top with Adjuster Ferrule	4/276	4/276	29/301
Cap Spring for Rod Control, with Adjuster	375/070	29/307	389/067
Cap Spring for Rod Control, with Ferrule	375/071	29/308	389/068
Fixing Screw for Cap Springs	4/241	4/241	4/241
Cable Adjuster	4/035	4/035	4/035
Cable Ferrules (Top Hat)	6/132A	6/132A	6/132A
Plug Screw	4/137A	4/137A	4/137A
Throttle Valve (specify cutaway)	375/060	376/060	389/060
Throttle Valve Spring (lighter than St'd)	—	376/132	—
Throttle Valve Spring	375/061	376/061	389/061
Throttle Valve Spring (Triumph T21)	375/079	—	—
Throttle Valve Spring (Carb. pairs)	—	376/132	—
Taper Needle	375/063	376/063	389/063
Taper Needle (for Alcohol only)	—	376/116	389/088
Needle Clip	4/230	4/230	4/230
Air Valve	375/062	376/062	389/062
Air Valve Guide	5/047	6/047	29/057
Air Valve Spring	4/046	4/046	4/046