SPARE PARTS LIST

for TYPE 302 LARGE TOP FEED FLOAT CHAMBER

Component	Туре. 302/1	(Remote) Type 302/3	Туре 302/10	(Remote) Type 302/11	List
	PART No.	PART No.	PART No.	Part No.	Pric
Complete Float Chamber	302/1	302/3	302/10	302/11	70
Float Chamber Body only	302/001	302/015	302/001	302/015	30
Cover complete with Baffle	302/902	302/002	302/002	302/002	20
Cover Fixing Screws	302/009	302/009	302/009	302/009	
Cickler	302/010	302/010	302/010	302/010	1
ickler Spring	14/032	14/032	14/032	14/032	_
Cickler Cotter	14/033	14/033	14/033	14/033	
Y 11 TT7 -1	14/189	14/189	14/189	14/189	
, ,	302/004	302/004	11/100	11/100	5
	302/032	302/032			5
San make	302/042	302/042	302/042	302/042	5
37 11	14/320	14/320	302/012	304/042	2
	302/035	302/035			2
37 11		302/033	302/044	302/044	
loat Needle	302/044		302/044	302/044	2
Base Plug and Guide modification *	14/321-2	14/321-2	i i	N.	3
Base Plug and Guide	14/322-302/036	14/322-302/036	900/045 0	000/045 0	3
Base Plug and Guide	302/045-6	302/045-6	302/045-6	302/045-6	3
Base Plug Washer	14/252	14/252	14/252	14/252	
Banjo Single	14/249	14/249	14/249	14/249	3`
Banjo Twin 90°	14/250	14/250	14/250	14/250	7
Banjo Twin 180°	14/251	14/251	14/251	14/251	7
Banjo Nut	14/255	14/255	14/255	14/255	1
Banjo Washers	14/275	14/275	14/275	14/275	
Petrol Union Nuts	14/042	14/042	14/042	14/042	
Petrol Union Nipples	14/026	14/026	14/026	14/026	
Plug Screw	14/232		14/232		
Plug Screw Washer	14/241	-	14/241		
Float Chamber Connection		14/219		14/219	3
Float Chamber Connection Washer		14/336		14/386	P
Mixing Chamber Connection	15 1 -	14/218		14/218	2
Banjo Connection (for M/ch.)		302/057		302/057	2
Banjo Connection Washer		14/336		14/336	
Banjo		302/058	5	302/058	3
Banjo Washers		14/037		14/037	
Banjo Nut		302/056		302/056	1
Base Plug and Guide (Excelsior)	302/069-046		302/069-046	,	3

^{*}Original part Numbers 302/004, 14/320, 14/321-2 were modified to 302/032, 302/035, 14/322-302/036 since when a further modification was made, *i.e.*, 302/042, 302/045-6.

We suggest that parts prior to the last modification should be replaced as an assembly so bringing the float chamber to the latest setting.

GUARANTEE.—The Company take all possible reasonable care in the manufacture and the quality of their products. Purchasers are informed that, any part proved to be defective in manufacture or quality, and returned to the works within six months of its purchase new, will be replaced. The Company must respectfully point out however, that its responsibility and that of its agents, stockists and dealers, is limited to this Guarantee, and that they cannot, under any circumstances, be held responsible for any loss or for any contingent or resulting liability arising through any defect.

These conditions of sale and use also apply when the Company's products form part of the original equipment of machines purchased new.

(THIS LIST IS PRINTED IN ENGLAND, AND IS ISSUED SUBJECT TO PRICES RULING AT THE DATE OF DELIVERY).

AMAL LTD., Holdford Road, Witton, BIRMINGHAM, 6 ENGLAND. TELEGRAMS: AMALCARB (PHONE), BIRMINGHAM.

TELEPHONE: BIRCHFIELDS 4571 (6 lines).

1,000/7/53. W.

PAGE FOUR