




- | | | |
|----|---------|--------------------|
| 1 | DE 6542 | SCREW |
| 2 | DE 0319 | COVER |
| 3 | DE 0535 | PIN |
| 4 | DE 7415 | SPRING |
| 5 | DE 0522 | LEVER - Ø 30-32-34 |
| 6 | DE 0426 | LEVER - Ø 36 |
| 7 | DE 1104 | SCREW |
| 8 | DE 1691 | NUT |
| 9 | DE 7745 | SCREW |
| 10 | DE 0295 | COVER |
| 11 | DE 0297 | GASKET |
| 12 | DE 4043 | SPRING |
| 13 | DE 3238 | VALVE |
| 14 | DE 0678 | GASKET |
| 15 | DE 0260 | WASHER |
| 16 | DE 7446 | SPRING |
| 17 | DE 7449 | SCREW |
| 18 | DE 7673 | SCREW |
| 19 | DE 4670 | SPRING |
| 20 | DE 4650 | WASHER |
| 21 | DE 7540 | GASKET |
| 22 | DE 7052 | JET HOLDER |
| 23 | DE 0426 | GASKET |
| 24 | DE 7051 | JET |
| 25 | DE 0173 | GASKET |
| 26 | DE 0558 | VALVE |
| 27 | DE 0598 | GASKET |
| 28 | DE 0539 | SCREW |
| 29 | DE 0599 | NUT |
| 30 | DE 0428 | SCREW |
| 31 | DE 5011 | LOCK WASHER |
| 32 | DE 0556 | COVER |
| 33 | DE 7626 | SPRING |
| 34 | DE 0555 | DIAPHRAGM |
| 35 | DE 7746 | STARTER JET |
| 36 | DE 0540 | NEEDLE JET |
| 37 | DE 0552 | JET HOLDER |
| 38 | DE 0541 | MAIN JET |
| 39 | DE 0550 | SPRING |
| 40 | DE 0525 | CLIP |
| 41 | DE 0551 | SLIDE |
| 42 | DE 0510 | NEEDLE |
| 43 | DE 0511 | GASKET |
| 44 | DE 0128 | THREADED RING |
| 45 | DE 0595 | INSULATING BUSHING |
| 46 | DE 0127 | SCREW |
| 47 | DE 0527 | CLAMP |
| 48 | DE 0109 | FILTER |
| 49 | DE 7890 | TWO-WAY CONNECTOR |
| 50 | DE 4052 | GASKET |
| 51 | DE 4568 | SCREW |
| 52 | DE 0557 | INTAKE VALVE |
| 53 | DE 1486 | IDLE JET |
| 54 | DE 0288 | GASKET |
| 55 | DE 0649 | VALVE |
| 56 | DE 7450 | FLOAT |
| 57 | DE 7146 | FLOAT BOWL PIN |
| 58 | DE 7451 | GASKET |
| 59 | DE 7881 | FLOAT BOWL |
| 60 | DE 4057 | GASKET |
| 61 | DE 0551 | PLUG |
| 62 | DE 0679 | PLUG |
| 63 | DE 4711 | GASKET |
| 64 | DE 0291 | STARTER CPT. |
| 65 | DE 6273 | CONNECTOR |