GENERAL INFORMATION.

The "MONOBLOC" Carburetters are supplied with or without an air valve. If an air valve is required it can be supplied suitable for operation by a cable and lever from the handle bar or by a rod on the carburetter itself. The standard range of float chamber banjo connections available are as follows:


Banjo Part No. 375/068. Single feed for \(\frac{3}{16}\)" bore flexible pipe.

Banjo Part No. 376/090. Single feed, screwed \(\frac{1}{4}\)" B.S.P., complete with nut and nipple for copper pipe.

Banjo Part No. 376/097. Single feed for \(\frac{1}{4}\)" bore flexible pipe.

Banjo Part No. 376/098. Double feed for \(\frac{1}{4}\)" bore flexible pipes.

Banjo Part No. 376/108. Double feed, screwed \(\frac{1}{4}\)" B.S.P., complete with nuts and nipples for copper pipes



DIMENSIONS OF CARBURETTER

Type Number	A	В	С	D	E	F	G	Н	J	K	Available with Cross Bore Sizes
	ins.	ins.	ins.	ins.	²¹ / ₃₂ in. (16·7 m/m.) ²³ / ₃₂ in. (18·3 m/m.)						
375	3.29	2.50	-156	2.18	1-21	1.34	1.146	2.062	1.437	3.93	32 in. (19·8 m/m.) 32 in. (19·8 m/m.) 33 in. (20·6 m/m.) 3 in. (22·2 m/m.)
376	3.39	2.78	-187	2.27	1.31	1.44	1.25	1.94	1.625	4.38	15 in. (23·8 m/m.) 1 in. (25·4 m/m.) 1 li. (27·0 m/m.)
389	3.53	2.97	-187	2.33	1.37	1.50	1.39	2.062	1.75	4.70	1½ in. (28-6 m/m.) 1½ in. (29-4 m/m.) 1¾ in. (30-2 m/m.)